

### STM32F303CCT6 MCU

STM32F303CCT6x

### HEADER PINS

Conn\_02x05\_Odd\_Even

| Pin | Signal |
|-----|--------|
| 1   | 3V3    |
| 2   | PA1    |
| 3   | PA3    |
| 4   | PA5    |
| 5   | PA7    |
| 6   | PC13   |
| 7   | LED_1  |
| 8   | LED_2  |
| 9   | LED_3  |
| 10  | PA4    |
| 11  | PA2    |
| 12  | PA6    |
| 13  | PA15   |
| 14  | PA14   |
| 15  | PA12   |
| 16  | PA10   |
| 17  | PA9    |
| 18  | PA8    |
| 19  | PA7    |
| 20  | PA6    |
| 21  | PA5    |
| 22  | PA4    |
| 23  | PA3    |
| 24  | PA2    |
| 25  | PA1    |
| 26  | 3V3    |

Conn\_02x05\_Odd\_Even

| Pin | Signal |
|-----|--------|
| 1   | PB0    |
| 2   | PB10   |
| 3   | PB12   |
| 4   | PB14   |
| 5   | PB15   |
| 6   | PB13   |
| 7   | PB11   |
| 8   | PB9    |
| 9   | PB8    |
| 10  | PB7    |
| 11  | PB6    |
| 12  | PB5    |
| 13  | PB4    |
| 14  | PB3    |
| 15  | PB2    |
| 16  | PB1    |
| 17  | PB0    |
| 18  | 3V3    |

### MICRO USB

MICRO USB

### MPU6050

MPU6050

### LCD

File: LCD.kicad\_sch

### stlinkv3

File: stlinkv3.kicad\_sch

[illegible][illegible]

### STM32F303CCT6 MCU

STM32F303CCTx

### LCD

File: LCD.kicad\_sch

### HEADER PINS

P1 Conn\_02x05\_Odd\_Even

| Pin | Signal |
|-----|--------|
| 1   | 3V3    |
| 2   | PA1    |
| 3   | PA3    |
| 4   | PA5    |
| 5   | PA7    |
| 6   | PC13   |
| 7   | LED_1  |
| 8   | LED_2  |
| 9   | LED_3  |
| 10  | PA4    |
| 11  | PA6    |

P2 Conn\_02x05\_Odd\_Even




| Pin | Signal |
|-----|--------|
| 1   | PB0    |
| 2   | PB10   |
| 3   | PB12   |
| 4   | PB14   |
| 5   | PB1    |
| 6   | PB11   |
| 7   | PB13   |
| 8   | PB15   |
| 9   | PB2    |
| 10  | PB12   |

### MICRO USB

U4 CDSOT236-0504C

### MPU6050

U1 MPU6050



### STM32F303CCT6 MCU

STM32F303CCTx

### LCD

File: LCD.kicad\_sch

### HEADER PINS

P1 Conn\_02x05\_Odd\_Even

| Pin | Signal |
|-----|--------|
| 1   | 3V3    |
| 2   | PA1    |
| 3   | PA3    |
| 4   | PA5    |
| 5   | PA7    |
| 6   | PC13   |
| 7   | LED_1  |
| 8   | LED_2  |
| 9   | LED_3  |
| 10  | PA4    |
| 11  | PA6    |

P2 Conn\_02x05\_Odd\_Even




| Pin | Signal |
|-----|--------|
| 1   | PB0    |
| 2   | PB10   |
| 3   | PB12   |
| 4   | PB14   |
| 5   | PB1    |
| 6   | PB11   |
| 7   | PB13   |
| 8   | PB15   |
| 9   | PB2    |
| 10  | PB12   |

### MICRO USB

USB\_B\_Micro

### MPU6050

MPU6050

[illegible][illegible]

### STM32F303CCT6 MCU

STM32F303CCTx

### HEADER PINS

Conn\_02x05\_Odd\_Even

### MPU6050

C18 100nF

### LCD

File: LCD.kicad\_sch

### MICRO USB


USB\_B\_Micro

1N5819WS

1.5K

U4

CDSOT236-0504C



### STM32F303CCT6 MCU

STM32F303CCTx

### HEADER PINS

Conn\_02x05\_Odd\_Even

### MPU6050

C18 100nF

### LCD

File: LCD.kicad\_sch

### MICRO USB


USB\_B\_Micro

1N5819WS

1.5K

U4

CDSOT236-0504C



### STM32F303CCT6 MCU

STM32F303CCTx

### HEADER PINS

Conn\_02x05\_Odd\_Even

### MPU6050

C18 100nF

### LCD

File: LCD.kicad\_sch

### MICRO USB



USB\_B\_Micro

1N5819WS




1.5K

U4

CDSOT236-0504C




## HEADERPINS




## TOUCH PANEL (CST816S)

## LCD (GC9A01)



## u-SD CARD



Sheet: /LCD/  
File: LCD.kicad\_sch

Title:

Size: A4

Date:

KiCad E.D.A. 9.0.7

Rev:

Id: 2/3

