# **PMDG B777 Checklist**

### **Cockpit Prep - From Cold and Dark + GPU**

Battery	ON
Primary + Secondary EXT PWR	ON
IFE/Cabin Utility	BOTH ON
ADIRU	ON

APU ON/START

SET LOCAL BARO LOCAL

Set Auto Brake RTO

Set Initial Altitude and RWY Heading

<u>Tablet - EFB - Request Data From Simbrief</u>
<u>Ground Operations - Req Jetway - Open Doors as req</u>
<u>Or use GSX if you have it</u>
Ground Maintenence - Check for any repairs needed

EMER Lights	ARMED + GUARDED
Window Heat	ON x4
Hydraulic C1 - C2	BOTH ON
L ELEC - C1 - C2 - R ELEC	ALL AUTO
Seat Belts	AUTO

#### MCDU Set Up

**FMC - Set Inertial Pos** 

<u>Route - Route Request - Simbrief RTE -</u> Set Payload - Set Fuel - Select RTE - Load -

<u>Activate - Exec</u> <u>Perf Init - Accept - Check CRZ ALT -</u> Click ZFW Twice to populate

Legs - RTE Data - Load - EXEC

DEP/ARR - Set Runway and SID - EXEC

DEP/ARR - Destination ARR 
Set Runway, STAR and Transition - EXEC

Legs - Check for any Discon's

VNAV - Page 3 - Forecast - Load

#### **Tablet - Performance Tool - Calculate Departure**

#### MCDU Set Up Cont.....

Follow order or V Speeds will be deleted

RTE - Take Off - Set Flaps CG - Click twice to populate

Thrust Limit - Set SEL TEMP & T/O DerateTake Off - Click V1, VR, V2 to populate
Set Stab Trim

Set V2 Speed o	n Control Panel
FD x2 - LNAV - VNAV	ON
<u>Set Squak</u>	(If on ATC)
Fuel Pumps (4 or 6 as req)	ON
EXT PWR	(Check APU isrunning) OFF

<u>Tablet - Close and Arm Doors - Release Jetway -</u> Remove Chocks

Connect the Tug ready for Pushback

Beacon ON

Press CANC/RCL twice to clear any warnings -Engine Shutdown' should be the only warning Complete Preflight & Before Start Checklists

### **Pushback & Engine Start**

Release Parking Brake to start pushback

L or R engines can be started first

Set desired Engine Start Dail to START

N2 @20% Fuel Switch
Engine Start Dail auto clicks back to NORM

Engine Start (second engine)
Start

N2 @20% Fuel Switch
ON
Engine Start Dail auto clicks back to NORM

**Set Parking Brake When needed** 

**Check Flight Controls** 

## **Before Taxi / Taxi / Hold Short**

Seat Belts		ON
	Set T/O Flaps	
Taxi Lights		ON
APU		OFF
	Complete Before Taxi Checklist	
	Release Parking Brake to Start Taxi	

Traffic Mode (TFC)	ON
Transponder	TA/RA
Weather Radar	ON
Strobes	ON
Runway Turnoff Lights	ON
Landing Lights	ON
Wing & Logo lights If I	Neccassary
Complete Before Take Off Checklist	

### **Take Off / After Take Off**

### Line Up / Take Off

Release Parking Brake & Hold on Toe Brake

Set thrust to 40% N1

Release Toe Brake

Push TO GA

At VR Pull back to Positive Climb

Raise Landing Gear

At Above 400ft Select AP at Pilots Discression

Climb		
Retract flaps as directed on the Speed Tape		
Taxi Lights	OFF	
RNWY Turn Off Lights	OFF	
At Transition Alt	Set BARO STD	
At 10,000ft		
Landing Lights	OFF	
Seat Belts	AUTO	
At Cruize		
Adjust Heading to Align with Nose Direction		

## **Decent Planning**

Tablet - Performance Tool - Calc Landing

Set Autobrake

MCDU - Init Ref - Select Landing Flaps and Insert

NAV RAD - Check ILS and Heading are Correct

Set Minimums BARO/RADIO

Pre Select Local BARO
Pre Set ALT (If not on ATC)
Complete Decent Checklist

If final Alt set complete Approach Checklist Otherwise complete once set

## **Approach**

Passing 10,000ft		
Seatbelt Light	ON	
Landing Lights	ON	
Press CANC/RCL to check for errors		
At Transition Level Set BARO to LOCAL		
Start to reduce speed manually if required		
Go to Flaps 1 then 5 as needed and when speed allo	ows	

Landing Procedure	
On Final Turn (or on intercept) LOC	ON
When LOC Actiive - Approach Mode	ON
Auto Pilot	CHECK ON

When G/S Alive		
Landing Gear	DOWN	
Flaps	Set 15	
Speedbrake	ARM	
Set Speed to Manual	SPD INTV	
Set Speed to REF (15 Bug)		
Flaps To La	nding Setting	
Set Speed to VREF (Landing Flaps E	Bug)	
Check Landing Checklist is all Gre	en	
Final Appraoch		
AP + Auto Throttle	OFF	

May all your landings be Buttery Smooth:)

# **After Landing**

After Landin	ıg
<u>Flaps</u>	Retract
<u>Speedbrake</u>	Retract
Weather Radar	OFF
Autobrake	OFF

After Vacating Rui	nway
Exterior Lights	AS NEEDED
APU	START

At Gate	
Parking Brake	ON
Fuel Pump Switches	OFF
Seatbelt Signs	OFF
Tablet - Ground Operations -	
Req Jetway - Open Doors as req	
Or use GSX if you have it	

Continue shutting down plane if required ie. Turn everything off :p