INTRO. TO COMP. ENG. CHAPTER XV-1 PROCEDURE CALLS •CHAPTER XV

# **CHAPTER XV**

# PROCEDURE CALLS AND SUBROUTINES

### INTRO. TO COMP. ENG. CHAPTER XV-2 PROCEDURE CALLS

# **PROCEDURE CALLS**

#### INTRODUCTION

•PROCEDURE CALLS
-INTRODUCTION

- Branches and jumps are important program control constructs, but another important extension of program control are procedure calls, often referred to as subroutines.
- Three basic steps form of a subroutine call
  - Program control is changed
    - from the current routine
    - to the beginning of the subroutine code.
  - Subroutine code is executed.
  - Program control is changed
    - from end of subroutine
    - to the calling routing immediately\* after subroutine call instruction.


### INTRO. TO COMP. ENG. CHAPTER XV-3 PROCEDURE CALLS

# **PROCEDURE CALLS**

PROGRAM FLOW

•PROCEDURE CALLS
-INTRODUCTION

We can illustrate how subroutine calls change program flow as follows.



### INTRO. TO COMP. ENG. CHAPTER XV-4 PROCEDURE CALLS

# **MACHINE STATE**

#### SAVING MACHINE STATE

•PROCEDURE CALLS
-INTRODUCTION
-PROGRAM FLOW

- How can program flow be changed to a subroutine?
  - PC = address of 1st instruction of subroutine
- And then returned from a subroutine call?
  - PC = address of instruction after subroutine call instruction
- The idea is to save the state of the machine.
- In the most basic microprocessor, saving the state means to save the PC in a known location!

- Some microprocessors also save other registers during a procedure call.
- MIPS only saves the PC and then restores the PC after the subroutine.

### INTRO. TO COMP. ENG. CHAPTER XV-5 PROCEDURE CALLS

# MACHINE STATE

#### SAVING STATE TO \$RA

- •PROCEDURE CALLS
  •MACHINE STATE
  -SAVING MACHINE STATE
  -MIPS REGISTER NAMES
- For MIPS, the primary location for saving the PC is in \$31/\$ra.
- MIPS uses the instruction jal <imm> (jump and link)
  - jal is J-format type instruction.
  - Stores the return address in \$ra, i.e. \$ra = PC + 4\*.
  - Performs jump such as with the j instruction.
- At the end of the subroutine, the instruction jr \$ra is executed to return to calling routing.
  - This causes the contents of \$ra to be put into PC
    - i.e. PC = \$ra which after the original jal instruction is PC = PC + 4\*.

## INTRO. TO COMP. ENG. CHAPTER XV-6 PROCEDURE CALLS

## **MACHINE STATE**

#### EXAMPLE PROCEDURE CALL

•MACHINE STATE

square root subroutine

- -SAVING MACHINE STATE
- -MIPS REGISTER NAMES
- -SAVING STATE TO \$RA
- Below is an example piece of pseudo-code that has been translated in assembly with a main routine and a square root subroutine.

main routine

Pseudo-Code

MIPS Assembly

(use \$s0 for a, \$s1 for b) (argument in \$a0, result in \$v0)
$$b = 6;$$

$$a = sqrt(b);$$

$$a = a + b;$$
(use \$s0 for a, \$s1 for b) (argument in \$a0, result in \$v0)
$$move $a0, $s1$$

$$move $s0, $s0$$

$$add $s0, $s0, $s1$$

$$add $s0, $s0, $s1$$

R.M. Dansereau; v.1.0

## INTRO. TO COMP. ENG. CHAPTER XV-7 PROCEDURE CALLS

## **MACHINE STATE**

#### SAVING STATE TO REGISTER

- •MACHINE STATE
  - -MIPS REGISTER NAMES
  - -SAVING STATE TO \$RA
  - -EXAMPLE PROC. CALL
- Another approach to saving the PC is the in the form jalr \$<dest>, \$<src>
  (jump and link register) instruction.
  - jalr is roughly an R-format type instruction.
  - Stores the return address in \$<dest>, i.e. \$5 = PC + 4\*.
  - Performs jump such as with the jr <\$src> instruction.
- At the end of the subroutine, to return from the subroutine the following can be executed.
  - jr \$<dest> (i.e. jr \$5)
- Another option for returning from a subroutine is to execute
  - jalr \$0, \$5,
  - or even jalr \$<new dest>, \$5.

## INTRO. TO COMP. ENG. **CHAPTER XV-8** PROCEDURE CALLS

## **MACHINE STATE**

#### EXAMPLE PROCEDURE CALL

- •MACHINE STATE
  - -SAVING STATE TO \$RA
  - -EXAMPLE PROC. CALL
  - -SAVING STATE TO REGIS.
- Another example where jalr is used and the subroutine is completely given. Pseudo-Code MIPS Assembly

$$b = 6;$$

$$a = decr(b);$$

$$a = a + b$$
;

main routine decrement subroutine (use \$s0 for a, \$s1 for b) (argument in \$a0, result in \$v0)

decr: subi \$v0,\$a0,1 jr \$s7 move \$s0, \$v0 add \$s0, \$s0, \$s1

## INTRO. TO COMP. ENG. CHAPTER XV-9 PROCEDURE CALLS

## **MACHINE STATE**

#### EXAMPLE PROCEDURE CALL

- •MACHINE STATE
  - -EXAMPLE PROC. CALL
  - -SAVING STATE TO REGIS.
  - -EXAMPLE PROC. CALL

A more complicated example could be as follows.

Pseudo-Code

MIPS Assembly

a = 6; b = 4; c = 10; d = func(b,c,a);

int func(x,y,z)
 return x+y-z;

Main routine (use \$s0-3\$ for a,b,c,d) lwi \$s0, 0x06 lwi \$s1, 0x04 lwi \$s2, 0x0A move \$a0, \$s1 move \$a1, \$s2 move \$a2, \$s0 jal func move \$s3, \$v0

func subroutine (arguments in \$a0-2, result in \$v0)

func: sub \$v0,\$a1,\$a2 add \$v0,\$a0,\$v0 jr \$ra

### INTRO. TO COMP. ENG. CHAPTER XV-10 PROCEDURE CALLS

## **MACHINE STATE**

#### **PROBLEMS**

•MACHINE STATE


- -EXAMPLE PROC. CALL
- -SAVING STATE TO REGIS.
- -EXAMPLE PROC. CALL
- Two problems exist with the subroutine approach discussed so far.
- Problem 1:
  - What if we want to call a subroutine within a subroutine?
    - Only one \$ra, so only one return address is stored with jal.
    - If we call a nested subroutine, the return address in \$ra is lost.
- Problem 2:
  - What if we need many temporary registers within the subroutine?
    - We don't want to lose the contents of registers that the calling function might still need!
- Solution: Stacks

## INTRO. TO COMP. ENG. CHAPTER XV-11 PROCEDURE CALLS

# **STACKS**PUSHING AND POPPING

•MACHINE STATE

- -SAVING STATE TO REGIS.
- -EXAMPLE PROC. CALL
- -PROBLEMS
- A stack is a **LIFO** (Last-In, First-Out) data structure.
  - Consider the example of a stack of plates at a cafeteria.



- A plate can be added to the top of the stack, called a push.
- A plate can be removed from the top of the stack, called a **pop**.

## INTRO. TO COMP. ENG. CHAPTER XV-12 PROCEDURE CALLS

# STACKS STACK OPERATION

•MACHINE STATE•STACKS-PUSHING AND POPPING

- Which way should a stack grow in memory?
  - It is customary for a stack to grow from larger memory addresses
     to smaller memory addresses.
- Use a stack pointer (SP) to point to top of stack. This is \$29/\$sp on MIPS.
- push: To place a new item onto the stack
  - first decrement SP,
  - then store item at the new location pointed to by SP.
- **pop**: To retrieve an item from the stack
  - first copy item pointed to by SP into desired destination,
  - then increment SP.
- Many processors deviate slightly from this, but with the same idea.

INTRO. TO COMP. ENG. CHAPTER XV-13 PROCEDURE CALLS

# STACKS MEMORY MODEL

•MACHINE STATE
•STACKS
-PUSHING AND POPPING
-STACKS IN MEMORY

0x76543210

0x45553323

Following the previous slide, we can think of our memory model as follows
 if SP = 0x00FFFFF4 and the bottom of the stack is 0x01000000.

push: 
$$SP = SP - 4$$

pop:  $SP = SP + 4$ 
 $0x00FFFE8$ 
 $0x00FFFE0$ 
 $0x00FFFE0$ 
 $0x00FFFF0$ 
 $0x00FFFF0$ 
 $0x00FFFF0$ 
 $0x00FFFF0$ 
 $0x00FFFF8$ 
 $0x00FFFF8$ 
 $0x0111120$ 
 $0x00FFFE8$ 

0x00FFFE0

0x00FFFFC

0x01000000

We can see that the stack grows from larger address to smaller address.

## INTRO. TO COMP. ENG. CHAPTER XV-14 PROCEDURE CALLS

# **STACKS**PUSH AND POP ON MIPS

•STACKS

- -PUSHING AND POPPING
- -STACKS IN MEMORY
- -MEMORY MODEL
- The following instructions perform a **push** of **R15** onto the stack.

The following instructions perform a pop from the stack into R15.

Many processors actually have the instructions push and pop, but MIPS removes these to have fewer opcodes (i.e. RISC).

INTRO. TO COMP. ENG. CHAPTER XV-15 PROCEDURE CALLS

# **STACKS**

**PUSH ON MIPS** 

•STACKS

- -STACKS IN MEMORY
- -MEMORY MODEL
- -PUSH AND POP ON MIPS
- A push on MIPS is performed and illustrated as follows.

Given that R15=0x77777777

Push of R15 onto stack

sub \$sp, 0x04 sw \$15, \$sp

# 0x00FFFFF0

0x00FFFF0 0x00FFFF4 SP → 0x00FFFF8 0x01234567 0x00FFFFC 0x76543210 0x01000000 0x45553323

## After push: R15=0x77777777

 SP
 Ox00FFFFF0

 0x00FFFFF4
 0x77777777

 0x00FFFFF8
 0x01234567

 0x00FFFFC
 0x76543210

 0x01000000
 0x45553323

INTRO. TO COMP. ENG. CHAPTER XV-16 PROCEDURE CALLS

# **STACKS**

POP ON MIPS


•STACKS

- -MEMORY MODEL
- -PUSH AND POP ON MIPS
- -PUSH ON MIPS
- A pop on MIPS is performed and illustrated as follows.

Pop from stack to R15

lw \$15, \$sp add \$sp, 0x04

Now R15=0x01234567



After pop: R15=0x01234567

	0x00FFFFF0	
	0x00FFFFF4	
	0x00FFFF8	0x01234567
SP →	0x00FFFFC	0x76543210
	0x01000000	0x45553323


### INTRO. TO COMP. ENG. CHAPTER XV-17 PROCEDURE CALLS

# **STACKS**

#### **NESTED PROCEDURE CALLS**

•STACKS

- -PUSH AND POP ON MIPS
- -PUSH ON MIPS
- -POP ON MIPS
- Procedure calls can now be nested since \$ra can be saved on the stack.



INTRO. TO COMP. ENG. CHAPTER XV-18 PROCEDURE CALLS

## **STACKS**

#### **NESTED PROCEDURE CALLS**

STACKS

- -PUSH ON MIPS
- -POP ON MIPS
- -NESTED PROC. CALLS

This example can be thought of in a higher level language as

```
complex Z addcomplex(complex X, complex Y) {
    Z.real = X.real + Y.real;
    Z.imaginary = X.imaginary + Y.imaginary;
    return Z;
complex W funcAadd2B(complex U, complex V) {
    W = addcomplex(U, V);
    W = addcomplex(W, V);
    return W;
main {
    complex A = 5 + i6, B = 2 + i7, C;
    C = funcAadd2B(A, B);
```

## INTRO. TO COMP. ENG. CHAPTER XV-19 PROCEDURE CALLS

# **STACKS**

#### EXAMPLE NESTED CALL

STACKS

- -POP ON MIPS
- -NESTED PROC. CALLS
- -EXAMPLE NESTED CALL
- Say that we want to write a function funcAadd2B that calculates A+2B where A and B are complex numbers.
  - (\$a0,\$a1) contains (real,imaginary) part of A.
  - (\$a2,\$a3) contains (real,imaginary) part of B.
  - (\$v0,\$v1) contains (real,imaginary) part of answer.
- To make life easier, also design function addcomplex that adds two complex numbers X and Y.
  - (\$a0,\$a1) contains (real,imaginary) part of X.
  - (\$a2,\$a3) contains (real,imaginary) part of Y.
  - (\$v0,\$v1) contains (real,imaginary) part of answer.

INTRO. TO COMP. ENG. CHAPTER XV-20 PROCEDURE CALLS

# **STACKS**

EXAMPLE NESTED CALL

- •STACKS
  - -POP ON MIPS
  - -NESTED PROC. CALLS
  - -EXAMPLE NESTED CALL
- This example could be implemented as follows in assembly.

Main routine funcAadd2B addcomplex sub \$sp, 0x04 add \$v0,\$a0,\$a2 add \$v1,\$a1,\$a3 sw \$ra, \$sp jal addcomplex ir \$ra move \$a0,\$v0 jal funcAadd2B move \$a1,\$v1 jal addcomplex lw \$ra, \$sp add \$sp, 0x04 jr \$ra