

SyncESMCDocker User Guide

Introduction

Ethernet Synchronous Message Channel (ESMC) is a logical communication channel which transmits Synchronous Status Message (SSM) information which is the quality level of the transmitting synchronous Ethernet Equipment Clock (EEC). ESMC support is based on the G.8264 specification. SyncESMC is the implementation of Synchronous Ethernet (Sync-E), according to ITU-T G.8264 (03/2018) and ITU-T G.781 (04/2020) standards.

Docker Image

docker pull syncmonk/syncesmc:v1.0-beta

Commands to run Docker Image

Launch the docker container

docker run --network host -v <local config file path>:/usr/bin/config.yml itd syncmonk/syncesmc:v1.0-beta syncESMC -f config.yml

Get the shell for CLI

docker exec -it <container name> /bin/bash



Docker snapshots



```
syncESMC> show running-config device
 device
                        dev0
 device id
 enable
                        ENABLE
 source select mode
                        PRIO
 network_option
                        OPTION 1
                        DISABLE
 enhanced_esmc
 holdover_ql
                        QL_SSU_A
 holdover_time
                        10
 ql mode
                        ENABLE
 forced ql en
                        DISABLE
 forced_ql
                        QL_DNU
 ql_exact_match
                       ENABLE
 num_accepted_ql
                        3
                        ['QL_SEC', 'QL_PRC', 'QL_SSU_A']
 accepted_ql
 rx_heartbeat_ms
                        1100
 tx heartbeat ms
                        1000
 clock select mode
                        1
 clock_local_ql
                        QL_SSU_B
 squelch
                        DISABLE
 wait_to_start
                        10
 hardware_monitor_ms
                        2000
 num_pg
                        0
 max_in_ports_pg
                        0
 max_out_pg
                        0
```



yncESMC> show clock	state
Attribute	Status
clock_state gnss_clock synchronized_port clock_source clock_ql	SYNCHRONIZED ENABLE gnss0 SOURCE_GNSS QL_PRC



syncESMC> show port state		
Attribute	Status	
port_name link_state source_state recovery_reasons holdover_reason accepted_ssm_code rx_pkt tx_pkt last_rx_ssm last_tx_ssm rx_timestamp hardware_events	eth0 LINK UP READY NO_RECOVERY NO_HOLDOVER None 0 44 None QL_PRC 0.0 None	
+ + Attribute	 Status	
port_name link_state source_state recovery_reasons holdover_reason accepted_ssm_code rx_pkt tx_pkt last_rx_ssm last_tx_ssm rx_timestamp hardware_events	gnss0 LINK UP LOCKED NO_RECOVERY NO_HOLDOVER QL_PRC 0 QL_PRC NOne 0.0	



```
| SyncESMC | Show log-messages all | [syncESMC||9506.533]: [INFO] | logging_level: 6 | [syncESMC||9506.533]: [INFO] | logging_level: 6 | [syncESMC||9506.534]: [INFO] | use_syslog: 1 | [syncESMC||9506.534]: [INFO] | use_syslog: 1 | [syncESMC||9506.534]: [INFO] | use_stdout: 1 | [syncESMC||9506.534]: [INFO] | bystem configuration] | [syncESMC||9506.534]: [INFO] | ptp_uds_address: /var/run/syncEsmcPTP | [syncESMC||9506.534]: [INFO] | ptp_uds_address: /var/run/syncEsmcPTP | [syncESMC||9506.534]: [INFO] | device: 0 | [syncESMC||9506.534]: [INFO] | device: 0 | [syncESMC||9506.535]: [INFO] | device: 0 | [syncESMC||9506.529]: [INFO] | device: 0 | [syncESMC||9506.629]: [
```



Configuration files

a. SyncESMC Slave - Dual RXTX Ports

```
logging:
    logging_level: 6
    use_syslog: 1
    message_tag: syncESMC
    use_stdout: 1
system:
    ptp_uds_address: /var/run/syncEsmcPTP
    interval: 10
device:
    0:
        device_enable: 1
        source_sel_mode: AUTO
        network_option: OPTION_1
        enhanced_esmc: 0
        holdover ql: QL SSU A
        holdover_time: 10
        ql_mode: 1
        forced_ql_en: 0
        forced ql: QL DNU
        ql exact match: 1
        accepted_ql:
        - QL PRC
        tx_heartbeat_ms: 1000
        rx_heartbeat_ms: 1100
        clock_sel_mode: PLL
        clock_local_ql: QL_SSU_B
        squelch: 0
        wait_to_start: 10
        hardware monitor ms: 2000
port:
        enp0s8:
            port_enable: 1
            priority: 1
            input_mode: LINE
            holdoff time ms: 5000
            wait to restore time: 10
            pll_id: 1
            pll_input: 1
            clock_id: 0
            transmit_mode: RXTX
        enp0s9:
            port_enable: 1
            priority: 2
            input mode: LINE
            holdoff_time_ms: 5000
            wait_to_restore_time: 10
            pll id: 1
            pll_input: 1
            clock id: 0
            transmit mode: RXTX
```



b. SyncESMC Master- TX Port + External GNSS Source)

```
logging:
    logging_level: 6
    use syslog: 1
    message_tag: syncESMC
    use_stdout: 1
    ptp uds address: /var/run/syncEsmcPTP
    interval: 10
device:
    0:
        device enable: 1
        source_sel_mode: AUTO
        network_option: OPTION_1
        enhanced esmc: 0
        \verb|holdover_ql: QL_SSU_A|
        holdover time: 10
        ql mode: 1
        forced_ql_en: 0
        forced_ql: QL_DNU
        ql exact match: 1
        accepted_ql:
        - QL PRC
        tx_heartbeat_ms: 1000
        rx_heartbeat_ms: 1100
        clock_sel_mode: PLL
        clock_local_ql: QL_PRC
        squelch: 0
        wait_to_start: 10
        hardware_monitor_ms: 2000
port:
    0:
        enp0s8:
            port enable: 1
            priority: 1
            input mode: LINE
            holdoff time ms: 5000
            wait to restore time: 10
            pll id: 1
            pll_input: 1
            clock_id: 0
            transmit_mode: TX
        gnss0:
            port_enable: 1
            priority: 2
            input_mode: EXTERNAL
            holdoff_time_ms: 300
            wait_to_restore_time: 10
pll_id: 1
            pll input: 1
            clock id: 0
            input_ql: QL_PRC
```



c. SyncESMC RX TX port

```
logging:
    logging_level: 6
    use syslog: 1
    message_tag: syncESMC
    use_stdout: 1
    ptp_uds_address: /var/run/syncEsmcPTP
    interval: 10
device:
    0:
        device enable: 1
        source_sel_mode: AUTO
        network_option: OPTION_1
        enhanced_esmc: 0
        holdover_ql: QL_SSU_A
        holdover time: 10
        ql mode: 1
        forced_ql_en: 0
        forced_ql: QL_DNU
        ql exact match: 1
        accepted_ql:
        - QL PRC
        tx_heartbeat_ms: 1000
        rx_heartbeat_ms: 1100
        clock_sel_mode: PLL
        clock_local_ql: QL_PRC
        squelch: 0
        wait_to_start: 10
        hardware_monitor_ms: 2000
port:
    0:
        enp0s8:
            port enable: 1
            priority: 1
            input mode: LINE
            holdoff time ms: 5000
            wait_to_restore_time: 10
            pll id: 1
            pll_input: 1
            clock_id: 0
            transmit_mode: RXTX
```



Copyright © 2022 SyncMonk Technologies, All Rights Reserved.

Information in this document is provided in connection with SyncMonk Technologies, ("SyncMonk") products or services. These materials, including the information contained herein, are provided by SyncMonk as a service to its customers and may be used for informational purposes only by the customer. SyncMonk assumes no responsibility for errors or omissions in these materials or the information contained herein. SyncMonk may change its documentation, products, services, specifications or product descriptions at any time, without notice. SyncMonk does not commit to updating the materials or information and shall have no responsibility whatsoever for conflicts, incompatibilities, or other difficulties arising from any future changes.

No license, whether express, implied, by estoppel or otherwise, is granted to any intellectual property rights by this document. SyncMonk assumes no liability for any materials, products or information provided hereunder, including the sale, distribution, reproduction or use of SyncMonk products, information or materials, except as may be provided in SyncMonk's Terms and Conditions of Sale.

THE MATERIALS, PRODUCTS AND INFORMATION ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE, INCLUDING FITNESS FOR A PARTICULAR PURPOSE OR USE, MERCHANTABILITY, PERFORMANCE, QUALITY OR NON-INFRINGEMENT OF ANY INTELLECTUAL PROPERTY RIGHT; ALL SUCH WARRANTIES ARE HEREBY EXPRESSLY DISCLAIMED. SyncMonk DOES NOT WARRANT THE ACCURACY OR COMPLETENESS OF THE INFORMATION, TEXT, GRAPHICS OR OTHER ITEMS CONTAINED WITHIN THESE MATERIALS. SyncMonk SHALL NOT BE LIABLE FOR ANY DAMAGES, INCLUDING BUT NOT LIMITED TO ANY SPECIAL, INDIRECT, INCIDENTAL, STATUTORY, OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION, LOST REVENUES OR LOST PROFITS THAT MAY RESULT FROM THE USE OF THE MATERIALS OR INFORMATION, WHETHER OR NOT THE RECIPIENT OF MATERIALS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

SyncMonk products are not intended for use in medical, lifesaving or life-sustaining applications, or other equipment in which the failure of the SyncMonk products could lead to personal injury, death, or physical or environmental damage. SyncMonk customers using or selling SyncMonk products for use in such applications do so at their own risk and agree to fully indemnify SyncMonk for any damages resulting from such improper use or sale.

Customers are responsible for their products and applications using SyncMonk products, which may deviate from published specifications as a result of design defects, errors, or the operation of products outside of published parameters or design specifications. Customers should include design and operating safeguards to minimize these and other risks. SyncMonk assumes no liability for applications assistance, customer product design, or damage to any equipment resulting from the use of SyncMonk products outside of SyncMonk's published specifications or parameters.