SAFE STOPPING POINT

Next Offline Steps

- 1. Blot, seal, and centrifuge the chip.
- 2. Continue with dispensing **Index-1**.