
Texecom Premier 832 + LCD Keypad

8–32 zone alarm control panel with built-in communicator

STOCK CODE

41PR832-LCD

A proven, expandable wired alarm panel — starts at 8 zones and grows to 32 for bigger homes and small businesses.



No product photo in the datasheet yet

8→32	4	64	1000
zones (expandable)	partitions	user codes	event log

WHY CUSTOMERS CHOOSE IT

- **8 zones on board**, expands to **32** with zone expanders
- **Built-in communicator** — Contact ID, SIA and more to the control room
- **LCD keypad** — 32-character display with full text
- 2 × 1 A supervised outputs + 6 × 100 mA outputs
- PC upload/download via Wintex UDL software

BEST FOR

- ✔ Larger homes needing more than 16 zones
- ✔ Small offices, shops & warehouses
- ✔ Sites needing separate areas (up to 4 partitions)
- ✔ Systems reporting to an armed-response control room
- ✔ Upgrading to a wired, expandable system

NOT FOR

- ✖ Customers wanting a fully wireless DIY kit
- ✖ Outdoor or damp locations (dry indoor use only)
- ✖ Very small sites — a Premier 412/816 is cheaper

KEY SPECS

Mains power	**16.5 VAC transformer (25/40 VA)**
Standby battery	**Up to 7 Ah, 24 h recharge**
Current draw	**< 50 mA quiet · < 150 mA alarm**
Zone EOL resistor	**3K3**
Panel size	**282 × 225 × 80 mm**
Operating temp	**−10 to +55 °C, indoor**

FAMILY — PICK THE RIGHT ONE

Premier 412	4 zones → 12, 2 partitions, 32 users
Premier 816	8 zones → 16, 4 partitions, 32 users
Premier 832	8 zones → 32, 4 partitions, 64 users — **this panel**

COUNTER QUICK ANSWERS

Battery? Takes up to a 12 V 7 Ah — e.g. Forbatt FB7.2-12 (06AS12-7).

Can it grow? Yes — add Premier 8X (remote) or 8XE (local) zone expanders up to 32 zones.

Grade? Suitable for EN 50131 Grade 2 systems when programmed correctly.