
DSC Neo HSM2108 8-Zone Expander

Adds 8 hardwired zones to any PowerSeries Neo panel

STOCK CODE

22HSM2108

Need more wired zones? Add 8 at a time to any PowerSeries Neo panel.



No clear product photo in the datasheet

+8	15	40 mA	12 V
wired zones	modules / system	current draw	DC

WHY CUSTOMERS CHOOSE IT

- **8 programmable zones** — no EOL, single or double EOL (5.6 k)
- Fully supervised and encrypted on the Corbus
- Home-run, daisy-chain or tee-tap wiring
- Tamper input

KEY SPECS

Board size	**45 × 92 mm**
Current	**40 mA max**
Voltage	**12 VDC nominal**
Operating temp	**−10 to +55 °C · 5–93% RH**

BEST FOR

- ✔ Neo systems that ran out of on-board zones
- ✔ Larger homes, offices and shops
- ✔ Wiring a remote building or floor (Corbus)

NOT FOR

- ✖ Non-Neo panels
- ✖ Adding wireless zones — use an HSM2HOST

FAMILY — PICK THE RIGHT ONE

HSM2108	**8-zone expander — this unit**
HSM2204	**High-current output module (+1 A)**
HSM2208	**8 low-current outputs**
HSM2300	**1 A supervised power supply**

COUNTER QUICK ANSWERS

How many can I add? Up to 15 per system (within the panel's zone limit).

Needs its own box? Fits in the panel cabinet or a separate enclosure.

Wireless zones? No — use an HSM2HOST transceiver.

Source: DSC PowerSeries Neo Output & Hardwire Zone Expansion Modules datasheet.

Internal counter reference