```
icc2 shell> man set floorplan forbidden rules
     2. Synopsys Commands
                                                                  Command Reference
 3
                              set floorplan forbidden rules
 4
 5
    NAME
            set floorplan forbidden rules
 6
 7
                   Defines a forbidden floorplan rule in the design.
8
9
    SYNTAX
10
            set floorplan forbidden rules
11
                   -lib cells lib cells
12
                   -name rule name
13
14
        Data Types
15
           lib cells
                            collection
16
           rule name
                             string
17
18
    ARGUMENTS
19
           -lib cells lib cells
20
                   Specifies the collection of library cells for the forbidden
21
                   floorplan rule. Specified lib cells are not allowed to be placed
22
                   in the design. This is a mandatory option.
23
24
            -name rule name
25
                   Specifies the name of the forbidden floorplan rule. This is a
26
                   mandatory option.
27
   DESCRIPTION
28
29
           The set floorplan forbidden rules command defines a named forbidden
30
            floorplan rule in the current design. The defined rule is persistent.
31
            If another floorplan rule by the same name exists then the command
32
           errors out.
33
34
            The set floorplan forbidden rules command is used to specify list of
35
            lib cells that are not allowed to be placed in the design.
36
37
   EXAMPLES
38
            The following example creates a forbidden rule named f1 to check that
39
           specified lib cells are not placed in the design.
40
41
              prompt> set_floorplan_forbidden rules -name f1 \
42
                 -lib cells {*/an2* */aoi*}
43
44 SEE ALSO
45
            set floorplan area rules (2)
46
            set floorplan enclosure rules (2)
47
            set floorplan extension rules (2)
48
            set floorplan exception rules (2)
49
            set_floorplan_halo_rules(2)
50
           set_floorplan_length_rules(2)
51
           set floorplan spacing rules (2)
52
           set floorplan width rules (2)
53
           remove floorplan rules (2)
54
           report floorplan rules (2)
55
56
                               Version S-2021.06-SP5
                 Copyright (c) 2022 Synopsys, Inc. All rights reserved.
57
58
     icc2 shell>
59
```