

Microcontroller Application and Development Sorayut Glomglome

# C programming for embedded microcontroller systems.

Assumes experience with assembly language programming.

V. P. Nelson


#### Outline

- Program organization and microcontroller memory
- Data types, constants, variables
- Microcontroller register/port addresses
- Operators: arithmetic, logical, shift
- Control structures: if, while, for
- Functions
- Interrupt routines

## Basic C program structure

```
/* I/O port/register names/addresses for the STM32F767xx microcontrollers
#include "stm32f767xx.h"
/* Global variables – accessible by all functions */
int count, bob;
                         //global (static) variables – placed in RAM
/* Function definitions*/
int function1(char x) {
                         //parameter x passed to the function, function returns an integer value
                         //local (automatic) variables – allocated to stack or registers
 int i,j;
 -- instructions to implement the function
/* Main program */
void main(void) {
 unsigned char sw1;
                         //local (automatic) variable (stack or registers)
                                                                                 Declare local variables
                         //local (automatic) variable (stack or registers)
 int k;
/* Initialization section */
 -- instructions to initialize variables, I/O ports, devices, function registers
                                                                                 Initialize variables/devices
/* Infinite loop */
                    //Can also use: for(;;) {
 while (1) {
 -- instructions to be repeated
                                                                                 Body of the program
 } /* repeat forever */
```

## STM32L100RC µC memory map



### Microcontroller "header file"

 Keil MDK-ARM provides a derivative-specific "header file" for each microcontroller, which defines memory addresses and symbolic labels for CPU and peripheral function register addresses.

```
#include "stm32f767xx.h" /* target uC information */

// GPIOA configuration/data register addresses are defined in stm32f767xx.h

void main(void) {
    uint16_t PAval; //16-bit unsigned variable

GPIOA->MODER &= ~(0x00000003); // Set GPIOA pin PAO as input
    PAval = GPIOA->IDR; // Set PAval to 16-bits from GPIOA

for(;;) {} /* execute forever */
}
```

## C compiler data types

- Always match data type to data characteristics!
- Variable type indicates how data is represented
  - #bits determines range of numeric values
  - signed/unsigned determines which arithmetic/relational operators are to be used by the compiler
  - non-numeric data should be "unsigned"
- Header file "stdint.h" defines alternate type names for standard C data types
  - Eliminates ambiguity regarding #bits
  - Eliminates ambiguity regarding signed/unsigned

(Types defined on next page)

# C compiler data types

Data type declaration *	Number of bits	Range of values
char k; unsigned char k; uint8_t k;	8	0255
signed char k; int8_t k;	8	-128+127
short k; signed short k; int16_t k;	16	-32768+32767
unsigned short k; uint16_t k;	16	065535
int k; signed int k; int32_t k;	32	-2147483648 +2147483647
unsigned int k; uint32_t k;	32	04294967295

<sup>\*</sup> intx\_t and uintx\_t defined in stdint.h

## Data type examples

- Read bits from GPIOA (16 bits, non-numeric)
  - uint16\_t n; n = GPIOA->IDR; //or: unsigned short n;
- Write TIM2 prescale value (16-bit unsigned)

```
- uint16_t t; TIM2->PSC = t; //or: unsigned short t;
```

Read 32-bit value from ADC (unsigned)

```
- uint32_t a; a = ADC; //or: unsigned int a;
```

System control value range [-1000...+1000]

```
- int32\_t \ ctrl; \ ctrl = (x + y)*z; //or: int \ ctrl;
```

Loop counter for 100 program loops (unsigned)

```
- uint8_t cnt;  //or: unsigned char cnt;
- for (cnt = 0; cnt < 20; cnt++) {</pre>
```

## Constant/literal values

Decimal is the default number format //16-bit signed numbers int m,n; m = 453; n = -25; Hexadecimal: preface value with 0x or 0X m = 0xF312; n = -0x12E4; Octal: preface value with zero (0) m = 0453; n = -023; Don't use leading zeros on "decimal" values. They will be interpreted as octal. Character: character in single quotes, or ASCII value following "slash" m = 'a'; //ASCII value 0x61  $n = '\13';$  //ASCII value 13 is the "return" character String (array) of characters: unsigned char k[7]; strcpy(m,"hello\n"); //k[0]='h', k[1]='e', k[2]='l', k[3]='l', k[4]='o', //k[5]=13 or '\n' (ASCII new line character), //k[6]=0 or '\0' (null character – end of string)

## Program variables

- A variable is an addressable storage location to information to be used by the program
  - Each variable must be declared to indicate size and type of information to be stored, plus name to be used to reference the information

```
int x,y,z; //declares 3 variables of type "int"
char a,b; //declares 2 variables of type "char"
```

- Space for variables may be allocated in registers,
   RAM, or ROM/Flash (for constants)
- Variables can be automatic or static

## Variable arrays

- An array is a set of data, stored in consecutive memory locations, beginning at a named address
  - Declare array name and number of data elements, N

```
- Elements are "indexed", with indices [0 .. N-1]

Address:

n[0]

n

n[1]

n[3] = 5;

//set value of 4^{th} array element

n[3]
```

n+16

n[4]

Note: Index of first element is always 0.

## Static variables

- Retained for use throughout the program in RAM locations that are not reallocated during program execution.
- Declare either within or outside of a function
  - If declared outside a function, the variable is global in scope,
    - e. known to all functions of the program
      - Use "normal" declarations. Example: int count;
  - If declared within a function, insert key word static before the variable definition. The variable is *local* in scope, i.e. known only within this function.

static unsigned char bob; static int pressure[10];

## Static variable example

```
unsigned char count; //global variable is static – allocated a fixed RAM location
                       //count can be referenced by any function
void math op () {
                       //automatic variable – allocated space on stack when function entered
 int i;
 static int j;
                       //static variable – allocated a fixed RAM location to maintain the value
if (count == 0)
                       //test value of global variable count
    i = 0;
                       //initialize static variable j first time math op() entered
i = count;
                       //initialize automatic variable i each time math op() entered
j = j + i;
                       //change static variable j – value kept for next function call
                       //return & deallocate space used by automatic variable i
void main(void) {
 count = 0;
                       //initialize global variable count
 while (1) {
  math op();
  count++;
                       //increment global variable count
```

## C statement types

- Simple variable assignments
  - Includes input/output data transfers
- Arithmetic operations
- Logical/shift operations
- Control structures
  - IF, WHEN, FOR, SELECT
- Function calls
  - User-defined and/or library functions

## Arithmetic operations

• C examples – with standard arithmetic operators

\*, /, % are higher in precedence than +, - (higher precedence applied  $1^{st}$ ) Example: j \* k + m / n = (j \* k) + (m / n)

Floating-point formats are not directly supported by Cortex-M3 CPUs.

## Bit-parallel logical operators

Bit-parallel (bitwise) logical operators produce n-bit results of the corresponding logical operation:

```
& (AND) | (OR) ^{\wedge} (XOR) ^{\sim} (Complement)
  C = A \& B;
   (AND)
                   B 1 0 1 1 0 0 1 1
                       0 0 1 0 0 0 1 0
  C = A \mid B;
                   A 0 1 1 0 0 1 0 0
  (OR)
                   B 0 0 0 1 0 0 0 0
                       0 1 1 1 0 1 0 0
  C = A \wedge B;
                   A 0 1 1 0 0 1 0 0
   (XOR)
                   B 1 0 1 1 0 0 1 1
                       1 1 0 1 0 1 1 1
  B = \sim A;
                       0 1 1 0 0 1 0 0
                       1 0 0 1 1 0 1 1
  (COMPLEMENT)
```

## Bit set/reset/complement/test

Use a "mask" to select bit(s) to be altered

```
C = A \& 0xFE;
                A abcdefqh
                                    Clear selected bit of A
                    abcdefg0
C = A \& 0x01;
                A abcdefqh
                                     Clear all but the selected bit of A
C = A \mid 0x01;
                A abcdefqh
              0 \times 01
                                     Set selected bit of A
C = A ^0x01;
                A abcdefgh
             0x01
                                     Complement selected bit of A
                    abcdefgh'
```

## Bit examples for input/output

 Create a "pulse" on bit 0 of PORTA (assume bit is initially 0)

```
PORTA = PORTA | 0x01; //Force bit 0 to 1
PORTA = PORTA & 0xFE; //Force bit 0 to 0
```

#### Examples:

```
if ((PORTA & 0x80)!= 0) //Or: ((PORTA & 0x80) == 0x80)

bob(); // call bob() if bit 7 of PORTA is 1

c = PORTB & 0x04; // mask all but bit 2 of PORTB value

if ((PORTA & 0x01) == 0) // test bit 0 of PORTA

PORTA = c | 0x01; // write c to PORTA with bit 0 set to 1
```

## Bit examples for input/output

• Create a "pulse" on bit 0 of PORTA (assume bit is initially 0)

```
#define GPIO_PIN_0 ((uint16_t) 0x0001U)

GPIOA -> ODR = GPIOA -> ODR | 0x01UL; //Force bit 0 to 1

GPIOA -> ODR = GPIOA -> ODR & 0xFEUL; //Force bit 0 to 0

GPIOA -> ODR = GPIOA -> ODR & ~(0x01UL); //Force bit 0 to 0
```


#### Examples:

#### Example of µC register address definitions in *stm32f767xx.h*

(read this header file to view other peripheral functions)

```
#define PERIPH BASE
                            ((uint32 t) 0x40000000UL)
                                                                          //Peripheral base address in memory
                                                                          //AHB peripherals
#define AHB1PERIPH BASE
                            (PERIPH BASE + 0x00020000UL)
/* Base addresses of blocks of GPIO control/data registers */
#define GPIOA BASE
                          (AHB1PERIPH BASE + 0x0000UL)
                                                                         //Registers for GPIOA
#define GPIOB BASE
                          (AHB1PERIPH BASE + 0x0400UL)
                                                                         //Registers for GPIOB
#define GPIOA
                          ((GPIO TypeDef *) GPIOA BASE)
                                                                         //Pointer to GPIOA register block
                          ((GPIO TypeDef *) GPIOB BASE)
                                                                        //Pointer to GPIOB register block
#define GPIOB
/* Address offsets from GPIO base address – block of registers defined as a "structure" */
typedef struct
                                                                      Address offset: 0x00
   IO uint32 t MODER;
                          /*!< GPIO port mode register,
   IO uint16 t OTYPER;
                          /*!< GPIO port output type register,
                                                                      Address offset: 0x04
                                                                                                */
   IO uint32 t OSPEEDR; /*!< GPIO port output speed register,
                                                                      Address offset: 0x08
                                                                                                */
   IO uint32 t PUPDR;
                          /*!< GPIO port pull-up/pull-down register,
                                                                      Address offset: 0x0C
                          /*!< GPIO port input data register.
                                                                                                */
   IO uint32 t IDR;
                                                                      Address offset: 0x10
   IO uint32 t ODR;
                          /*!< GPIO port output data register,
                                                                      Address offset: 0x14
                                                                                                */
   IO uint32 t BSRR;
                          /*!< GPIO port bit set/reset register,
                                                                      Address offset: 0x18
                                                                                                */
  IO uint32 t LCKR;
                          /*!< GPIO port configuration lock register,
                                                                      Address offset: 0x1C
                                                                                                */
   IO uint32 t AFR[2];
                          /*!< GPIO alternate function low register,
                                                                      Address offset: 0x20-0x24 */
} GPIO TypeDef;
```

# Example: I/O port bits (using bottom half of GPIOB)



Switch connected to bit 4 (PB4) of GPIOB

```
uint32 tsw;
                                 //32-bit unsigned type since GPIOB IDR and ODR = 32 bits
                                 // sw = xxxxxxxxhgfedcba (upper 8 bits from PB15-PB8)
sw = GPIOB->IDR;
                                 // \text{ sw} = 000e0000 \text{ (mask all but bit 4)}
sw = GPIOB -> IDR \& 0x0010;
                                 // Result is sw = 00000000 or 00010000
                                 // NEVER TRUE for above sw, which is 000e0000
if (sw == 0x01)
                                 // TRUE if e=1 (bit 4 in result of PORTB & 0x10)
if (sw == 0x10)
if (sw == 0)
                                 // TRUE if e=0 in PORTB & 0x10 (sw=00000000)
if (sw != 0)
                                 // TRUE if e=1 in PORTB & 0x10 (sw=00010000)
GPIOB->ODR = 0x005a;
                                 // Write to 16 bits of GPIOB; result is 01011010
                                 // Sets only bit e to 1 in GPIOB (GPIOB now hgf1dcba)
GPIOB->ODR \mid= 0x10;
GPIOB->ODR &= \sim0x10;
                                // Resets only bit e to 0 in GPIOB (GPIOB now hgf0dcba)
if ((GPIOB->IDR \& 0x10) == 1) // TRUE if e=1 (bit 4 of GPIOB)
```

## Shift operators

#### Shift operators:

```
x >> y (right shift operand x by y bit positions)
x << y (left shift operand x by y bit positions)
Vacated bits are filled with 0's.</pre>
```

Shift right/left fast way to multiply/divide by power of 2

#### C control structures


- Control order in which instructions are executed (program flow)
- Conditional execution
  - Execute a set of statements if some condition is met
  - Select one set of statements to be executed from several options, depending on one or more conditions
- Iterative execution
  - Repeated execution of a set of statements
    - A specified number of times, or
    - Until some condition is met, or
    - While some condition is true

#### **IF-THEN** structure

 Execute a set of statements if and only if some condition is met

```
TRUE/FALSE condition

if (a < b)
{
    statement s1;
    statement s2;
    ....
}</pre>
```



## **Relational Operators**

Test relationship between two variables/expressions

Test	TRUE condition	Notes
(m == b)	m equal to b	Double =
(m != b)	m not equal to b	
(m < b)	m less than b	1
(m <= b)	m less than or equal to b	1
(m > b)	m greater than b	1
(m >= b)	m greater than or equal to b	1
(m)	m non-zero	
(1)	always TRUE	
(0)	always FALSE	

1. Compiler uses signed or unsigned comparison, in accordance with data types

#### Example:

```
unsigned char a,b;
int j,k;
if (a < b) – unsigned
if (j > k) - signed
```

## Boolean operators

 Boolean operators && (AND) and || (OR) produce TRUE/FALSE results when testing multiple TRUE/FALSE conditions

```
if ((n > 1) \&\& (n < 5)) //test for n between 1 and 5
if ((c == 'q') \mid | (c == 'Q')) //test c = lower or upper case Q
```

Note the difference between Boolean operators &&, ||
 and bitwise logical operators &, |

#### Common error

Note that == is a <u>relational</u> operator,
 whereas = is an <u>assignment</u> operator.

```
if (m == n) //tests equality of values of variables m and n
if (m = n) //assigns value of n to variable m, and then
//tests whether that value is TRUE (non-zero)
```

The second form is a common error (omitting the second equal sign), and usually produces unexpected results, namely a TRUE condition if n is 0 and FALSE if n is non-zero.

#### IF-THEN-ELSE structure

• Execute one set of statements if a condition is met and an alternate set if the condition is not met.

```
if (a == 0)
{
    statement s1;
    statement s2;
}
else
{
    statement s3;
    statement s4:
}
```

## Multiple ELSE-IF structure

 Multi-way decision, with expressions evaluated in a specified order

```
if (n == 1)
  statement1; //do if n == 1
else if (n == 2)
  statement2; //do if n == 2
else if (n == 3)
  statement3; //do if n == 3
else
  statement4; //do if any other value of n (none of the above)
Any "statement" above can be replaced with a set of
statements: {s1; s2; s3; ...}
```

#### **SWITCH** statement

 Compact alternative to ELSE-IF structure, for multiway decision that tests one variable or expression for a number of constant values

## WHILE loop structure

 Repeat a set of statements (a "loop") as long as some condition is met

```
while (a < b)
{
    statement s1;
    statement s2;
    ...
}</pre>


a < b
    S1;
S2;
    ...
"loop" through these
statements while a < b</pre>
```

Something must eventually cause a >= b, to exit the loop

## WHILE examples

```
/* Add two 200-element arrays. */
int M[200], N[200], P[200];
int k;
/* Method 1 – using DO-WHILE */
                          //initialize counter/index
k = 0;
do {
 M[k] = N[k] + P[k]; //add k-th array elements
            //increment counter/index
  k = k + 1;
\} while (k < 200); //repeat if k less than 200
/* Method 2 – using WHILE loop
k = 0;
                         //initialize counter/index
while (k < 200) { //execute the loop if k less than 200
 M[k] = N[k] + P[k]; //add k-th array elements
  k = k + 1;
                          //increment counter/index
```

## WHILE example



Wait for a 1 to be applied to bit 0 of GPIOA and then read GPIOB

```
while ((GPIOA->IDR & 0x00001) == 0) // test bit 0 of GPIOA
{} // do nothing & repeat if bit is 0
c = GPIOB->IDR; // read GPIOB after above bit = 1
```

## FOR loop structure

- Repeat a set of statements (one "loop") while some condition is met
  - often a given # of iterations

```
Initialization(s) execution

for (m = 0; m < 200; m++)

{

statement s1;

statement s2;
}

Operation(s) at end of each loop
```

## FOR loop structure

 FOR loop is a more compact form of the WHILE loop structure

## FOR structure example

## FOR structure example

```
/* Nested FOR loops to create a time delay */

— for (i = 0; i < 100; i++) { //do outer loop 100 times

— for (j = 0; j < 1000; j++) { //do inner loop 1000 times

— } //do "nothing" in inner loop

— }
```

### **C** functions

- Functions partition large programs into a set of smaller tasks
  - Helps manage program complexity
  - Smaller tasks are easier to design and debug
  - Functions can often be reused instead of starting over
  - Can use of "libraries" of functions developed by 3<sup>rd</sup> parties, instead of designing your own

### **C** functions

- A function is "called" by another program to perform a task
  - The function may return a result to the caller
  - One or more arguments may be passed to the function/procedure

#### **Function definition**

```
Type of value to be returned to the caller*

int math_func (int k; int n)

{

int j; //local variable

j = n + k - 5; //function body

return(j); //return the result
}
```

<sup>\*</sup> If no return value, specify "void"

## **Function arguments**

- Calling program can pass information to a function in two ways
  - By value: pass a constant or a variable value
    - function can use, but not modify the value
  - By reference: pass the address of the variable
    - function can both read and update the variable
  - Values/addresses are typically passed to the function by pushing them onto the system stack
    - Function retrieves the information from the stack

## Example – pass by value

```
/* Function to calculate x<sup>2</sup> */
int square (int x) { //passed value is type int, return an int value
                     //local variable – scope limited to square
  int y;
  y = x * x;
                     //use the passed value
  return(x);
                    //return the result
void main {
 int k,n;
                  //local variables – scope limited to main
 n = 5;
 k = square(n); //pass value of n, assign n-squared to k
 n = square(5); // pass value 5, assign 5-squared to n
```

## Example – pass by reference

In the above, *main* tells *square* the location of its local variable, so that *square* can write the result to that variable.

## Example – receive serial data bytes

```
/* Put string of received SCI bytes into an array */
Int rcv_data[10]; //global variable array for received data
Int rcv_count; //global variable for #received bytes

void SCI_receive () {
  while ((SCISR1 & 0x20) == 0) {} //wait for new data (RDRF = 1)
  rcv_data[rcv_count] = SCIDRL; //byte to array from SCI data reg.
  rcv_count++; //update index for next byte
}
```

Other functions can access the received data from the global variable array rcv\_data[].

#### Some on-line C tutorials

- http://www.cprogramming.com/tutorial/ctutorial.html
- http://www.physics.drexel.edu/courses/Comp
   \_Phys/General/C\_basics/
- http://www.iu.hio.no/~mark/CTutorial/CTutorial.html
- http://www2.its.strath.ac.uk/courses/c/