Lecture 12/13
Home
Ed Discussion
Announcements
Assignments
Quizzes
Recorded Lectures
Zoom
Pages
Grades
Chatterbox
Teamlinks
Q4 Kahoots Search
Q4 Online Quizzes
Q4 Online Quizzes (ELEC1601)
Notebook

Project Essentials

▶ Overview
▶ Sensor shield
▼ The take-home board
To assist you with the essential task, we have created take-home boards as follows:



These boards emulate the sensor shield available on the robot.

With this board, you should be able to complete the "take-home" part of each of the following scenarios at home.

Aspects to be aware of:

- The sensors are similar to those on the robot, but slightly different (they are functionally instead of vertically aligned).
 - You may need to do some recalibration in the lab.
 - You may have to make some subtle adjustments in the lab.
- A pair of red and green LEDs has been provided on each side of the board (between the Arduino footprint and the front sensor block). You could use these to indicate whether you are commanding the servos to rotate forward (green) or backwards (red).
- A short of either paper fasteners similar to the resistance we use in the room
- The take-home board doesn't have wheels, but don't forget about them!
 - You should test your code on the robot in the lab.
 - You don't need to worry about full-light movements.
- The gap between the walls is a corridor is 30cm

4. The "Take-Home Robot Emulator"

Good news! You do get to use your code at home when emulated.

While this board have servos, a chassis, or wheels, this will allow you to develop robot code outside the classroom!

Aspects to be aware of:

- Wheels have been replaced with blinking LEDs (different frequencies for different speeds). Green for forward (LED1A and 4A), Red for backwards (LED1B and 4B).
- You will have to change 2 line of code to switch between the lab robot and the robot emulator.
- The IR LEDs and sensors are slightly better on the emulator.

The rest is pretty much the same.

Here's how to use it:

- Do your code demonstration, tell them your team number, and sign off on receiving one.



- Borrow the Emulator you want your teammates.
 - Caution: Don't lose it - you'll have to charge $200 for lost and severely damaged boards. This is how much it costs us to replace them.
- Download the compressed folder:
 The compressed folder contains a file: an example Arduino code scaffold, TakeHomeBoard_BootCode.ino.zip, the library header file ELEC1601_TakeHomeBoard.h, the library implementation file ELEC1601_TakeHomeBoard.cpp, and the library configuration file library.properties.

You don't need to adjust any of these files. However, **you do have to include it as a library in your Arduino IDE.**





- **In your code code, comment out the command #include "Servo" using // forward slashes and include the following command #include "ELEC1601_TakeHomeBoard.h"**
- Use the USBB to USBB cable to connect the Take Home Robot Emulator to your computer. The cable supplies enough power for operating the board. If you do not have USBB ports on your board, you can use a dongle or a USBA to USBB cable.
- Upload your code. Make sure to uncomment the Serial.begin(9600); command. Open the Serial Monitor and Serial Plotter and develop your code. Once you think your code is ready, turn it off, upload it to a lab robot in your room session, and test it on the track. Make sure to uncomment out, #include "ELEC1601_TakeHomeBoard.h" and include #include "Servo.h" instead when using the actual lab robot.

▼ The essential tasks - scenarios you must detect and escape from

For each of the following scenarios:

- Your robot should display on the three LEDs a binary code to indicate the scenario it has detected.
- Your robot should do nothing for at least 5 seconds to so that we can see this code being displayed on the LEDs
- After this, LEDs can display what you like.
- Your robot must complete a sequence of servo operations to get out of that position.
- You can just maintain all the servo commands individually, however, in order to be ready for extension, it is advised to have one piece of code that can detect and deal with each individual scenario

All of the scenarios can be tested in the room at the start of this page.

▼ 0. Unknown Scenario

What you must display:

- LED A Right (MSB): OFF
- LED B Middle (2): OFF
- LED C/Left (LSB): OFF
- (While this, your LEDs can do what you want)

What your robot must do for:

- Not move at all

Why this scenario is important:

- This is perhaps the most important scenario!
- If your robot doesn't know where it is, it is invaluable for it to stop
 - This is the default scenario if your robot doesn't detect any of the scenarios in 1-4.
 - You can then manage a bit and define your own scenario 5.

▼ 1. Robot is in the middle of a long corridor



What you must display:

- LED A Right (MSB): ON
- LED B Middle (2): OFF
- LED C/Left (LSB): OFF
- (While this, your LEDs can do what you want)

What your robot must check:

- Both left and right sensors should identify a similar reading
 - You can choose how you measure this. Calibrating your sensors to measure distance is advised

What your robot must do for:

- The forward sensor should not be used, as it will at least 15cm away.
- Once again, calibrating your sensors to measure distance is advised

What your robot must do to:

- A much more (to) forward
- A much more approximately parallel to the walls
- The center of the robot must remain within 3cm of the center of the corridor
- Stop after completion

Why this scenario is important:

- This is the main one your robot should move along a corridor in a straight line!

▼ 2. Ideal position for Right Turn



What you must display:

- LED A Right (MSB): ON
- LED B Middle (2): ON
- LED C/Left (LSB): OFF
- (While this, your LEDs can do what you want)

What your robot must check:

- The left and right sensors should be used
- The left wall should be used as a wall
 - Ideally you are able to decide the wall is a specific range away (at least a cm away, but less than a cm). This will help you not turn too early/late.

What your robot must do to:

- Robot must rotate 90 degrees
- A much then more forward
- A forward must be enough that it re-enters the corridor and remains approximately parallel to the walls
- The center of the robot must remain within 3cm of the center of the corridor
- Stop after completion

Why this scenario is important:

- This is how you will turn corridors

▼ 3. Ideal position for Left Turn



What you must display:

- LED A Right (MSB): ON
- LED B Middle (2): ON
- LED C/Left (LSB): OFF
- (While this, your LEDs can do what you want)

What your robot must check:

- The left and right sensors should be used
- The left wall should be used as a wall
 - Ideally you are able to decide the wall is a specific range away (at least a cm away, but less than a cm). This will help you not turn too early/late.

What your robot must do to:

- Robot must rotate 90 degrees
- A much then more forward
- A forward must be enough that it re-enters the corridor and remains approximately parallel to the walls
- The center of the robot must remain within 3cm of the center of the corridor
- Stop after completion

Why this scenario is important:

- This is how you will turn corridors

▼ 4. Dead End



What you must display:

- LED A Right (MSB): OFF
- LED B Middle (2): ON
- LED C/Left (LSB): ON
- (While this, your LEDs can do what you want)

What your robot must check:

- The left and right sensors should see a wall

What your robot must do to:

- Robot must rotate 180 degrees
- A much then more forward
- A much then more forward or hard Turn.
- A should remains approximately parallel to the walls
- The center of the robot must remain within 3cm of the center of the corridor
- Stop after completion

Why this scenario is important:

- Do the hallway point in the extension room, your robot must turn around

▼ 5. Bad Starting position - close to the left wall, but parallel to a wall

What you must display:

- LED A Right (MSB): ON
- LED B Middle (2): OFF
- LED C/Left (LSB): ON
- (While this, your LEDs can do what you want)

What your robot must check:

- The left and right sensors should see a wall
 - You should be able to identify that the left sensor is significantly closer to the wall than the left sensor
 - You can choose how you measure this. Calibrating your sensors to measure distance is advised

The forward sensor should see a wall, or a wall at least 15cm away.

- Once again, calibrating your sensors to measure distance is advised

What your robot must do to:

- Robot must rotate clockwise slightly
- A much then more forward
- A should then rotate anticlockwise so it is once again parallel to the walls
- A should then move backwards so it is much safe its starting position, but now more central
 - You may or may not find this step necessary in your final design. It can stop the robot down, but also reduces the likelihood of an accumulation of errors.
- A final position should be approximately parallel to the walls
- The center of the robot must remain within 3cm of the center of the corridor
- Stop after completion

Why this scenario is important:

- This scenario is similar to a bad initial starting position.

▼ 6. Bad Starting position - close to the right wall, but parallel to a wall

What you must display:

- LED A Right (MSB): ON
- LED B Middle (2): OFF
- LED C/Left (LSB): ON
- (While this, your LEDs can do what you want)

What your robot must check:

- The left and right sensors should see a wall
 - You should be able to identify that the right sensor is significantly closer to the wall than the right sensor
 - You can choose how you measure this. Calibrating your sensors to measure distance is advised

The forward sensor should see a wall, or a wall at least 15cm away.

- Once again, calibrating your sensors to measure distance is advised

What your robot must do to:

- Robot must rotate clockwise slightly
- A much then more forward
- A should then rotate anticlockwise so it is once again parallel to the walls
- A should then move backwards so it is much safe its starting position, but now more central
 - You may or may not find this step necessary in your final design. It can stop the robot down, but also reduces the likelihood of an accumulation of errors.
- A final position should be approximately parallel to the walls
- The center of the robot must remain within 3cm of the center of the corridor
- Stop after completion

Why this scenario is important:

- This robot must be robust to a bad initial starting position.

▼ 7. Bad Starting position - close to the left wall, approx 30° angle

What you must display:

- LED A Right (MSB): ON
- LED B Middle (2): ON
- LED C/Left (LSB): OFF
- (While this, your LEDs can do what you want)

What your robot must check:

- The left and forward sensors should see a wall relatively close
 - You should be able to identify that the left sensor is significantly closer to the wall than the right sensor
 - Be careful: the reading of the side forces forward and left likely be different between an entire wall to the for robot), so you might need to recalibrate.
- The right sensor should see a wall far away
- You need to distinguish this from case 17.
 - You must show your demonstrators that your robot can notice the difference

What your robot must do to:

- Robot must rotate clockwise slightly until it is parallel
- You could do nothing. Your robot might detect you are now in Scenario 5, or you create a custom solution.
- Stop after completion

Why this scenario is important:

- Your robot must be robust to a bad initial starting position.

▼ 8. Bad Starting position - close to the right wall, approx 30° angle

What you must display:

- LED A Right (MSB): FLASH (1 second delay)
- LED B Middle (2): ON
- LED C/Left (LSB): OFF
- (While this, your LEDs can do what you want)

What your robot must check:

- The right and forward sensors should see a wall relatively close
 - You should be able to identify that the right sensor is significantly closer to the wall than the left sensor
 - Be careful: the reading of the side forces forward and left likely be different between an entire wall to the for robot), so you might need to recalibrate.
- The left sensor should see a wall far away
- You need to distinguish this from case 17.
 - You must show your demonstrators that your robot can notice the difference

What your robot must do to:

- Robot must rotate anticlockwise slightly until it is parallel
- You could do nothing. Your robot might detect you are now in Scenario 5, or you create a custom solution.
- Stop after completion

Why this scenario is important:

- Your robot must be robust to a bad initial starting position.

▼ 9./10. Your own scenarios

Some ideas:

What you must display:

- Scenario 9:
 - LED A Right (MSB): OFF
 - LED B Middle (2): FLASH (1 second delay)
 - LED C/Left (LSB): OFF
 - (While this, your LEDs can do what you want)
- Scenario 10:
 - LED A Right (MSB): FLASH (1 second delay)
 - LED B Middle (2): FLASH (1 second delay)
 - LED C/Left (LSB): OFF
 - (While this, your LEDs can do what you want)

What your robot must check:

- You decide

What your robot must do to:

- You decide
- Stop after completion

Why these scenarios are important:

- You need to learn and master your own issues

▼ Design Advice

It is not possible to take robots home — You can only test your code in the labs. Therefore, the first thing you need to do is to separate work that can be done at home and work that must be done in the lab.

- Work that can be done at home:
- Work that must be done in the lab:

Unless otherwise noted, the content of course materials are licensed under the Creative Commons Attribution-NonCommercial-ShareAlike 4.0 International License and the University of Sydney's Policy on Open Access and Creative Commons. If you would like to reuse any of the content of this course for commercial purposes, you must request permission from the copyright owner. You can find more information about the Creative Commons licenses at the University's Open Access and Creative Commons page.