
## Drone Reality Workshop Walkthrough


- 1. Visit <a href="https://codrone.robolink.com/pro/blockly/">https://codrone.robolink.com/pro/blockly/</a>
- 2. Insert the battery into the drone
- 3. Click the pair button to open a menu listing nearby Bluetooth devices



4. Find and connect to the Petrone device




- 5. Click on the Flight Commands blocks section
- 6. Drag out the "take off" and "land" blocks
- 7. Drag out the "go forward" block and place it between the take off and land blocks



8. Change the seconds variable to get your drone to fly to a marked position a few feet away

9. Once successful, add a "turn 180 degrees" block and another "go forward" block to make the drone fly to the marked position then return to its original position



- 10. For more of a challenge, try to use the "repeat", "go forward", and "turn" blocks to make the drone fly in a square
- 11. Alternatively, drag the blocks to create this template, and configure the values to make the drone fly in a square

