Classwork-6 Due: 7<sup>th</sup> July, 2015

Note: When being asked to design/create a filter, you have to <u>at least</u> include its frequency response.

## **Problem 1:**

Let the sampling frequency Fs be 8 kHz, and the time vector t runs from 0 to 50 ms. Create a signal  $y(t) = \cos(2\pi f_1 t) + \cos(2\pi f_2 t)$  where  $f_1 = 1209$  Hz and  $f_2 = 1336$  Hz

- a) Plot y(t) in both time and frequency domain.
- b) Design a low-pass filter to filter out  $f_2$ , and then apply this filter to y(t). Plot the result in both time and frequency domain.
- c) Design a high-pass filter to filter out  $f_1$ , and then apply this filter to y(t). Plot the result in both time and frequency domain.
- d) Design a band-pass filter to pass  $f_1$  while reject  $f_2$ , and then apply this filter to y(t). Plot the result in both time and frequency domain.

## **Problem 2:**

The sampling rate of the ECG signal we had from classwork-2 is 512Hz. Each impulse is one beat. The normal heart rate is between 50 and 100 beats per minute at rest

- a) Plot the signal versus time domain. Estimate the heart rate from the signal.
- b) Plot the frequency spectrum of the signal.
- c) Baseline Wander removal: Given that the baseline wander is usually in the range below 0.5Hz in case the patients' movements are not large. Design a high pass filter to remove those low frequency components. Apply the filter you have just designed onto the ECG signal and plot the result.

## **Problem 3:**

In classwork-2, we already applied a low-pass filter to the ECG signal (using the Matlab's *'filter'* function). That filter has the difference equation:

$$y(n) = \frac{x(n) + x(n-1) + x(n-2)}{3}$$

Plot the frequency response of this filter; adjust your axis properly and put a marker to show the cut-off frequency. Estimate its cut-off frequency in Hz given that the sampling frequency is 512 Hz.