1. CPE 325: Laboratory Assignment #4 Subroutines, Passing Parameters, and 16-Bit Hardware Multiplier

Objectives: This laboratory exercise will continue the introduction to assembly language programming with the MSP430 hardware. In this lab, you will learn:

- How subroutines are developed in assembly language
- How to pass parameters to subroutines using registers and the stack
- How to work with the hardware multiplier on the MSP430

Note:

It is required that students have completed the tutorial titled "The MSP430 IAR Embedded Workbench," before starting with this one.

1.1. Subroutines

In a given program, it is often needed to perform a particular sub-task many times on different data values. Such a subtask is usually called a subroutine. For example, a subroutine may sort numbers in an integer array or perform a complex mathematical operation on an input variable (e.g., calculate sin(x)). It should be noted, that the block of instructions that constitute a subroutine can be included at every point in the main program when that task is needed. However, this would be an unnecessary waste of memory space. Rather, only one copy of the instructions that constitute the subroutine is placed in memory and any program that requires the use of the subroutine simply branches to its starting location in memory. The instruction that performs this branch is named a CALL instruction. The calling program is called CALLER and the subroutine called is called CALLER.

The instruction that is executed right after the CALL instruction is the first instruction of the subroutine. The last instruction in the subroutine is a RETURN instruction, and we say that the subroutine returns to the program that called it. Since a subroutine can be called from different places in a calling program, we must have a mechanism to return to the appropriate location (the first instruction that follows the CALL instruction in the calling program). At the time of executing the CALL instruction we know the program location of the instruction that follows the CALL (the program counter or PC is pointing to the next instruction). Hence, we should save the return address at the time the CALL instruction is executed. The way in which a machine makes it possible to call and return from subroutines is referred to as its *subroutine linkage method*. The simplest subroutine linkage method is to save the return address in a specific location. This location may be a register dedicated to this function, often referred to as the *link register*. When the subroutine completes its task, the return instruction returns to the calling program by branching indirectly through the link register.

The CALL instruction is a special branch instruction and performs the following operations:

• Store the contents of the PC in the link register

• Branch to the target address specified by the instruction.

The RETURN instruction is a special branch instruction that performs the following operations:

• Branch to the address contained in the link register.

1.1.1. Subroutine Nesting

A common programming practice, called subroutine nesting, is to have one subroutine call another. In this case, the return address of the second call is also stored in the link register destroying the previous contents. Hence, it is essential to save the contents of the link register in some other location before calling another subroutine. Subroutine nesting can be carried out to any depth. For example, imagine the following sequence: subroutine A calls subroutine B, subroutine B calls subroutine C, and finally subroutine C calls subroutine D. In this case, the last subroutine D completes its computations and returns to the subroutine C that called it. Next, C completes its execution and returns to the subroutine B that called it and so on. The sequence of returns is as follows: D returns to C, C returns to B, and B returns to A. That is, the return addresses are generated and used in the last-in-first-out order. This suggests that the return addresses associated with subroutine calls should be pushed onto a stack. Many processors do this automatically. A particular register is designated as the stack pointer, or SP, that is implicitly used in this operation. The stack pointer points to a stack called the processor stack.

The CALL instruction is a special branch instruction and performs the following operations:

- Push the contents of the PC on the top of the stack
- Update the stack pointer
- Branch to the target address specified by the instruction

The RETURN instruction is a special branch instruction that performs the following operations:

- Pop the return address from the top of the stack into the PC
- Update the stack pointer.

1.1.2. Parameter Passing

When calling a subroutine, a calling program needs a mechanism to provide to the subroutine the input parameters, the operands that will be used in computation in the subroutine or their addresses. Later, the subroutine needs a mechanism to return output parameters, the results of the subroutine computation. This exchange of information between a calling program and a subroutine is referred to as *parameter passing*. Parameter passing may be accomplished in several ways. The parameters can be placed in registers or in memory locations, where they can be accessed by subroutine. Alternatively, the parameters may be placed on a processor stack. Let us consider the following program shown in Figure 1. We have two integer arrays arr1 and arr2. The program finds the sum of the integers in arr1 and displays the result on the ports P1 and P2, and then finds the sum of the integers in arr2 and displays the result on the ports P3 and P4. It is obvious that we can have a single subroutine that will perform this operation and thus make our code more readable and reusable. The subroutine needs to get three input parameters: what is the starting address of the input array, how many elements the array has,

and where to display the result. In this example, the subroutine does not return any output parameter to the calling program.

Let us first consider the main program (Figure 2) and corresponding subroutine (suma rp, Figure 3) if we pass the parameters through registers. Passing parameters through the registers is straightforward and efficient. Three input parameters are placed in registers as follows: R12 keeps the starting address of the input array, R13 keeps the array length, and R14 defines the display identification (#0 for P1&P2 and #1 for P3&P4). The calling program places the parameters in these registers, and then calls the subroutine using CALL #suma rp instruction. The subroutine uses register R7 to hold the sum of the integers in the array. The register R7 may contain valid data that belongs to the calling program, so our first step should be to push the content of the register R7 on the stack. The last instruction before the return from the subroutine is to restore the original content of R7. Generally, it is a good practice to save all the general-purpose registers used as temporary storage in the subroutine as the first thing in the subroutine, and to restore their original contents (the contents pushed on the stack at the beginning of the subroutine) just before returning from the subroutine. This way, the calling program will find the original contents of the registers as they were before the CALL instruction. Other registers that our subroutine uses are R12, R13, and R14. These registers keep parameters, so we assume we can modify them (they do not need to preserve their original value once we are back in the calling program).

```
1 /*-----
2 * Program : Find a sum of two integer arrays;
3 * Input : The input arrays are signed 16-bit integers in arr1 and arr2 4 * Output : Display sum of arr1 on P10UT&P2OUT and sum of arr2 on P3OUT&P4OUT
5 * Modified by: A. Milenkovic, milenkovic@computer.org
  * Date : September 14, 2008
   * Description: MSP430 IAR EW; Demonstration of the MSP430 assembler
  #include "msp430.h"
                                      ; #define controlled include file
10
11
         NAME main
                                       ; module name
         PUBLIC main
12
                                       ; make the main label visible
1.3
                                       ; outside this module
         RSEG CSTACK
14
                                       ; pre-declaration of segment
         RSEG CODE
                                       ; place program in 'CODE' segment
15
17 main: MOV #SFE(CSTACK), SP
                                       ; set up stack
        MOV.W #WDTPW+WDTHOLD, &WDTCTL ; Stop watchdog timer
18
19
        BIS.B #0xFF,&P1DIR ; configure P1.x as output
20
        BIS.B #0xFF, &P2DIR
                                      ; configure P2.x as output
        BIS.B #0xFF,&P3DIR ; configure P3.x as output BIS.B #0xFF,&P4DIR ; configure P4.x as output
21
22
        ; load the starting address of the arrayl into the register R4 MOV.W #arr1, R4
23
24
        ; load the starting address of the arrayl into the register R4 \underline{\text{MOV.W}} + \text{arr2} , R5
25
26
27 ;
         Sum arr1 and display
2.8
         CLR R7
                                       ; Holds the sum
29 MOV
                #8, R10
                                       ; number of elements in arr1
30 lnext1: ADD @R4+, R7
                                       ; get next element
                R10
31 DEC
32
         JNZ
                lnext1
        MOV.B R7, P10UT
                                      ; display sum of arr1
33
34
         SWPB R7
35
        MOV.B R7, P2OUT
36; Sum arr2 and display
37 CLR R7
38 MOV #7, R10
                                      ; Holds the sum
                                       ; number of elements in arr2
39 lnext2: ADD
                 @R5+, R7
                                       ; get next element
40
         DEC
                 R10
                 lnext2
          JNZ
41
        MOV.B R7, P30UT
42
                                      ; display sum of arr1
43
         SWPB R7
44
        MOV.B R7, P40UT
45
         JMP
46
49
50
         END
```

Figure 1. Assembly program for summing up two integer arrays (Lab4 D1.s43).

```
1. /*-----
2. * Program : Find a sum of two integer arrays using a subroutine (Lab2 D4 SR.s43)
3. * Input : The input arrays are signed 16-bit integers in arr1 and arr2 4. * Output : Display sum of arr1 on P10UT&P20UT and sum of arr2 on P30UT&P40UT
5. * Modified by: A. Milenkovic, milenkovic@computer.org
6. * Date : September 14, 2008
7. * Description: MSP430 IAR EW; Demonstration of the MSP430 assembler
8. *-----*/
9. #include "msp430.h"
                                                   ; #define controlled include file
10.
11.
       NAME main
12.
                                                    ; module name
13.
14. PUBLIC main
                                                  ; make the main label visible
15.
                                                    ; outside this module
16.
17.
           EXTERN suma_rp
18.
     RSEG CSTACK
                                                  ; pre-declaration of segment
19.
20.
                                                    ; place program in 'CODE' segment
21.
22. main: MOV
                     #SFE(CSTACK), SP
                                                   ; set up stack
23. MOV.W #WDTPW+WDTHOLD, &WDTCTL; Stop watchage time:
24. BIS.B #0xFF, &P1DIR; configure P1.x as output
25. BIS.B #0xFF, &P2DIR; configure P2.x as output
"0.77 CP3PIP configure P3.x as output
            MOV.W #WDTPW+WDTHOLD, &WDTCTL ; Stop watchdog timer
                                           ; configure P3.x as output configure P4.x as output
          BIS.B #0xFF,&P3DIR
BIS.B #0xFF,&P4DIR
27.
28.
29. MOV #arr1, R12 ; put address into R12
30. MOV #8, R13 ; put array length into R13
31. MOV #0, R14 ; display #0 (P1&P2)
32. CALL #suma_rp
33.
34. MOV #arr2, R12 ; put address into R12
35. MOV #7, R13 ; put array length into R13
36. MOV #1, R14 ; display #0 (P3&P4)
37. CALL #suma_rp
38.
            JMP
39.
40.arr1 DC16 1, 2, 3, 4, 1, 2, 3, 4; the first array 41.arr2 DC16 1, 1, 1, 1, -1, -1; the second array
42.
43.
             END
```

Figure 2. Main assembly program for summing up two integer arrays using a subroutine suma_rp (Lab4_D2_main.s43).

```
2. * Program : Subroutine that sumps up two integer arrays
3. * Input : The input parameters are:
4.
               R12 -- array starting address
               R13 -- the number of elements (assume it is =>1)
5.
6.
                R14 -- display ID (0 for P1&P2 and 1 for P3&P4)
7. * Output : No output parameters
8. *----
9. #include "msp430.h"
                                          ; #define controlled include file
10.
11.
       PUBLIC suma rp
12.
13.
     RSEG CODE
14.
15. suma_rp:
16. ; save the register R7 on the stack
17.
          PUSH R7 ; temporal sum
18. CLR R7
19.lnext: ADD @R12+, R7
20. DEC
                 R13
         JNZ
                  lnext
21.
21. JNZ Inext
22. BIT #1, R14
23. JNZ lp34
24. MOV.B R7, P1OUT
25. SWPB R7
26. MOV.B R7, P2OUT
27. JMP lend
28.lp34: MOV.B R7, P3OUT
                                    ; display on P1&P2
; it's P3&P4
29. SWPB R/
30. MOV.B R7, P40UT
31.lend: POP R7
                                           ; restore R7
32.
        RET
33.
           END
```

Figure 3. Subroutine for summing up an integer array (Lab4_D2_SR.s43).

If many parameters are passed, there may not be enough general-purpose register available for passing parameters into the subroutine. In this case we use the stack to pass parameters. Figure 4 shows the calling program (Lab3 D2 main.s43) and Figure 5 shows the subroutine (Lab3 D2 SR.s43). Before calling the subroutine we place parameters on the stack using PUSH instructions (the array starting address, array length, and display id – each parameter is 2 bytes long). The CALL instruction pushes the return address on the stack. The subroutine then stores the contents of the registers R7, R6, and R4 on the stack (another 8 bytes) to save their original content. The next step is to retrieve input parameters (array starting address and array length). They are on the stack, but to know exactly where, we need to know the current state of the stack and its organization (how does it grow, and where does SP point to). The original values of the registers pushed onto the stack occupy 6 bytes, the return address 2 bytes, the display id 2 bytes, and the array length 2 bytes. The total distance between the top of the stack and the location on the stack where we placed the starting address is 12 bytes. So the instruction MOV 12 (SP), R4 loads the register R4 with the first parameter (the array starting address). Similarly, the array length can be retrieved by MOV 10 (SP), R6. The register values are restored before returning from the subroutine (notice the reverse order of POP instructions). Once we are back in the calling program, we can free 6 bytes on the stack used to pass parameters.

```
1. /*-----
2. * Program : Find a sum of two integer arrays
3. * Input : The input arrays are signed 16-bit integers in arr1 and arr2 4. * Output : Display sum of arr1 on P10UT&P20UT and sum of arr2 on P30UT&P40UT
5. * Modified by: A. Milenkovic, milenkovic@computer.org
6. * Date : September 14, 2008
7. * Description: MSP430 IAR EW; Demonstration of the MSP430 assembler
8. *-----*/
9. #include "msp430.h"
                                             ; #define controlled include file
10.
11.
      NAME main
12.
                                              ; module name
13.
14. PUBLIC main
                                             ; make the main label visible
15.
                                              ; outside this module
16.
17.
         EXTERN suma_sp
18.
        RSEG CSTACK
                                          ; pre-declaration of segment
19.
20.
           RSEG CODE
                                              ; place program in 'CODE' segment
21.
22. main: MOV #SFE(CSTACK), SP
                                              ; set up stack
23. MOV.W #WDTPW+WDTHOLD, &WDTCTL; Stop watchdog timer
24. BIS.B #0xFF, &P1DIR; configure P1.x as output
25. BIS.B #0xFF, &P2DIR; configure P2.x as output
26. BIS.B #0xFF, &P3DIR; configure P3.x as output
27. BIS.B #0xFF, &P4DIR; configure P4.x as output
           MOV.W #WDTPW+WDTHOLD, &WDTCTL ; Stop watchdog timer
28.
29. PUSH #arr1
30. PUSH #8
31. PUSH #0
32. CALL #suma_sp
33. ADD #6,SP
                                             ; push the address of arr1
                                             ; push the number of elements
                                             ; push display id
                                            ; collapse the stack
34.
34.
35. PUSH #arr2
36. PUSH #7
37. PUSH #1
38. CALL #suma_sp
39. ADD #6,SP
                                             ; push the address of arr1
                                             ; push the number of elements
                                             ; push display id
                                         ; collapse the stack
40.
        JMP
41.
42.
45.
46.
           END
```

Figure 4. Main program for summing up two integer arrays using a subroutine suma_sp (file: Lab4 D3 main.s43).

```
2. * Program : Subroutine for that sums up elements of an integer array
4.
                 starting address of the array
5.
                 array length
6.
                  display id
7. * Output : No output parameters
8. *-----*/
9. #include "msp430.h"
                                               ; #define controlled include file
10.
11.
           PUBLIC suma sp
12.
13.
           RSEG CODE
14.
15. suma_sp:
16. ; save the registers on the stack
17. PUSH R7 ; temporal sum
PUSH R7

18. PUSH R6

19. PUSH R4

20. CLR R7

21. MOV 10(SP), R6

22. MOV 12(SP), R4

23. lnext: ADD @R4+, R7

24. DEC R6

25. JNZ lnext

26. MOV 8(SP), R4

27. BIT #1, R4

28. JNZ lp34

29. MOV.B R7, P1OUT

30. SWPB R7

31. MOV.B R7, P2OUT

32. JMP lend

33. lp34: MOV.B R7, P3OUT
                                               ; array length
                                               ; pointer to array
                                               ; retrieve array length
                                        ; get id from the stack
; display on P1&P2
; it's P3&P4
33.1p34: MOV.B R7, P30UT
34. SWPB R7
35. MOV.B R7,
           MOV.B R7, P40UT
36.lend: POP R4
                                               ; restore R4
36. Tena.
37. POP
                     R6
38.
            POP
                     R7
39.
            RET
40.
            END
```

Figure 5. Subroutine for summing up an integer array (file: Lab4 D3 SR.s43).

1.2. Hardware multiplier

The MSP430 contains an optional peripheral hardware multiplier that allows the user to quickly perform multiplication operations. Multiplication operations using the standard instruction set can be complex and consume a lot of processing time; however, the hardware multiplier is a specialized peripheral that the user can operate with only a few commands. The multiplier can perform up to 16-bit by 16-bit multiplication, and can performed signed or unsigned multiplication with or without an accumulator. Some MSP430 models have no multiplier, but some models have a 32-bit by 32-bit multiplier. It's important to check the datasheet for your particular device to understand the available peripherals.

To use the hardware multiplier, you simply move your first multiplicand into a register designed to accept the first operand. There are four registers which can accept the first operand, and the one you choose determines the type of multiplication that will be performed. The second operand is then moved to the OP2 register. The result of the multiplication is calculated and

placed in two registers – RESLO and RESHI. An additional result register, SUMEXT, is used in certain multiplication operations. The MSP430 user's guide includes a list of examples for performing the different types of multiplication, and they are listed here for convenience.

```
; 16x16 Unsigned Multiply
      MOV #01234h, &MPY ; Load first operand MOV #05678h, &OP2 ; Load second operand
                                 ; Process results
      ; ...
; 8x8 Unsigned Multiply. Absolute addressing.
      MOV.B #012h, &0130h ; Load first operand MOV.B #034h, &0138h ; Load 2nd operand
                                 ; Process results
      ; ...
; 16x16 Signed Multiply
      MOV #01234h, &MPYS ; Load first operand MOV #05678h, &OP2 ; Load 2nd operand
                                 ; Process results
; 8x8 Signed Multiply. Absolute addressing.
      MOV.B \#012h, &0132h ; Load first operand
      SXT &MPYS ; Sign extend first operand MOV. B #034h,&0138h ; Load 2nd operand
      {\tt SXT} &OP2 ; Sign extend 2nd operand
                                ; (triggers 2nd multiplication)
                                 ; Process results
      ; ...
; 16x16 Unsigned Multiply Accumulate
      MOV #01234h, &MAC ; Load first operand MOV #05678h, &OP2 ; Load 2nd operand
                              ; Load 2nd operand
                                 ; Process results
; 8x8 Unsigned Multiply Accumulate. Absolute addressing
      MOV.B \#012h, &0134h ; Load first operand
      MOV.B #034h, &0138h
                                ; Load 2nd operand
                                ; Process results
      ; ...
; 16x16 Signed Multiply Accumulate
      MOV #01234h, &MACS ; Load first operand
      MOV \#05678h, \&OP2; Load 2nd operand
                                 ; Process results
      ; ...
; 8x8 Signed Multiply Accumulate. Absolute addressing
      MOV.B \#012h, &0136h ; Load first operand
      SXT &MACS ; Sign extend first operand
MOV.B #034h,R5 ; Temp. location for 2nd operand

Sign extend 2nd operand
      SXT R5
MOV R5,&OP2
                                ; Sign extend 2nd operand
                           ; Load 2nd operand
                                ; Process results
      ; ...
```

More information about the hardware multiplier, including information about the particular registers, can be found in the user's manual.

1.3. References

You should read the following references to gain more familiarity with subroutines, passing parameters, and the hardware multiplier:

- Page 177-185 in the Davies text (subroutines and passing parameters)
- Chapter 8, pages 345-352, in the MSP430FG4618 user's guide (16-bit hardware multiplier)
- TI MSP430: Hardware Multiplier write up by Dr. Milenkovic

1.4. Assignment

Write an assembly language program the initializes four values. These values should be 8-bit signed values. The first two elements are passed to a subroutine using registers that calculate the product using the hardware multiplier. The product is output to R4. The second two elements are passed to a second subroutine using the stack, and the product is calculated using a shift-and-add method. The product is output to R5. The larger of the two products should be output to ports 1 and 2 (little endian).