Electro-hydrostatic actuator accumulator start pressure

The random start pressure of the accumulator of an electro-hydrostatic actuator (EHA) can no longer be so low that the actuator cannot move on its electric pump

Aircraft	A32NX and A380X
Where to find it	Nothing to operate: the spoiler EHAs and the other electro-hydrostatic actuators of the hydraulic model, at every sim start
Branch	`core/eha-accumulator-start-pressure`, based on `master` (FlyByWire master 66021c244 merged in); independent.
Status	Not sim-tested. Found and fixed offline from a flaky Rust test; the fix has a unit test (the lowest possible random draws are lifted above the pump threshold) and the Rust test suites of the three systems crates passed when it was written.
Pictures	No pictures: the change is a number in the hydraulic model.

1. Accumulator start pressure above the pump threshold

> **Aircraft:** A32NX and A380X | **Where:** Hydraulic model, no control | **Status:** Not sim-tested. One unit test; the Rust test suites passed.

What it is for

An electro-hydrostatic actuator (EHA) has a small accumulator that must hold more than 100 psi for its electric pump to run. At every start the sim draws the accumulator pressure at random (mean 800 psi, spread 200 psi) and the draw was cut only at 0 psi. About one start in 4300 therefore gave an accumulator below the pump threshold: a spoiler EHA then could not move on its electric backup, and the unit tests that move an EHA failed at random.

The start pressure is now cut at three spreads below the mean (200 psi), as a serviced accumulator is never charged lower than that; a flat accumulator is a failure, not a random start state. The pump threshold of 100 psi got a name in the code.

What you should see

Situation	What you should see
Any start of the sim, normal draw (almost always)	No change: the accumulator starts between 200 psi and its maximum, about 800 psi.
The rare very low draw (about 1 in 4300 starts)	Before: the accumulator started under 100 psi and the spoiler EHA could not move on its electric pump. Now: it starts at 200 psi and the EHA moves.

Limitations and why

Limitation	Why	What to do
A failure that empties the accumulator is not covered.	The fix only changes the random start state.	-

How to use

1. Nothing to set: the fix applies at every sim start.

How to test

#	Do this	Expected result
1	Developer check, outside the sim: run the Rust tests of the systems crates (`cargo test`).	All pass, including `a_serviced_electro_hydrostatic_accumulator_is_never_below_the_pump_start_pressure`; the spoiler EHA tests no longer fail at random.
2	In the sim, any aircraft on the ground with hydraulic systems off and electrics on, move the spoilers with the speedbrake lever (A32NX) or the ground spoiler test as usual after several restarts.	The spoilers move on the electric backup every time; no start leaves a spoiler EHA stuck.