/ 2.9.28 OUTPUT FOR EXTERNAL MOTION $(G80, G81)^{\dagger}$

G81 X ... Y ... L ... ;

With this command, the control outputs external motion signals to the machine after each positioning.

The L number specifies the number of repeated positioning motions. G8l is a modal G code, and remains effective until cancellation with G80. G8l may be used either for this purpose or as a canned cycle command code, depending on the setting of the parameter #6018p0.




Fig. 2.80