Table 4-1 List of Standard Input Signals

	D ₇	D ₆	D ₅	D ₄	D ₃	D_2	D ₁	O
#1300	EDT	MEM	a	Т	s	Н	J	RT
	EDIT	MEMORY	MDI	TAPE	STEP	HANDLE	MANUAL FEED	RAPID TRAVERSE
#1 30 1	ovc	ROV2	ROV1	0V16	ov8	ov4	OV2	OV1
OVERRIDE								
	CANCEL	RAPID T RATE OV		FEEDRATE OVERRIDE				
#1302	-α	+α	-Z	+Z	Y	+Y	-x	+X
JOB PB								
#1 30 3	SPC	SPB	SPA	JV16	JV8	JV4	JV2	JV1
	SPINDLE SPEED MANUAL FEEDRATE OVERRIDE OVERRIDE							
#1 304	DRS	MP4	MP2	MP1	Ηα	HZ	НҮ	НХ
DISPLAY RESET HANDLE PULSE MULTIPLY HANDLE AXIS								
#1305	AFL	MLK	OPT	DRN	BDT	DLK		SBK
	M- FUNCTION LOCK	MACHINE LOCK	OPTIONAL STOP	DRY RUN	BLOCK DELETE	DISPLAY LOCK		SINGLE BLOCK
#1306	SRN	F1	RET	TLMI	ZRN	EDTLK	SP	ST
	PROGRAM RESTART	F1- DIGIT	RETRACT	TLMIN	ZERO RETURN	EDIT LOCK	FEED HOLD	CYCLE START
#1307	PINT	ANG	ABS		MI	MIZ	MIY	MIX
	PROGRAM INTER-	Z-AXIS LOCK	MANUAL ABSOLUTE	MIRROR IMAGE				
#1308	9BDT	8BDT	7BDT	6BDT	5BDT	4BDT	3BDT	2BD
SPECIAL BLOCK DELETE								
#1309			4NG					
			4TH AXIS NEGLECT					