Table 5-2 List of Alarm Codes (Cont'd)

Code	Causes	Code	Causes
335	FUSE (5)	355	OL (5)
	FUSE BLOWN 5		OVERLOAD (1) 5
341	SERVO ERROR (X)	357	OL (OTHERS)
	SERVO ERROR X		OVERLOAD (2)
342	SERVO ERROR (Y)	361	PG ERROR (X)
	SERVO ERROR Y		PG ERROR X
343	SERVO ERROR (Z)	362	PG ERROR (Y)
	SERVO ERROR Z		PG ERROR Y
344	SERVO ERROR (4)	363	PG ERROR (Z)
	SERVO ERROR 4		PG ERROR Z
345	SERVO ERROR (5)	364	PG ERROR (4)
	SERVO ERROR 5		PG ERROR 4
351	OL (X)	365	PG ERROR (5)
	OVERLOAD (1) X		PG ERROR 5
352	OL (Y)	371	FG ERROR (X)
	OVERLOAD (1) Y		FG ERROR X
353	OL (Z)	372	FG ERROR (Y)
	OVERLOAD (1) Z		FG ERROR Y
354	OL (4)	373	FG ERROR (Z)
	OVERLOAD (1) 4		FG ERROR Z
	•		
		1	