# **Tode-RC**

# Hardware Development

Arduino-Mega Pro + Ebyte E32-433T30D [#AMPE32T30]

by TGit-Tech [ <a href="http://www.tgit-tech.com">http://www.tgit-tech.com</a> ]
Build Version: 21V9 / Last Updated: 2021-11-09



( 1. Introduction :: Introduction ) Page -2-

# **Table of Contents**

1. Introduction	2
2. <u>Tode-RC</u>	3
2.1 Bill of Materials (BOM) \$40	3
2.1.1 Parts \$34	3
2.1.2 <u>Supplies \$4</u>	5
2.1.3 <u>3D-Prints \$2</u>	6
2.2 Display Assembly	7
2.2.1 PCB Assembly	7
A. Schematic & Layout	9
2.2.2 Hardware Assembly	9
- ·	

2.3 Backplane AMPE32T30	10
2.3.1 PCB Assembly	10
A. Schematic & Layout	13
2.4 Final Assembly	14
3. Battery Tray	16
3.1 Bill of Materials (BOM) \$4	16
3.1.1 <u>Supplies \$3</u>	16
3.1.2 <u>3D-Prints \$1</u>	16
3.2 Assembly	17

# 1. Introduction

The Tode System

Tode-RC = Handheld Remote Control Models

https://github.com/TGit-Tech/Tode-RC

Model #AMP Arduino Mega Pro (No RF Module)

Model #AMPE32T30 Arduino Mega Pro + Ebyte E32-433T30D (1W/30dbm) RF module

• Model #AMPE32T20 Arduino Mega Pro + Ebyte E32-433T20D (250mW/20dbm) RF module

Model #AMPXBEE Arduino Mega Pro + Digi XBee RF Module

Tode-SideIO = Input/Output Stations

Model #SIOST Tode SideIO with Screw Terminals <a href="https://github.com/TGit-Tech/Tode-SIOST">https://github.com/TGit-Tech/Tode-SIOST</a>

Model #SIOAP Tode SideIO with Aviation Plugs

Manuals

User Manual Operator Instructions including Setup and Wiring

Hardware Development
 How to build the hardware including detailed circuit diagrams

• Firmware Development How to adjust and create firmware for the Tode


The Tode System is licensed under the MIT License.

# 2. Tode-RC

# 2.1 Bill of Materials (BOM) \$40

- ✓ See the "Tode General Hardware Development" document for required tools
  - o Note: A 3.5mm Drill bit is required as well as general tools described in that document.

#### 2.1.1 Parts \$34



✔ Arduino Mega Pro Mini [ATmega2560 @ 16MHz]

o Power In: 6Vdc to 9Vdc (Peek 18Vdc)

o Power Out: 5Vdc @ 800mA + 3Vdc @ 800mA

o Load Amps: 5Vdc @ 220mA

o IO-Pins: 54-Digital, 16-Analog

Memory: 256kb RAM, 4kb EEPROM

Temp Rng: -40C to 85CPricing: ~ \$10/each

• Web @ https://robotdyn.com/mega-2560-pro-embed-

ch340g-atmega2560-16au.html



✓ Ebyte E32433T30D

 $\circ$  Power In: 3.3Vdc to 5.2Vdc ( + = Damage )

Load Amps: Tx @ 106mA, Rx @ 15mA

Oata Rate: 0.3Kbps to 19.2Kbps

୍ Antenna Plg: SMA-K

• Frequency: 410MHz to 441MHz

o RF: Tx @ 30dBm, Rx @ -147dBm

Pricing: ~ \$10/each

Web @ https://www.ebyte.com/en/index.aspx


https://www.ebyte.com/en/product-view-news.html?id=108




✓ 1.8 / 1.77 -Inch TFT LCD Display

Power-In: 5Vdc

o Resolutions: 128 x 160dpi ST7735 RGB





✓ Tode #EMPE32T30 PCB


Manufacturer: Oshpark.com

o Pricing: \$3.84

Dimensions: 35mm x 56mmTemp: -20C to 70C

(8)Pin-Order: GND,VCC,SCL,SDA,RES,DC,CS,BL

o Pricing: ~ \$4.75/each




✓ Tode Buttons PCB

o Manufacturer: Oshpark.com

o Pricing Each: \$1.41

Batch Price: \$112.80 per 80

Batch Price: \$115.20 per 30



10mm/0.39in

#### 20mm/0.78in

✔ Dorhea 5V @ 3A Buck Power Supply Module

o Input Voltage: 4.5Vdc to 24Vdc

Output Voltage: 0.8-17V (Fixed Voltage by Trace-Cut)

Max Output: 3A Nominal Output: 1.5A Pricing: \$1/ea

Web @ <a href="https://www.amazon.com/dp/B08Y674Z6F">https://www.amazon.com/dp/B08Y674Z6F</a>



- ✓ 433M SMA Aerial Antenna
- ✓ Various Models may be used ranging from \$1 to \$5/ea
- ✔ Price estimate at \$3/ea

#### 2.1.2 Supplies \$4




# 2.1.3 3D-Prints \$2

- ✓ 3D Print the Following Casing (Order according to Assembly Needed)
  - Files in Folder: /3DPrints/

File Name	Grams	Plastic Cost \$0.02/g	Time	Power + Machine Use \$0.01/hr	Total Cost	Supports
Tode-DispKB-Cover.stl	13-grams	\$0.26	2h 31m	\$0.03	\$0.29	YES
Tode-Handheld-AMPE32T30.stl	24-grams	\$0.48	4h 50m	\$0.05	\$0.53	NO
Tode-Handheld-AMPCenter.stl	17-grams	\$0.34	3h 25m	\$0.04	\$0.38	NO
Tode-DispKB-Buttons.stl	1-gram	\$0.02	0:16m	\$0.01	\$0.03	NO

- o Pricing at \$20/per 1KG Roll
- 0.15 Layer Height
- ✓ See separate Section #3.Battery Tray|outline for the Battery Tray Extension



# 2.2 Display Assembly


#### 2.2.1 PCB Assembly

Printed Circuit Boards can be either ordered from a Custom PCB Manufacturer or created with a CNC Router.

- ✓ Custom Manufactured PCB
  - o Benefits Custom PCB manufacturing is by far the better approach.
    - Copper through holes provide better connection
    - A Silk Sscreen for better corrosion resistance
    - Far easier to solder
  - Common Custom Manufacturing Businesses
    - https://oshpark.com/
    - https://jlcpcb.com/
    - https://www.pcbway.com/orderonline.aspx
    - https://www.customcircuitboards.com/
    - https://custompcb.com/
- ✓ CNC Routed PCB
  - Benefits
    - Generally cheaper by a couple dollars
    - Instant product (No shipping/manufacturing wait time)
    - Good for designing phases; not good for finished design production.

#### STEP #1 - Obtain (Purchase/Make) the BUTTONS - PCB

- ✔ Design File
  - FOLDER = /kicad/Buttons/output/
  - GERBER FILE = Buttons-F\_Cu.gbr
- ✓ CNC Routing
  - OCNC File = Buttons-F\_Cu.45S045D.gbr.nc
  - o Hole Sizes = 0.8mm, 2.7mm




#### STEP #2 - Attach SMT Resistors

- ✓ Use <u>Schematic & Layout</u> to determine Resistor Locations
- ✔ Apply solder paste at all Resistor locations (as shown)
- ✔ Place SMT Resistors at correct Locations

#### STEP #3 – Use Reflow Oven to solder SMT Resistors


✔ Place Board w/Resistors & Paste in Reflow Oven T-962 Select Wave #3 and Start the Reflow Oven



#### **STEP #4** - Install and Solder Buttons

Set the board asside and proceed to Assembly Instructions.

NOTICE: The 3P Male Header and Power LED will be installed to fit during assembly.




# **STEP #5** – Keypad Connection

✔ Push the pins of a 3P Male Header flush with Top





## **Step #6** – Insert and Solder 3P Male Header

✓ Solder from the bottom-side instead of top



#### A. Schematic & Layout





- ✓ Surface Mount (SMT) 0805 Resistors
  - $\circ$  LFT–SW6 = (R1) 910-ohm
  - $\circ$  UP-SW3 = (R2) 330-ohm
  - $\circ$  DWN-SW5 = (R3) 680-ohm
  - $\circ$  RHT–SW4 = (R4) 10-ohm or less
  - $\circ$  OK-SW2 = (R5) 1200-ohm
  - $\circ$  SET-SW1 = (R6) 1500-ohm
  - o LED = (R7) 1500-ohm

- ✓ D1(LED) = 3mm Round LED
  - J1(KEYB) Pin #2 is 5V / R7(1500) = 3.3mA through LED
  - Polarity = +/Long-Lead to J1 Side, -/Short-Lead to Bottom
- ✓ SW1 to SW6 are ALL 7mm Tactical Switches

#### 2.2.2 Hardware Assembly

#### **STEP #1** – Install Nuts to <u>Tode-DispKB-Cover.stl</u>

- ✓ Melt-in two M2 Nuts
  - Hold Nut with a long M2 screw and pliers as shown
  - Heat the Nut using a heat gun
  - o Press the nut, edges lined up to shell & flush with top

#### **STEP #2** – Prepare and Insert Tode-DispKB-Buttons.stl

- ✔ Place Buttons on Keypad Switches
  - Use Scissors to cut Buttons apart at the center
  - Skinny legged arrow belongs on top
  - o If button don't push-on use 3.5mm bit to drill-out
- ✔ Place 3mm LED light into PCB
  - Square-Pad is Negative (short-lead)
  - Do not solder the LED at this point



#### **STEP #1** – Install Stickers to Face of Tode-DispKB-Cover.stl

#### STEP #3 – Fasten Display & Keypad and Solder LED

- ✔ Place 1.8/1.77-Inch TFT Display in Tode-DispKB-Cover.stl
  - Solder the 8P Male Header to Screen if separate
- ✔ Place the Keypad in Shell over the LCD as shown
  - Fasten with Screw Size: M2x0.4 8mm long
  - Suggest using Phillips flat head but Pan-head okay.
- ✓ Use LED pins to position LED in Shell Hole for LED
  - Solder and cut LED pins to PCB
- On Manufactured Keypad PCBs a proper fit may require cutting, sanding above the 3P Connection Header.




# 2.3 Backplane AMPE32T30

## 2.3.1 PCB Assembly


STEP #1 - Obtain (Purchase/Make) the AMPE32T30 - PCB

- ✔ Design File
  - FOLDER = /kicad/AMPE32T30/output/
  - GERBER FILE = AMPE32T30-F\_Cu.gbr
- ✓ CNC Routing
  - OCNC File = AMPE32T30-F\_Cu.gbr.nc
  - o CNC Settings: Z-Down: -0.045, Speed: 45mm/s
  - CNC Isolation Bit = Pyramid 0.2mm Tip 45-deg
  - Hole Sizes = 0.8mm, 2.7mm



#### **STEP #2** – Attach Female Dupont Headers

- ✔ Plug the following Female Headers onto the Mega-Pro Pins
  - $\circ$  J1 [PWR] = 2x3P Female Header ( Very Top left )
  - J2 [ICSP] = 2x3P Female Header (ICSP 6-Pin Port)
  - J3 [D44...] = 2x3P Female Header (Bottom-Right Corner)
  - J7 [D18...] = 2x3P Female Header ( 4-Pin Rows Up on Left )
  - $\circ$  J8 [A1...] = 1x9P Female Header (Top Inner on Right)
- ✔ Refer to <u>Schematic & Layout</u> to place Pin-Headers



#### STEP #3 - Solder Female Headers to the PCB


- ✔ Place the Arduino Mega Pro and Headers into proper place on PCB
- ✓ Solder the Female Pin-Headers from Step #3 to the PCB board.



#### WARNING: Never solder-on E32 Radio before STEP #4.

STEP #4 – Attach & Solder J11 1x10P [SideIO] Female Header

- 1. Unplug the Arduino Mega Pro from PCB
- 2. Press header pins on a flat surface; bend to 90-deg
- 3. **J11** [IO] = 1x10P Female Header w/bent pins
- 4. Insert as shown. Be sure face is parallel with edge of board
- 5. Use a Clip to hold in place while soldering the pins to the PCB.
- ✓ Refer to <u>Schematic & Layout</u>



#### STEP #5A - BUZZER OPTION (OPTIONAL) Buzzer Resistor

- ✓ Using <u>Schematic & Layout</u> Solder-Paste SMT Resistors
  - $\circ$  R1 = 910K $\Omega$  SMT 0805 Resistor
  - $\circ$  R2 = 470K $\Omega$  SMT 0805 Resistor
  - $\circ$  R3 = 39 $\Omega$  SMT 0805 Resistor
- ✔ Bake the PCB in Reflow Oven

**SKIP THIS STEP** – The battery monitor is no longer relevant due to the required external 3A Power Supply.

If a Buzzer Feature is desired - Manually solder the R3 =  $39\Omega$  SMT Resistor.

#### STEP #5B - BUZZER OPTION (OPTIONAL) Attach Buzzer

- ✓ Insert Ultra-Thin 5Vdc Piezo Buzzer into Bottom-Left
- ✓ Solder the Piezo Buzzer leads and snip to board level.


#### STEP #6 - Solder the Ebyte E32 Radio to the PCB

- 1. Cut a 4P Male Header and Insert at the top for alignment a) The red circle in the picture
- 2. Insert Ebyte E32 RF Module into the AMPE32T30 PCB (as shown)
- 3. Solder Pins that attach to the PCB
  - a) No need to solder the 4P top alignment pins to E32 Module




#### **STEP #7** – Prepare 5V 3A Power Module

- ✓ Using Razor Knife cut the Top Trace (label ADJ)
- ✓ Jump a Solder bridge where 5V is labeled
- ✔ Do a Continuity Test verifying changes



#### STEP #8 - Wire 5V 3A Power Supply(PS) Ground

- ✓ With 22awg Black stranded wire
  - Solder GND hole of P.S. by twisted together the ends of....
    - <u>4"</u> long piece
    - 1-1/2" long piece
  - o Solder GND hole of PCB board by twisting together the ends of...
    - The other end of the 4"-long wire above from P.S.
    - 3-1/2" long piece
- ✓ NOTE It was found that the Mega-Pro on board power regulator couldn't feed the radio while set to high-power (30dbm) and would cause the Mega-Pro to reset during transmission.
  - The Solution is an external 3A Power Module feeding directly into the Radio but GND must also feed to PCB/Mega.





#### **STEP #9** – Wire 5V 3A Power Supply Power

- ✓ With 22awg Red stranded wire
  - Solder <u>1-1/2"</u> long piece
    - Power Supply VO+(5Vdc) → E32-VCC Pin
  - Solder 1-1/2" long piece in P.S. VI+ (In) hole.



#### A. Schematic & Layout





✔ Female Dupont 2.54mm pitch Connectors


J1	PWR	2x3P Female Header
J2	ICSP	2x3P Female Header
J3	D44-	2x3P Female Header
J4	E32	E32 Radio Module ( Direct Solder )
J5	TFT	1x8P Female Header ( TFT ) Display
J6	КВ	Keypad PCB
J7	D18	2x3P Female Header
J8	A1-10	1x9P Female Header
J10	SideIO	1x10P Female Header
	1	

- ✓ J4(E32) Direct Solder
- ✓ Battery Monitor Resistors
  - R1 910Kohm 0805 SMD (No longer used)
  - o R2 470Kohm 0805 SMD (No longer used)
  - Due to the external 3A power regulator the battery monitor feature design is no longer used.
- ✔ Buzzer Feature (If a buzzer feature is desired)
  - o R3 390hm 0805 SMD
  - BZ1 Direct Solder

# 2.4 Final Assembly

#### STEP #1 - Fasten Mega 2560-Pro Board to AMPCenter

- ✓ 3D-Print File: Tode-Handheld-AMPCenter.stl
- ✔ Pan-head Screw Size: M2.5x0.45 6mm long




# **STEP #2** – Plug on Long-Leg 3P Female and 8P Female

- ✓ On the Display Assembly
  - o Plug in a Long-Legged 8P Female Header to Screen
  - o Plug in a Long-Legged 3P Female Header on Keypad



#### **Step #3** – Plug on Back-plane Assembly with Screen

- Carefully Align the Mega-Pro Pins [from Step#1] with the AMPE32T30 back-plane PCB as well as the Screen and Keypad pins
- Compress the assembly verifying all plugs are seated.
   Lift Plugs on Display & Keypad just a hair.
- ${m 
  u}$  Solder the Display and Keypad Plug Pins to the PCB.
  - Cut off excessive leads




#### **Step #4** – Insert and Fasten the AMPE32T30 Back-plane PCB.

- ✓ Slide PCB from bottom to top and E32 Antenna plug through hole
- ✓ Using (2) #2-56 x 1/4" Machine Screws and Nuts fasten the PCB
  - Use the hole in the very Bottom-Right (as shown)
  - Use the hole in the very Top-Left (next to wires)
  - Use a longer screw to pull nuts into the plastic




#### **Step #5** – Solder Switch

- ✓ Thread the 1-1/2" long piece in P.S. VI+ (In) hole ( from Step #9 ) through the switch hole and solder to the bottom leg of the switch as shown.
- ✓ Cut 1-1/2" long piece and solder to switch top leg and thread it through the switch hole as shown.



#### **Step #6** – Finish Wiring

- ✓ Wire Power Supply GND to Barrel Plug (long-leg)
  Thread wire through Barrel NUT BEFORE soldering.
- ✓ Tighten barrel jack with Nut
- ✔ Wire Switch top-leg to Barrel Plug (short-leg)
- ✓ Insert Switch fully and arrange wires





#### **STEP #7** – Final Assembly and Functional Test

- ✔ Plug the Mega-Pro Into the AMPE32T30 Backplane
- ✔ Plug the DiskKB on top.
  - Fasten using (4) #2 x 3/8" long pan-head SMS.
- ✔ Fasten from the backside
  - Use (4) #2 5/8" long Pan-head Sheet Metal Screws
- ✓ Side-IO Cover Install
  - Insert a #2-56 nut into side of cover
  - Use #2-56 x 3/4" long screw to tighten
- ✔ Plug the Tode-RC into Computer via Top-USB
- ✔ Upload the firmware and test button/screen operation

**NOTICE** – E32 Radio's must be configured in 'Fixed' Mode for the Tode to Work. See the Users Guide for more info.



# 3. Battery Tray

# 3.1 Bill of Materials (BOM) \$4

#### 3.1.1 Supplies \$3



QTY: 1 @ \$1.75/ea 5.5x2.1mm DC Barrel Plug Female Panel Mount 2-Terminal with Nut



QTY: 2 @ \$0.35/ea = \$0.90

Hard Plastic Side-Exit Wires 9V Battery Connector Clip \*Wires must exit from a side / must be hard plastic.



Pan-Head Screws @ \$0.10/ea

(1) #2 x 1/4" Long.


(1) #4 x 3/4" Long.

#### 3.1.2 3D-Prints \$1

- ✓ 3D Print the Following Casing (Order according to Assembly Needed)
  - Files in Folder: /3DPrints/

File Name	Grams	Plastic Cost \$0.02/g	Time	Power + Machine Use \$0.01/hr	Total Cost	Supports
Tode-BattTray-Top.stl	7-grams	\$0.14	1h 43m	\$0.02	\$0.16	NO
Tode-BattTray-Bottom.stl	4-grams	\$0.08	1h 0m	\$0.01	\$0.09	NO
Tode-BattTray-Insert.stl	2-grams	\$0.04	0h 20m	\$0.01	\$0.05	NO
Tode-BattTray-Cover.stl	14-gram	\$0.28	2h 54m	\$0.03	\$0.31	NO


- Pricing at \$20/per 1KG Roll
- 0.15 Layer Height



# 3.2 Assembly


# **STEP #1** – Place Insert and Plugs

- ✔ Place (2) 9V Clips in Tode-BattTray-Insert.stl
- ✔ Bend wires back behind the clip as shown
- ✓ Slide the Insert w/Plugs into the <u>Tode-BattTray-Top.stl</u>



#### **STEP #2** – Cut-to-fit wires and strip

- ✔ Pull the wires together to the edge of the model
- ✓ Snip the wires and strip their ends
- ✔ Bend the long DC-Barrel Plug Lead over to fit in model
- Cut the wire holding part off with dikes



## **STEP #3** – Solder wires to DC-Barrel Plug

- ✓ Twist the two red wires together and solder to short lead on DC-Barrel plug
- ✓ Twist the two black wires together and solder them to the longer (cut-off & bent) lead.



#### **STEP #4** – Assemble the <u>Tode-BattTray-Bottom.stl</u>

- ✓ Slide the Bottom down over the top
- ✓ Make sure wires don't get trapped in the joint
- ✓ Use #4 3/4" long screw to tighten/hold assembly



## **STEP #5** – Attach <u>Tode-BattTray-Cover.stl</u> to Tode-RC Unit

- ✓ Place a #2 1/4" Long Screw on a screwdriver
- ✔ Run the screw up through the holes in the Tray Cover
- ✔ Hold the screw up and place Tode-RC on top ○ Where the Grooves mesh together
- ✓ Tighten the Screw with the screwdriver



## **STEP #6** – Loading / Replacing Batteries

- ✔ Plug (2) 9V Batteries onto battery clips
- ✓ Slide the assembly right into battery cover
- ✓ The DC-Barrel jack will align correctly with Tode-RC

