# Chapter 6

# The Link Layer and LANs

2

# Link layer and LANs: our goals

- •understand principles behind link layer services:
  - error detection, correction
  - sharing a broadcast channel: multiple access
  - link layer addressing
  - local area networks: Ethernet, VLANs

 instantiation, implementation of various link layer technologies



# Link layer, LANs: roadmap

- introduction
- error detection, correction
- multiple access protocols
- LANs
  - · addressing, ARP
  - Ethernet
  - switches
  - VLANs



a day in the life of a web request

Link Layer: 6-7


7

# Link layer: introduction

#### terminology:

- hosts and routers: nodes
- communication channels that connect adjacent nodes along communication path: links
  - wired
  - wireless
  - LANs
- layer-2 packet: frame, encapsulates datagram

link layer has responsibility of transferring datagram from one node to physically adjacent node over a link



### Link layer: context

- datagram transferred by different link protocols over different links:
  - e.g., WiFi on first link, Ethernet on next link
- each link protocol provides different services
  - e.g., may or may not provide reliable data transfer over link

#### transportation analogy:


- trip from Princeton to Lausanne
  - · limo: Princeton to JFK
  - plane: JFK to Geneva
  - train: Geneva to Lausanne
- tourist = datagram
- transport segment = communication link
- transportation mode = link-layer protocol
- travel agent = routing algorithm

Link Layer: 6-9

9

### Link layer: services


- framing, link access:
  - encapsulate datagram into frame, adding header, trailer
  - · channel access if shared medium
  - "MAC" addresses in frame headers identify source, destination (different from IP address!)
- reliable delivery between adjacent nodes
  - · we already know how to do this!
  - · seldom used on low bit-error links
  - wireless links: high error rates
    - <u>Q:</u> why both link-level and end-end reliability?



Link Layer: 6-10

# Link layer: services (more)


- flow control:
  - pacing between adjacent sending and receiving nodes
- error detection:
  - errors caused by signal attenuation, noise.
  - receiver detects errors, signals retransmission, or drops frame
- error correction:
  - receiver identifies and corrects bit error(s) without retransmission
- half-duplex and full-duplex:
  - with half duplex, nodes at both ends of link , but not at same time




11


## Where is the link layer implemented?

- in each-and-every host
- link layer implemented in network interface card (NIC) or on a chip
  - Ethernet, WiFi card or chip
  - implements link, physical layer
- attaches into host's system buses
- combination of hardware, software, firmware



# Interfaces communicating





#### sending side:

- encapsulates datagram in frame
- adds error checking bits, reliable data transfer, flow control, etc.

#### receiving side:

- looks for errors, reliable data transfer, flow control, etc.
- extracts datagram, passes to upper layer at receiving side

Link Layer: 6-13

13

### Link layer, LANs: roadmap

- introduction
- error detection, correction
- multiple access protocols
- LANs
  - addressing, ARP
  - Ethernet
  - switches
  - VLANs
- link virtualization: MPLS




a day in the life of a web request

Link Layer: 6-15

### **Error detection**

EDC: error detection and correction bits (e.g., redundancy)
D: data protected by error checking, may include header fields



Error detection not 100% reliable!

- protocol may miss some errors, but rarely
- larger EDC field yields better detection and correction


Link Layer: 6-16

16

# Parity checking

#### single bit parity:


detect single bit errors



Even parity: set parity bit so there is an even number of 1's

#### two-dimensional bit parity:

detect and correct single bit errors



no errors: 10101|1 11110|0 01110|1 10101|0



Link Layer: 6-18

# Internet checksum (review)

Goal: detect errors (i.e., flipped bits) in transmitted segment

#### sender:

- treat contents of UDP segment (including UDP header fields and IP addresses) as sequence of 16-bit integers
- checksum: addition (one's complement sum) of segment content
- checksum value put into UDP checksum field

#### receiver:

- compute checksum of received segment
- check if computed checksum equals checksum field value:
  - not equal error detected
  - equal no error detected. But maybe errors nonetheless? More later ....

Transport Layer: 3-19

19

## Cyclic Redundancy Check (CRC)

- more powerful error-detection coding
- D: data bits (given, think of these as a binary number)
- G: bit pattern (generator), of r+1 bits (given)



*goal:* choose r CRC bits, R, such that <D,R> exactly divisible by G (mod 2)

- receiver knows G, divides <D,R> by G. If non-zero remainder: error detected!
- can detect all burst errors less than r+1 bits
- widely used in practice (Ethernet, 802.11 WiFi)

# Cyclic Redundancy Check (CRC): example

#### We want:

 $D \cdot 2^r XOR R = nG$ 

or equivalently:

 $D \cdot 2^r = nG XOR R$ 

or equivalently:

if we divide D·2<sup>r</sup> by G, want remainder R to satisfy:

$$R = remainder \left[ \frac{D \cdot 2^r}{G} \right]$$

G										
							0			
1001	1	0	1	1	1	0	0	0	0	
	1	0	0	1		$\overline{}$		$\setminus$		
			1	0	1			$   \sqrt{} $	D*2	r
			0	0	0				D 2	-
				0						
			1	0	0	1				
					1	1	0			
					0	0	0			
					1	1	0	0		
					1	0	0	1		
						1	0	1	0	
						1	0	0	1	
							0	1	1	
							_	_		
								R		

\* Check out the online interactive exercises for more examples: http://gaia.cs.umass.edu/kurose\_ross/interactive/

Link Layer: 6-21

21

# Link layer, LANs: roadmap

- introduction
- error detection, correction
- multiple access protocols
- LANs
  - addressing, ARP
  - Ethernet
  - switches
  - VLANs
- link virtualization: MPLS
- data center networking



a day in the life of a web request

Link Layer: 6-22

### Multiple access links, protocols

two types of "links":

- point-to-point
  - point-to-point link between Ethernet switch, host
  - PPP for dial-up access
- broadcast (shared wire or medium)
  - old-fashioned Ethernet
  - upstream HFC in cable-based access network
  - 802.11 wireless LAN, 4G/4G. satellite











shared radio: satellite humans at a cocktail party (shared air, acoustical)

Link Laver: 6-23

23

### Multiple access protocols

- single shared broadcast channel
- two or more simultaneous transmissions by nodes: interference
  - collision if node receives two or more signals at the same time

#### multiple access protocol -

- distributed algorithm that determines how nodes share channel, i.e., determine when node can transmit
- communication about channel sharing must use channel itself!
  - no out-of-band channel for coordination

# An ideal multiple access protocol

given: multiple access channel (MAC) of rate R bps desiderata:

- 1. when one node wants to transmit, it can send at rate R.
- 2. when M nodes want to transmit, each can send at average rate R/M
- 3. fully decentralized:
  - no special node to coordinate transmissions
  - no synchronization of clocks, slots
- 4. simple

Link Layer: 6-25

25

### MAC protocols: taxonomy


#### three broad classes:

- channel partitioning
  - divide channel into smaller "pieces" (time slots, frequency, code)
  - allocate piece to node for exclusive use
- random access
  - channel not divided, allow collisions
  - "recover" from collisions
- "taking turns"
  - nodes take turns, but nodes with more to send can take longer turns

# Channel partitioning MAC protocols: TDMA

#### TDMA: time division multiple access

- access to channel in "rounds"
- each station gets fixed length slot (length = packet transmission time) in each round
- unused slots go idle
- example: 6-station LAN, 1,3,4 have packets to send, slots 2,5,6 idle




Link Layer: 6-27

27

### Channel partitioning MAC protocols: FDMA

#### FDMA: frequency division multiple access

- channel spectrum divided into frequency bands
- each station assigned fixed frequency band
- unused transmission time in frequency bands go idle
- example: 6-station LAN, 1,3,4 have packet to send, frequency bands 2,5,6 idle



Link Layer: 6-28

### Random access protocols

- when node has packet to send
  - transmit at full channel data rate R.
  - no a priori coordination among nodes
- two or more transmitting nodes: "collision"
- random access MAC protocol specifies:
  - how to detect collisions
  - how to recover from collisions (e.g., via delayed retransmissions)
- examples of random access MAC protocols:
  - ALOHA,
  - slotted ALOHA
  - CSMA,
  - · CSMA/CD,
  - CSMA/CA

Link Layer: 6-29

29

#### Slotted ALOHA

#### assumptions:


- all frames same size
- time divided into equal size slots (time to transmit 1 frame)
- nodes start to transmit only slot beginning
- nodes are synchronized
- if 2 or more nodes transmit in slot, all nodes detect collision

#### operation:

- when node obtains fresh frame, transmits in next slot
  - if no collision: node can send new frame in next slot
  - if collision: node retransmits frame in each subsequent slot with probability p until success

randomization – why?

### Slotted ALOHA



#### Pros:

- single active node can continuously transmit at full rate of channel
- highly decentralized: only slots in nodes need to be in sync
- simple

max efficiency = 1/e = 0.37

#### Cons:


- collisions, wasting slots
- idle slots
- nodes may be able to detect collision in less than time to transmit packet
- clock synchronization

Link Layer: 6-31

31

### **Pure ALOHA**

- unslotted Aloha: simpler, no synchronization
  - when frame first arrives: transmit immediately
- collision probability increases with no synchronization:
  - frame sent at t<sub>0</sub> collides with other frames sent in [t<sub>0</sub>-1,t<sub>0</sub>+1]



pure Aloha efficiency: 18%!

## CSMA (carrier sense multiple access)

#### simple CSMA: listen before transmit:

- if channel sensed idle: transmit entire frame
- if channel sensed busy: defer transmission

#### CSMA/CD: CSMA with collision detection


- · collisions detected within short time
- colliding transmissions aborted, reducing channel wastage
- collision detection easy in wired, difficult with wireless

Link Layer: 6-35

35

### CSMA: collisions


- collisions can still occur with carrier sensing:
  - propagation delay means two nodes may not hear each other's juststarted transmission
- collision: entire packet transmission time wasted
  - distance & propagation delay play role in in determining collision probability



Link Layer: 6-36

## CSMA/CD:

- CSMA/CD reduces the amount of time wasted in collisions
  - transmission aborted on collision detection



Link Layer: 6-37

37


## Ethernet CSMA/CD algorithm

- 1. NIC receives datagram from network layer, creates frame
- 2. If NIC senses channel:

if idle: start frame transmission.

if busy: wait until channel idle, then transmit

- 3. If NIC transmits entire frame without collision, NIC is done with frame!
- 4. If NIC detects another transmission while sending: abort, send jam signal
- 5. After aborting, NIC enters binary (exponential) backoff:
  - after mth collision, NIC chooses K at random from {0,1,2, ..., 2<sup>m</sup>-1}. NIC waits K'512 bit times, returns to Step 2
  - more collisions: longer backoff interval



39

## "Taking turns" MAC protocols

#### channel partitioning MAC protocols:

- share channel efficiently and fairly at high load
- inefficient at low load: delay in channel access, 1/N bandwidth allocated even if only 1 active node!

#### random access MAC protocols

- efficient at low load: single node can fully utilize channel
- high load: collision overhead


#### "taking turns" protocols

look for best of both worlds!

# "Taking turns" MAC protocols

#### polling:

- master node "invites" other nodes to transmit in turn
- typically used with "dumb" devices
- concerns:
  - polling overhead
  - latency
  - single point of failure (master)




Link Layer: 6-42

42

# "Taking turns" MAC protocols

#### token passing:

- control token passed from one node to next sequentially.
- token message
- concerns:
  - token overhead
  - latency
  - single point of failure (token)



Link Layer: 6-43

## Cable access network: FDM, TDM and random access!

Internet frames, TV channels, control transmitted downstream at different frequencies

cable headend

CMTS

cable modem termination system

- multiple downstream (broadcast) FDM channels: up to 1.6 Gbps/channel
  - single CMTS transmits into channels
- multiple upstream channels (up to 1 Gbps/channel)
  - multiple access: all users contend (random access) for certain upstream channel time slots; others assigned TDM

Link Layer: 6-44