

# Installation Tutorial


## Preparation

Before installing the Zebra Label Printer application, ensure your store meets the compatibility requirements. Check if your zebra is on the network by clicking the X button on the printer. If the ethernet icon is green then your printer is connected to the network.

Status	Image
Printer is ready to work with both NET/TCP and USB mode	
Printer is not connected to the network, it is only working with USB mode	

### If you encounter issues with network connectivity, ensure the following:

Make sure you have an ethernet cable connected to your printer in the port below:



## Installation Steps

1. Download the latest version of `zlp-installer.exe` from the releases page. (Click on the button below to navigate to the download page.)

[Download `zlp-installer.exe`](#)

1. Launch the Application and Accept Windows SmartScreen warning if it appears.

X

# Windows protected your PC

Windows Defender SmartScreen prevented an unrecognized app from starting. Running this app might put your PC at risk.

[More info](#)

**Click**


**Click**

[Run anyway](#)

[Don't run](#)

[Don't run](#)

1. Follow the on-screen prompts
2. Complete the setup wizard ( Don't worry if it takes a bit longer, it's normal. Grab a coffee ☕ while you wait. ☕ )



1. Launch the application from the Desktop icon or Start Menu. (If it doesn't open automatically after installation.)

## First Time Configuration

The app has 3 pages at the top: **Main**, **Server Settings**, **Currency**.

1. Open Zebra Label Printer.exe (if it didn't open automatically after installation).
2. Go to **Server Settings**.

### Option A: NET/TCP (Network printer)

1. Set **Print Mode** to NET/TCP.
2. Click Find Printers to scan your network for Zebra printers.
3. Select/enter the printer IP (and port, usually 9100).
4. Click Test Printer.
5. Click Save Configuration (at the bottom).

### Option B: USB (Local USB printer)

1. Set **Print Mode** to USB.
2. Select your Zebra printer from the dropdown.
3. If you don't see it, click Refresh.
4. Click Test Printer.
5. Click Save Configuration (at the bottom).

### Currency


1. Go to **Currency**.

2. Choose currency, price suggestion type, and decimals.
3. Click Save Configuration (at the bottom).

## Start printing

1. Go to **Main**.
2. Click Start Server (if it didn't start automatically).
3. Click Open Printer Page.

(Example pages)

Page	Image
Main	 <p>The screenshot shows the Zebra Label Printer application window. At the top, there's a menu bar with 'File' and 'Help'. Below the menu, a message '✓ Server Running' is displayed. A navigation bar at the bottom has three tabs: 'Main' (which is highlighted in yellow), 'Server Settings', and 'Currency'. In the bottom right corner of the main area, there's a section titled 'Actions' containing four buttons: 'Start Server', 'Stop Server', 'Open Printer Page', and 'QR Code'.</p>

Page	Image
Server Settings	
Currency	

**Notes:**

- If you encounter any issues during installation or configuration, refer to the Troubleshooting section in the README.md or contact support for assistance.
- If you kept the default settings during installation, the application will create a Desktop icon and it will Start with Windows for convenience. (You just have to press the Open Printer Page button to start using it.)
- You can save the Web Interface link as a bookmark in your browser for easy access.

Tip: If you try to leave a page with unsaved changes, the app will ask you to Save / Discard / Cancel.

## Printing Your First Label

1. In the web interface, select the price mode: "SALE PRICE" or "NORMAL PRICE".
2. Enter the price using the suggestion buttons or manually input the price.
3. Set the quantity of labels to print (default is 1, if not specified).
4. Click Submit to print the label.
5. Verify that the label prints correctly from your Zebra printer.

(Web Interface Screenshot)

The screenshot shows the Zebra Price Labeler application. At the top left is a logo of a zebra head. The title 'Zebra Price Labeler' is displayed. On the right, there is a note: 'Time saved with ZPL: 26 min 15 sec' and 'Assuming that each label saves 45 seconds of worktime'. The main interface consists of several input fields and a large grid of price labels.

**Input Fields:**

- SALE PRICE** and **NORMAL PRICE** dropdown menus.
- OLD PRICE\*** input field with a dropdown menu showing 'HUF'.
- Qty (Default: 1)** input field with a dropdown menu showing 'PC'.
- Discount (%)** input field with dropdown options: 20%, 30%, 40%, 50%, 60%, 70%.
- History** section with a note: 'History will show here...' and a 'Clear history' button.
- Action Buttons**: **Submit**, **Reprint Last**, and **Reset fields**.

**Grid of Price Labels:**

The grid displays numerous price labels, each containing a value in HUF. The values are arranged in a grid pattern across multiple rows and columns. Some values are repeated, such as 2490 HUF, 2990 HUF, and 3490 HUF.

Row 1	Column 1	Column 2	Column 3	Column 4	Column 5
2490 HUF	2990 HUF	3490 HUF	3990 HUF	4490 HUF	4990 HUF
5490 HUF	5990 HUF	6490 HUF	6990 HUF	7490 HUF	7990 HUF
8490 HUF	8990 HUF	9490 HUF	9990 HUF	10490 HUF	10990 HUF
11490 HUF	11990 HUF	12490 HUF	12990 HUF	13490 HUF	13990 HUF
14490 HUF	14990 HUF	15490 HUF	15990 HUF	16490 HUF	16990 HUF
17490 HUF	17990 HUF	18490 HUF	18990 HUF	19490 HUF	19990 HUF
20490 HUF	20990 HUF	21490 HUF	21990 HUF	22490 HUF	22990 HUF
23490 HUF	23990 HUF	24490 HUF	24990 HUF	25490 HUF	25990 HUF
26490 HUF	26990 HUF	27490 HUF	27990 HUF	28490 HUF	28990 HUF
29490 HUF	29990 HUF	30490 HUF	30990 HUF	31490 HUF	31990 HUF
32490 HUF	32990 HUF	33490 HUF	33990 HUF	34490 HUF	34990 HUF
35490 HUF	35990 HUF	36490 HUF	36990 HUF	37490 HUF	37990 HUF

**Congratulations!** You have successfully installed and configured the Zebra Label Printer application. You can now print price labels efficiently using the web interface.