

PE Test

EQUIPMENT:

1. DC Source : Chroma 62100H-40 [5V/25A]

2. Digital Multimeter : Keysight 34461A

3. Voltage probe : Burster Kelvin Probes Type 2387-V001

TEST SPEC:

✓ Customer Spec. ☐ DES Soest ☐ QE Test Procedure

Other Standard : 20200605_Renault-5DH-DCDC_ENV_TS_Safety_Rev04.pdf


TEST PARAMETER:

Ambient Temperature : Room Temperature 23°C ±5K

Humidity : uncontrolled

 $\begin{array}{cccc} Current & : & 1A \\ U_{max} & : & 20mV \end{array}$

For electrical risk you can do something like this:



ACCEPTANCE CRITERIA:

The measured voltage in both case must be less than 20mV (20mV/1A = 20m□)

GND (P1) to Cover Center (P2)

GND (P1) to Cover Edge (P3)