

CPU DISPLAYADDRESS FUNCTIONS

<u>ADDRESS</u>	<u>FUNCTION</u>
401	MISCELLANEOUS REG
402	IAR
404	OUT REG
420	UPAC, MOD, SAR, REG/SLOT 'N'
440	UPAL, AAD, CAD, CADCH
500	LS H0
600	MS H0
1004	LS M0
1010	MS M0
1020	LS M1
1040	MS M1
1100	MONITOR POINTS
1200	MONITOR POINTS
2001	UPB0
2002	UPB1
2004	UPB2
2010	UPB3
2020	UPB4
2040	UPAN/UPA
4001	UPB5
4002	UPB6
4004	UPB7
4010	UPB8
4020	UPB9
4040	FUN

CPU DISPLAYMISCELLANEOUS REGISTER

<u>BIT</u>	<u>WRITES</u>	<u>READS</u>
0	CLOCK	
1	SINGLE SLOT	
2	SINGLE INSTRUCTION	
3	STOP ON IAR 8-23 (IAR IN TD410)	
4	STOP ON IAR 4-7 & 8-23	
5	STOP ON IAR 0-3 & 8-23	
6	FORCE H0	
7	INHIBIT MICROPROG. DECODE	
8		
9		
10		
11		
12	REPEAT	
13		
14		
15	STOP AFTER 'N' SLOTS (N IN TD420) STOP AT FAULT	
16		
17		
18	STOP ON SLOT 'N' (N IN TD420)	
19		
20		
21	CLEAR TSCADCH & TSINITO	TSCADCH TOGGLE
22	UPR	TSINITO TOGGLE
23		H. TOGGLE

* TSINITO:

BIT 21 SET - CPU RUNNING

BIT 21 RESET - CPU STOPPED

