

POS (2MK 2.1) COMMANDS

<u>POS ABBREV.</u>	<u>POS COMMAND or COS EQUIVALENT</u>	<u>POS ABBREV.</u>	<u>POS COMMAND or COS EQUIVALENT</u>
AD	#ADR	OF	#OFS
RQ	#ALO	WS	#PRO
WB	#BLK	RB	#REB
BC	BINCOM	PR	#REG
RC	RELCOM	RT	#REL
CU	#CON	RN	#REN
CY	#COP	RS	#RES
PT	PRINT	SP	#RSP
DL	#DEL	RU	#RUN
AL	#EDI	PS	#STA
WC	#FST	ST	#STO
GI	#GIV	SU	#SUS
TR	#HOL	TX	#TEX
LO	#LOO	TI	TIME
LI	#LOI	MO	MODE
LP	#LOP	QI	QUIET
MN	#MON	PL	PRINTLAST
NM	#NAM	CS	CLOSEDOWN
ON	#ONS		

NOTE COS COMMANDS ARE INDICATED BY #.

BINCOM <C6><Command Name> <C7 Offset in C6> <Abbreviation>
sets up the defined subroutine as CI Binary Command

The command name must be 3-12 chars in length and unique within system.
The offset and 2 char abbreviation are optional and default to 0, and no
abbreviation, respectively.

RELCOM <Command Name>

Releases the specified command which may be specified in full or as an
abbreviated name. The system will not allow basic commands to be released.

POS (2MK 2.1) COMMANDS (Cont'd)

PRINT <Block Name> <Mode> <Start Offset> <Finish Offset>

Prints the defined locations of the block in the defined mode, which must be one of following:-

DEC = DECIMAL
BIN = BINARY
OCT = OCTAL
HEX = HEXADECIMAL
CAP = CAPABILITY
INS = INSTRUCTION

The default mode is decimal.

TIME <Hours> <Minutes> <Seconds>

Initialises POS time of day. e.g. TI 21 29 02

MODE <Device Type> <Full or Half Duplex>

Defines the type of Console in use

Parameter 1 must be TTY, S700 or VDU.

Parameter 2 is optional and if present should be either HD or FD (Default is FD).

QUIET <On or Off>

Suppresses error messages.

Parameter 1 is optional. If absent, the state of the QUIET switch will be inverted. If QUIET is ON then errors will be reported as

** ERROR <Error Type> <Parameter No. In Error >

Parameter number is only output if error can be attributed to a particular parameter.

PRINTLAST

Prints in full last error message. (Useful if QUIET is set).

CLOSEDOWN

Causes both CPU's to enter an idle loop, flashing the CPU fault lights, at end of current schedule cycle. The system can be restarted by simply faulting each CPU. This is a safe method of closing the system in order to dump to DISC or MAG TAPE. Terminal use may continue uninterrupted after the system restart.