OptiCAL User's Guide v4.02

Page 15

Reading EEPROM

The byte at any OptiCAL EEPROM address can be read in one of two ways:

Add 128 to the address (as shown in the manual)

Send 2 bytes: the first being 'R' (52_{16}) and the second being the ASCII equivalent of the binary address

For example: to read address number 48, send two bytes: 'R' followed by '0' (ASCII 48) or send only one byte ' $^{\circ}$ (ASCII 176 = 128+48).

NOTE: the addresses in the EEPROM table are in decimal format not Hex.

Page 16

Reading ADC Values

The command should be 'L' or $4C_{16}$ and not 'R' or 52_{16} as stated.

Page 18

Luminance Equation

The luminance equation is incorrect and should read:

Luminance = ((ADCadjust/524288)*Vref*1E-6)/(Rfeed*Kcal*1E-15)