




Power Connector and Switch Assembly























PARTS LIST		
ITEM	PART NUMBER	
1	Connector Case	
2	Connector Case Cover	
3	Power Connector and Switch	
4	M3x10mm Countersunk Screw	
6	M3 Washer	
7	M3x20mm Screw	







A (4:1)





PARTS LIST		
ITEM	PART NUMBER	
2	Connector Case Cover	
3	Power Connector and Switch	
4	M3x10mm Countersunk Screw	
5	M3 Nut	
6	M3 Washer	
7	M3 Spring Washer	
8	M3x20mm Screw	



PARTS LIST		
ITEM	PART NUMBER	
1	Connector Case	
2	Connector Case Cover	
3	M3 Nut	
4	M3 Washer	
5	M3x20mm Screw	







PARTS LIST		
ITEM	PART NUMBER	
1	Connector Case Body	
2	M4x12mm Screw	
3	M4 Washer	

PARTS LIST		
ITEM	PART NUMBER	
1	Connector Case Cover	
2	Connector Case Body	
3	M4 T Nut	

