




Y Movement Limit Switch


























3	3
	4
4	2

PARTS LIST	
ITEM	PART NUMBER
1	Makerbot Limit Switch Board
2	25x25mm Angle Bracket
3	M3x6mm Plastic Screw
4	M3x6mm Internal and External
	Thread Plastic Spacer
5	M3 Washer
6	M3 Plastic Nut

