

## Y Movement Bearing Assembly





PARTS LIST	
ITEM	PART NUMBER
1	Motor/Bearing Holder
2	608-2Z Bearing
3	Wood Screw