
How To: Install g.NEEDaccess MATLAB API Version 1.16.00

Note: Please make sure that g.NEEDaccess Server is installed before g.NEEDaccess MATLAB API is installed!

The installation of g.NEEDaccess MATLAB API consists of two steps:

1. Insert the g.tec product CD into the CD-drive and change to the g.NEEDaccess MATLAB API directory of your CD-drive and double-click the setup.exe file and follow the instructions on the screen to install the g.tec MATLAB API.

Please read the License Agreement for g.NEEDaccess MATLAB API and if you agree with the terms, click **Next**. After installation, you can view the license agreement in the file license.rtf located in the installation directory.




Then just follow the instruction on the screen.

2. When the setup.exe has finished you need to set the MATLAB path.

To make the path settings start MATLAB and open the **Set Path** window from the **File** menu. Then click on the **Add with Subfolders** button and select

C:\Program Files\gtec\gNEEDaccessMATLABAPI

to add all subdirectories:



To add the folder containing the examples to the MATLAB paths, click **Add with Subfolders** and select

C:\Users\<user_name>\Documents\gtec\gNEEDaccessMATLABAP
I\Examples

The g.NEEDaccess Server root installation folder has also to be added to the MATLAB paths. Click **Add Folder...** and browse to the folder

C:\Program Files\gtec\gNEEDaccess

and click OK.

Click Save and Close to finish the installation.