

Verify Lot Numbers

Color-matching guidance for DeckRite PVC membrane installations

WHY THIS MATTERS

Every effort is made during manufacturing to match color batches from one production run to the next. However, even with computerized color-matching techniques, colors may vary slightly between production runs.

BEFORE INSTALLATION

1	CHECK LOT NUMBERS Verify the lot numbers shown on the roll labels before installing material that will be used in adjacent areas.
2	COMPARE ADJACENT MATERIAL After verifying the lot number and before gluing the DeckRite membrane in place, compare the membrane color to adjacent material.
3	LOT NUMBER + COLOR CHECK Match the roll lot numbers and visually compare membrane color before gluing the material in place.

DECKRITE SHIPPING

DeckRite will strive to ship rolls with the same lot number.

INSTALLER RESPONSIBILITY

The installer must also check lot numbers. DeckRite product may be sold through independent distributors who may or may not supply rolls with matching lot numbers.

IMPORTANT: Match lot numbers and compare adjacent membrane color before gluing the DeckRite membrane in place.

Color may vary slightly between production runs. Verify roll labels and adjacent material before installation; contact DeckRite Technical Services with questions.