
Arduino ide does not recognize ESP32 board In the beginning so it is necessary to import files so that it can do it


1) click on file and preferences.




2) write this link on the boards manager URLs box

https://dl.espressif.com/dl/package_esp32_ind ex.jsonhttps://dl.espressif.com/dl/package_esp 32_index.json

Note: If you have more URLs write a comma to separate them.




3) Click on Tools and boards manager.




4) write esp32 on the box and click on install.



5) After executing the above steps, select your ESP32 board.




6) Select the port.



6) and click in verify and upload.

7) When is the first time that we load a code in the ESP32 board is necessary press the boot button at this precise moment.



```
Uploading...

Global variables use 14060 bytes esptool.py v3.0-dev

Serial port COM5

Connecting....
9
```