Space Heater SH-1500 User Manual

Safety Information

Read all instructions before use. Do not operate the unit with a damaged cord. Keep the air inlets and outlets clear. Unplug the unit before cleaning.

Specifications

Model: SH-1500

Rated power consumption: 1500 W

Operating temperature range: 5 to 30 degrees C

Filter replacement interval: every 12 months

Net weight: 3.8 kg

Warranty: 1 years limited warranty

Troubleshooting

If the display shows an error code, find it below before contacting support.

Error code E1 means the water tank is full or missing.

Error code E2 means the room temperature is outside the operating range.

Error code E3 means the filter needs cleaning or replacement.

Error code E4 means the humidity sensor has failed.

Maintenance

Clean the housing with a dry cloth. Replace the filter every 12 months or sooner in dusty environments.