Steps for updating firmware

In order to drop these files onto the PACMod, you'll need to plug into the USB cable that is located behind the side trim panel on the side of the dash (need to have passenger door open to access this). Once you connect to the USB, please copy the .bin and CONFIG.txt files that are on our PACMod and save those on your computer in case the update doesn't give the desired results. Once you have copied the original .bin and .txt files off to your computer, please replace the files on the PACMod with the files that are located in the zip file attached. Once that's done, please unplug the USB cable, depress the e-stop button and then restart the vehicle. At this point, you should be up and running and be able to enable the system just as you did before.