



# ADDAC System

ADDAC2190UT MONO TO STEREO  
ASSEMBLY GUIDE

Revision.01 March.2025

# ADDAC System

## ADDAC2190UT Assembly Guide

March.2025



## ADDAC2190UT Assembly Guide

### STEP 1:

This is our simplest DIY kit, simply place the jacks on the pcb in the color order indicated below, place the front-panel and tighten the jack nuts. Then solder all jack legs.



## ADDAC2190UT Assembly Guide



You're all done!

Happy Patching!

For feedback, comments or problems please contact us at:  
[addac@addacsystem.com](mailto:addac@addacsystem.com)