1- Be sure to have internet connection.
2- Be sure you have installed ubuntu English version: http://www.ubuntu.com/download.
3- Open a terminal window and type the commands after the $ sign to install the following packages:

M4 : $ sudo apt-get install m4
C-shell : $ sudo apt-get install csh
Xlib.h: $ sudo apt-get install libx11-dev
ncurses : $ sudo apt-get install libncurses-dev
Tcl/Tk : $ sudo apt-get install tcl-dev tk-dev
BLT: $ sudo apt-get install blt-dev

4- Download magic: http://opencircuitdesign.com/magic/ . Then, go to your /Download directory and extract it.
5- From your terminal navigate to your magic extracted directory and type the following commands in order to install magic in /usr/local/bin:

```
$ sudo ./configure
$ sudo make
$ sudo make install
```

6- Download irsim: http://opencircuitdesign.com/irsim/. Then, go to your /Download directory and extract it.
7- From your terminal navigate to your irsim extracted directory and type the following commands in order to install irsim in /usr/local/bin:

```
$ sudo ./configure
$ sudo make
$ sudo make install
```

8- Type in your terminal:

```
$ sudo chown [your account name] /usr/local/bin
```

9- Save scmos100.prm https://www.apt-browse.org/browse/debian/jessie/main/amd64/irsim/9.7.87-1/file/usr/lib/x86_64-linux-gnu/irsim/prm/scmos100.prm in /usr/local/bin.
10- To open magic, open new terminal and type :

```
$ cd /usr/local/bin
$ magic [file name]
```

11- Setup your technology file: Start magic and click on menu item "*Options->Tech Manager*". Next to “Technology:” click to get a pull-down menu of available technology files. Choose **scmos.**
To do it using command line way, type

```
$ magic -T scmos [file name]"
```