AAS-UML-MultiProcessingStation

submodel non sono mostrati

- kind = Instance

- value = 0.0

category = VARIABLEterminalType = output (Q1)

- terminalNumber = 17

- semanticId = http://www.test.com/017

- description = motor turn-table counterclockwise

<<Property>>


Terminal-MotorTurnTable

value: real

<<DataSpecificationContent>>

terminalType: stringterminalNumber: intdescription: string

Alessandro Messina | November 2, 2019



<<Operation>>

Turn

- kind = Instance

<<Operation>>

ActivateSaw

- kind = Instance