EEE095/6S 2022 Class Test 2

Student Number:								
Name:								

ANSWER SHEET

11 October 2022 [100]

Solutions!

Instructions:

Please use this attached answer sheets for answering the questions for this test. NB: write you student number and name on the box at the top of each answer page.

Section 1: Multiple Choice [7 x 5marks = 35 marks]

Mark your answer option with a tick (✔) or a cross (**X**), to delete an entry scratch it out (♒) thoroughly so that it looks like neither a tick or a cross otherwise you'd get 0 for the question. Assume you are only to select one answer option for question unless stated otherwise.

Question	A	B	C	D
1.1		X		
1.2			X	
1.3				X
1.4		X		
1.5	X			
1.6				X
1.7		X		

Section 2: YES/NO [5 x 5marks = 25 marks]

Mark your answer option with a tick (✔) or a cross (**X**), to delete an entry scratch it out (♒) thoroughly so that it looks like neither a tick or a cross otherwise you'd get 0 for the question. Assume you are only to select one answer option, Yes or No, unless it is stated that short circuiting your answer is permissible.

Question	YES	NO

2.1		X
2.2		X
2.3		X
2.4		X
2.5	X	

Section 3: Short Answers [40 marks] Solutions!

Question 3.1 Answer [25 marks]



```
module charge_monitor (trigger_in, reset, settrigger,
                       add, sub, en, above, below)

input [7:0] trigger_in, reset, settrigger, add, sub, en;
output above, below;   // 1 bit input and output variables
reg [7:0] level;   // 8 bit register to store level
reg [7:0] triggerLevel;   // 8 bit register to store trigger level

if (reset == 1'b1) level = 0;   // reset level if reset is high
else begin
  if (en == 1'b1) begin   // check if enable is high
    always @(posedge settrigger)   // when positive edge of
                                   settrigger is high
      triggerLevel <= trigger_in;   // store trigger value
    always @(posedge add)   // when add positive edge is high
      level <= level + 1;   // increment level
    always @(posedge sub)   // when sub positive edge is high
      level <= level - 1;   // decrement level
    always @(level)   // when level changes
      if (triggerLevel < level)   // level is greater than
                                  trigger level
        above <= 1;   // set above to high
      else
        above <= 0;   // set above to low
```

```
            if (level < triggerLevel) // if level is lower
                                        than triggerlevel
              below <= 1; //set below to high
            else
              below <= 0; //set below to low

          end //end of if(en == 1'b1)
      end // end of else
endmodule
```

```
module charge_monitor(input trisser_in, input reset, input settrisser,
                      input add, input sub, input en, output above,
                      output below);

    global reg[7:0] level;
    global reg[7:0] trisser;
    global prev_settrisser;
    global prev_add;
    global prev_sub;

    if (reset == 1) begin;
       level = 0;
       prev_settrisser = 0;
       prev_add = 0;
       prev_sub = 0; end;
    else begin; // if reset is low
       if (en == 1) begin;                                  posedge
          if (settrisser & ~prev_settrisser) begin;
             assign trisser = trisser_in;
             end;                                           posedge
          if (add & ~prev_add) begin;
             assign level = level + 1;
             end;                                           posedge
          if (sub & ~prev_sub) begin;
             assign level = level - 1;
             end;
          if (level < trisser) begin;
             assign below = 1
             end;
          else begin;
             assign below = 0;
             end;
          if (level > trisser) begin;
             assign above = 1;
          end
          else begin;
             assign above = 0;
          end;
       end; // end of if(en)
    end // end of else

endmodule
```

```
module charge_monitor ( trigger_in, reset, settriger, add,
                        sub, en, above, below );
 // Declare inputs and out-puts
input [7,0] trigger_in;
input reset, settrigger, add, sub, en;
output reg above, ~~belbw~~ below;

// Declare registers
reg prev_settrigger, prev_add, prev_sub;
reg [7,0] level;

// module logic
always @ (*) begin
   if (reset == 1'b1) begin
        level <= 0;
        prev_settrigger <= 0;
        prev_add <= 0;
        prev_sub <= 0;
   end
   else begin
```

```
if (en == 1'b1) begin
    if (settrigger && (~prev_settriged) begin
        trigger <= trigger_in;
    end
    if ( add && ~prev_sub) begin
        level <= level + 1'b1;
    end
    if(sub && ~prev_sub) begin
        level <= level - 1'b1;
    end
    if ( level < trigger) begin
        above <= 1'b1;
    end
    else begin
        below <=1'b0;
    end
    if(level > trigger) begin
        above <= 1'b1;
    else begin
        above <= 1'b0;
    end
end
prev_settrigger <= settrigger;
prev_add <= add;
prev_sub <= sub;
end
endmodule
```

Question 3.2 Answer [15 marks]

```
.global :
squared_equal :
    MUL  R0, R0, R0      (a) X * X
    CMP  R0, R1          (2) Compare X with Y
    BEQ  equal           (3) branch if equal
    BNE  not_equal       (3) branch if not Equal
equal :
    MOV  R0, #1          (2) Return 1
    B  end
not_equal :
    MOV  R0, #0          (2) Return 0
    B end
end :
    MOV R7, #1
    SWI 0                (2) End program
```

```
Squaredequal:    @function will return 1 if
                 @X squared is equal to Y
mov r2, Y        @assign the value of Y into r2
mov r3, X        @assign the value of X into r3
tst r4, r3, #1   @divide X by 2
mul r1, r3, r3   @multiply r3 by r3, square r3
cmp r1, r2       @compare contents of r1 and r2
blt Notequal     @branch to Notequal if lesser
bgt Notequal     @branch to Notequal if greater

Equal:           @the condition function for equal
  mov r0, #1     @assign the number 1 to r0
  return r0      @return what is in r0 and exit

Notequal:        @function for when it is not equal
  mov r0, #0     @assign the number 0 to r0
  return r0      @return what is in r0 and exits
```

```
.global squared_equal
.type squared_equal, function
Squared_equal:
@ The parameter are stored on r0, -r12
@ r0 = int X
@ r1 = int Y
    mov
    LDR   R2, R0        @ move X from reg0
    mul   R3, R1, R2

@ now R3 = X * X
    CMP   R3, R1
    BEQ   return_1
    mov   R0, #0
    bx    lP, SP        // The Return value
                        // is stored on r0
return_1:
    mov   R, #1
    bx    lP, SP        // return 1
```

```
Squared_equal (x, y):
    mov   r1, x       @ r1 is set to the value of x
    mul   r2, r1, r1  @ r2 is set to the value of x squared
                      @ r2 = r1 x r1
    mov r3, y         @ set r3 to the value of y
    cmp r2, r3        @ compare squar of x and y
    beq EQUAL         @ branch to equal if they are
                      @ the same (r2 == r3)

NOTEQUAL:             @ set default to not equal
    mov r0, #0        @ set res(r0) to 0 if not equal
    b RETURN          @ branch to RETURN

EQUAL:                @ declare equal branch
    mov r0, #1        @ set res(r0) to 1 if equal
    b RETUEN          @ branch to RETUEN

RETUEN:               @ declare RETUEN branch.
    bx lr             @ standard return from functich.
```

```
Squared_equal:
    mov  r1, x   ;   @ r1 = x
    MUL  r1, r1, r1 ;  @ r1 = r1 * r1 = x * x
    mov  r2, y   ;   @ r2 = y
    CMP  r1, r2  ;
    BEQ  Equal   ;   @ If r1 == r2, branch to Equal
    B    NotEqual;   @ Branch to NotEqual - will happen if r1 != r2
                     Reg ~~return equal~~

Equal:
    mov  r0, #1  ;   @ r0 = 1;
    b    Return  ;

NotEqual:
    mov  r0, #0  ;   @ r0 = 0;
    b    Return  ;

Return:
    bx   lr      ;   @ return value stored at default location r0
```

end of test solutions