ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

Task / Activity:	**GENERAL CONSTRUCTION**	**EWMS Number:**	001
		Revision Number:	001
		Next Review Date:	12/06/2026
Purpose:	The purpose of this statement is to eliminate (or reduce as far as practicable) the possibility of an environmental incident occurring. The Hierarchy of Controls must govern the choice of controls adopted. A consultative process will be used to complete this statement. The person(s) carrying out the work activities in this EWMS shall be involved in the EWMS preparation and be trained in the relevant procedures, processes, and requirements. ALL PERSONS INVOLVED IN CARRYING OUT THE NOMINATED TASK / ACTIVITY MUST FOLLOW THIS ENVIRONMENTAL WORK METHOD STATEMENT.		
Project:	4249 Royerdale Pl	**Date Prepared:**	5/03/2026
Project Address:	201 Royerdale Pl, East Kurrajong NSW 2758		
Company Address:	15 Nicol Way, Brendale, QLD, 4500		
Personnel responsible for implementing, monitoring and ensuring compliance with EWMS	Michael Ellul		
Personnel Involved in Developing EWMS:	Zane Taylor (Owner/Director)		
	Adam Henricks (HSEQ Manager)		

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

Legislative Act / Regulation:	Code(s) of Practice:	Australian / NZ Standards, Other:
Environmental Protection (Air) Policy 2019 Environmental Protection (Noise) Policy 2019 Waste Reduction and Recycling Act 2011 (Qld) Waste Reduction and Recycling Regulation 2011 Nature Conservation Act 1992 (Qld) Vegetation Management Act 1999 (Qld) Water Act 2000 (Qld) Biosecurity Act 2014 (Qld) Environment Protection and Biodiversity Conservation Act 1999 (Cth) Environment Protection (Impact of Proposals) Act 1974 (Cth) Protection of the Environment Operations Act 1997 (NSW) Protection of the Environment Operations (General) Regulation 2022 (NSW) Protection of the Environment Operations (Waste) Regulation 2014 (NSW) Environmental Planning and Assessment Act 1979 (NSW)	Erosion and Sediment Control (ESCP) Guidelines Queensland Urban Drainage Manual (QUDM) National Environment Protection Measures (NEPMs) Department of Environment & Science Construction Noise Guidelines Stormwater Management Code of Practice AS 1940 – Storage and Handling of Flammable and Combustible Liquids AS/NZS 3833 – Storage and Handling of Mixed Classes of Dangerous Goods AS 2436 – Guide to Noise Control on Construction Sites Safe Work Australia – Managing the Risk of Hazardous Chemicals Safe Work Australia – Welding Fumes and Airborne Contaminants (if relevant to works)	AS/NZS 14001 – Environmental Management Systems AS/NZS ISO 31000 – Risk Management – Guidelines AS/NZS 5667 – Water Quality Sampling AS 1940 – The Storage and Handling of Flammable and Combustible Liquids AS/NZS 1715 – Selection, Use and Maintenance of Respiratory Protection AS/NZS 1716 – Respiratory Protective Devices AS/NZS 4452 – The Storage and Handling of Toxic Substances AS/NZS 3816 – Management of Clinical and Related Wastes AS 2436 – Guide to Noise and Vibration Control on Construction, Maintenance and Demolition Sites AS/NZS 3500 – Plumbing and Drainage (Stormwater & Sewerage Protection) AS 4970 – Protection of Trees on Development Sites

Biodiversity Conservation Act 2016 (NSW) Water Management Act 2000 (NSW		AS/NZS 1337 – Eye Protectors for Industrial Applications AS/NZS 4501 – Occupational Protective Clothing AS/NZS 1170 – Structural Design Actions (relevant for temporary works impacting the environment) AS/NZS 4389 – Safety Requirements for Earthmoving Machinery (environmental spill & containment interfaces) AS/NZS 3843 – Carbon Footprint & Emissions Reporting (where applicable) AS/NZS 2601 – Demolition of Structures (environmental dust, noise, waste) AS 2550 – Cranes, Hoists & Plant Operations Environmental Considerations AS/NZS 4801 – Occupational Health and Safety Management Systems (for integrated HSEQ systems)
Competencies/ Training Required to undertake Activities:	**Specific Plant Required to Undertake Task:**	**Hazardous Substances Required for Task:**
General Construction Induction (White Card) Environmental Awareness Training	Excavators Skid steers / Bobcats	Concrete (wet concrete / grout) Cement powder

Spill Response Training	Loaders	Adhesives
Waste Management & Segregation Training	Water carts / Water trucks	Sealants
Hazardous Chemicals / SDS Awareness	Vacuum excavation units	Fillers
Sediment & Erosion Control Training (ESC)	Street sweepers / broom attachments	Paints (including primer, acrylic, oil-based, gloss)
Stormwater Protection Awareness	Mobile concrete mixers	Cleaning chemicals
Noise & Dust Management Training	Concrete pumps	Fertilisers
Plant & Equipment Environmental Impact Awareness	Generators	Pesticides
Concrete Washout Management Training	Fuel storage pods / fuel trailers (bunded)	Herbicides
Fuel & Chemical Storage and Handling Training	Portable spill response trailers or spill kits	Fuels (diesel, petrol)
Refuelling Environmental Safety Training	Dust suppression equipment (misters, atomisers)	Oils & lubricants
Asbestos & Hazardous Materials Awareness (if applicable)	Portable pumps (for dewatering under permit)	Solvents
Manual Handling Training	Bunded chemical storage units	Insulation materials (fibrous batts, dust-generating)
Traffic Management Awareness	Rumble grids or wheel-wash systems	Tile adhesives & grouts
Working Around Waterways / Sensitive Environmental Areas Awareness	Trucks (tippers, delivery trucks)	Liquid Nails or other bonding compounds
	Elevated Work Platforms (EWPs)	

Waste Classification & Disposal Training Contaminated Land Awareness Flora & Fauna Protection Awareness Environmental Emergency Response Training Loop System Induction (Tallan process requirement) Site-Specific Environmental Induction (on each project)	Mobile scaffolds Chainsaws / pole saws (for vegetation management) Mulchers or chippers Hand tools (rakes, shovels, brooms) Power tools (grinders, saws, drills — with dust extraction) Concrete vibration equipment (for works generating slurry) Portable sediment control installation tools (staplers, post drivers) Measuring and monitoring equipment (noise meters, particulate meters, water quality meters if applicable)	

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

AUTHORISATION			
We hereby request acceptance of this statement and confirm that the documented precautions / control measures will be complied with.			
Company Name:	Tallan Group	**Work Area/ Task Location:**	All Areas
ABN.:	22 649 005 096	**Onsite supervisor/person responsible for actioning controls:**	All Staff
Responsible Director			

Zane Taylor	Director		12/06/2025
Name	**Position**	**Signature**	**Date**

Note: All relevant signatures must be obtained prior to the commencement of work.

REVIEW								
Review Number	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**
Name	Adam Henricks							
Date	12/12/2025							
Review to be undertaken on a 6 monthly basis or when there is any change that will require the EWMS to be updated to reflect those changes.								

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
Site preparation	Soil disturbance, sediment runoff, stormwater pollution, vegetation disturbance	Moderate	Possible	M13	• Install and maintain erosion and sediment controls (e.g. silt fences, sediment socks, diversion drains, check dams) before starting earthworks. • Limit disturbance to clearly defined work zones; fence off or flag "no-go" areas, particularly around sensitive vegetation and waterways. • Stabilise exposed soil (e.g. mulch, temporary turf, geo-fabric) as soon as practicable. • Locate stockpiles away from drains, gullies and watercourses and protect them with sediment controls. • Protect all stormwater inlets with approved inlet filters or geotextile and inspect before and after rain events. • Sequence works to avoid large areas of bare ground being open at one time. • Avoid working during heavy rainfall where practicable and check controls after any rain event. • Do not discharge turbid water off site without treatment and approval	Supervisor and WHSE Manager in Site Establishment Checklist and regular Site Inspections	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					(e.g. settlement, filtration, pH adjustment where required). • Record installation and inspection of erosion and sediment controls in site checklists / Loop EWMS inspections.		
Delivery of materials – by others or from your work vehicle	Vehicle emissions, fuel spill potential, soil tracking onto roads	Moderate	Possible	M13	• Restrict vehicle movements to designated haul routes and hardstand areas to minimise soil disturbance and vegetation damage. • Install rumble grids, shaker pads or wheel-wash at exits where there is a risk of mud tracking onto public roads. • Sweep or vacuum clean hardstand and access routes as required to prevent sediment reaching stormwater systems. • Implement idling reduction: switch off engines when not in use to reduce emissions and fuel use. • Conduct daily visual checks for fuel and oil leaks; repair leaking plant immediately or remove from service. • Refuel only in designated areas with impermeable bunding and spill containment.	Supervisor and WHSE Manager in regular Site Inspections	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Keep spill kits at refuelling points and on fuel trucks / pods; use absorbent material to contain and recover any spills. • Prevent washdown water, fuel or oil from entering stormwater drains; collect and dispose of washdown water appropriately. • Record any significant spills in Loop and investigate causes and corrective actions.		
Vehicle Mobilization to site	Vehicle emissions, fuel spill potential, soil tracking onto roads	Moderate	Possible	M13	• Restrict vehicle movements to designated haul routes and hardstand areas to minimise soil disturbance and vegetation damage. • Install rumble grids, shaker pads or wheel-wash at exits where there is a risk of mud tracking onto public roads. • Sweep or vacuum clean hardstand and access routes as required to prevent sediment reaching stormwater systems. • Implement idling reduction: switch off engines when not in use to reduce emissions and fuel use.	Supervisor in Site Inspection	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Conduct daily visual checks for fuel and oil leaks; repair leaking plant immediately or remove from service. • Refuel only in designated areas with impermeable bunding and spill containment. • Keep spill kits at refuelling points and on fuel trucks / pods; use absorbent material to contain and recover any spills. • Prevent washdown water, fuel or oil from entering stormwater drains; collect and dispose of washdown water appropriately. • Record any significant spills in Loop and investigate causes and corrective actions.		
Entering and leaving site in vehicle	Vehicle emissions, fuel spill potential, soil tracking onto roads	Moderate	Possible	M13	• Restrict vehicle movements to designated haul routes and hardstand areas to minimise soil disturbance and vegetation damage. • Install rumble grids, shaker pads or wheel-wash at exits where there is a risk of mud tracking onto public roads. • Sweep or vacuum clean hardstand and access routes as required to	Supervisor in Site Inspection	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					prevent sediment reaching stormwater systems. • Implement idling reduction: switch off engines when not in use to reduce emissions and fuel use. • Conduct daily visual checks for fuel and oil leaks; repair leaking plant immediately or remove from service. • Refuel only in designated areas with impermeable bunding and spill containment. • Keep spill kits at refuelling points and on fuel trucks / pods; use absorbent material to contain and recover any spills. • Prevent washdown water, fuel or oil from entering stormwater drains; collect and dispose of washdown water appropriately. • Record any significant spills in Loop and investigate causes and corrective actions.		
Driving on site	Vehicle emissions, fuel spill potential, soil tracking onto roads	Moderate	Possible	M13	• Restrict vehicle movements to designated haul routes and hardstand areas to minimise soil disturbance and vegetation damage.	Supervisor in Site Inspection	L6

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Install rumble grids, shaker pads or wheel-wash at exits where there is a risk of mud tracking onto public roads. • Sweep or vacuum clean hardstand and access routes as required to prevent sediment reaching stormwater systems. • Implement idling reduction: switch off engines when not in use to reduce emissions and fuel use. • Conduct daily visual checks for fuel and oil leaks; repair leaking plant immediately or remove from service. • Refuel only in designated areas with impermeable bunding and spill containment. • Keep spill kits at refuelling points and on fuel trucks / pods; use absorbent material to contain and recover any spills. • Prevent washdown water, fuel or oil from entering stormwater drains; collect and dispose of washdown water appropriately. • Record any significant spills in Loop and investigate causes and corrective actions.		

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
Vehicle Receiving load	Vehicle emissions, fuel spill potential, soil tracking onto roads	Moderate	Possible	M13	• Restrict vehicle movements to designated haul routes and hardstand areas to minimise soil disturbance and vegetation damage. • Install rumble grids, shaker pads or wheel-wash at exits where there is a risk of mud tracking onto public roads. • Sweep or vacuum clean hardstand and access routes as required to prevent sediment reaching stormwater systems. • Implement idling reduction: switch off engines when not in use to reduce emissions and fuel use. • Conduct daily visual checks for fuel and oil leaks; repair leaking plant immediately or remove from service. • Refuel only in designated areas with impermeable bunding and spill containment. • Keep spill kits at refuelling points and on fuel trucks / pods; use absorbent material to contain and recover any spills. • Prevent washdown water, fuel or oil from entering stormwater drains;	Supervisor in Site Inspection	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					collect and dispose of washdown water appropriately. • Record any significant spills in Loop and investigate causes and corrective actions.		
Vehicle Tipping load	Vehicle emissions, fuel spill potential, soil tracking onto roads	Moderate	Possible	M13	• Restrict vehicle movements to designated haul routes and hardstand areas to minimise soil disturbance and vegetation damage. • Install rumble grids, shaker pads or wheel-wash at exits where there is a risk of mud tracking onto public roads. • Sweep or vacuum clean hardstand and access routes as required to prevent sediment reaching stormwater systems. • Implement idling reduction: switch off engines when not in use to reduce emissions and fuel use. • Conduct daily visual checks for fuel and oil leaks; repair leaking plant immediately or remove from service. • Refuel only in designated areas with impermeable bunding and spill containment.	Supervisor in Site Inspection	L6

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Keep spill kits at refuelling points and on fuel trucks / pods; use absorbent material to contain and recover any spills. • Prevent washdown water, fuel or oil from entering stormwater drains; collect and dispose of washdown water appropriately. Record any significant spills in Loop and investigate causes and corrective actions.		

Use of power tools and hand tools	General environmental risk including dust, waste, noise, soil disturbance	Moderate	Possible	M13	• Dust control
					  • Use water carts, misting or fine spray hoses for dust-generating activities (cutting, excavation, demolition, sweeping external areas).
					  • Use dust extraction or on-tool vacuum systems on saws, grinders, sanders and other high-dust tools.
					  • Avoid dry sweeping where possible; use H-class vacuum or damp sweeping methods.
					  • Cover or bind dusty stockpiles and cover truck loads leaving site.
						Site Supervisor during regular site inspections	L6

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			

					• Schedule high-dust activities away from strong winds where practicable.
					• Noise control
					  • Maintain plant and equipment to minimise noisy operation (exhausts, guards, bearings).
					  • Position stationary plant (generators, compressors, pumps) as far as practicable from neighbouring sensitive receivers.
					  • Use local acoustic screens or barriers around very noisy stationary plant where needed.
					  • Comply with approved working hours and local noise conditions; avoid high-impact works early morning/late evening.
					• Waste management & housekeeping
					  • Provide clearly labelled waste streams (general waste, recyclables, scrap metal, timber, concrete, green waste, hazardous waste).
					  • Keep work areas tidy and clear of off-cuts and debris; remove waste at least daily.		

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Prevent debris and off-cuts from entering stormwater drains, pits, waterways or neighbouring properties. • Use licensed waste contractors and keep records of waste removed (dockets, weighbridge tickets where available). • Soil & habitat protection • Confine works to designated areas to avoid unnecessary vegetation damage and soil compaction. • Protect tree trunks and root zones with fencing or bollards where trees are to be retained. • Do not store materials or park plant within tree protection zones. • General environmental management • Include environmental controls in pre-start talks and site inductions. • Complete EWMS / environmental checklists as per Tallan's HSEQ requirements in Loop.		
Cutting of products containing silica	Airborne dust (silica), debris pollution, waste generation	Moderate	Possible	M13	• Use water-suppressed saws or grinders where practicable to	Site Supervisor during regular site inspections	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					minimise respirable crystalline silica (RCS) and nuisance dust. • Fit saws, grinders, sanders and drills with H-class or M-class dust extraction units with HEPA filtration. • Enclose or partially enclose cutting areas where practicable to contain dust and debris. • Avoid cutting or grinding in open windy conditions near sensitive receptors (schools, hospitals, neighbouring residences). • Use local screening (shade cloth hoardings, solid barriers) to prevent debris leaving the site boundary. • Collect slurry and cuttings; do not allow slurry to enter stormwater drains or soak directly into soil. • Segregate and dispose of dust-contaminated waste, broken tiles, masonry and concrete via licensed facilities. • Clean surfaces using H-class vacuum and damp wiping; avoid dry sweeping of fine dust.		
General Carpentry	General environmental risk including dust,	Moderate	Possible	M13	• Dust control • Use water carts, misting or fine spray hoses for dust-generating	Site Supervisor during regular site inspections	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
	waste, noise, soil disturbance				activities (cutting, excavation, demolition, sweeping external areas). • Use dust extraction or on-tool vacuum systems on saws, grinders, sanders and other high-dust tools. • Avoid dry sweeping where possible; use H-class vacuum or damp sweeping methods. • Cover or bind dusty stockpiles and cover truck loads leaving site. • Schedule high-dust activities away from strong winds where practicable. • Noise control • Maintain plant and equipment to minimise noisy operation (exhausts, guards, bearings). • Position stationary plant (generators, compressors, pumps) as far as practicable from neighbouring sensitive receivers. • Use local acoustic screens or barriers around very noisy stationary plant where needed. • Comply with approved working hours and local noise		

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			

					conditions; avoid high-impact works early morning/late evening.
					• Waste management & housekeeping
					  • Provide clearly labelled waste streams (general waste, recyclables, scrap metal, timber, concrete, green waste, hazardous waste).
					  • Keep work areas tidy and clear of off-cuts and debris; remove waste at least daily.
					  • Prevent debris and off-cuts from entering stormwater drains, pits, waterways or neighbouring properties.
					  • Use licensed waste contractors and keep records of waste removed (dockets, weighbridge tickets where available).
					• Soil & habitat protection
					  • Confine works to designated areas to avoid unnecessary vegetation damage and soil compaction.
					  • Protect tree trunks and root zones with fencing or bollards where trees are to be retained.		

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Do not store materials or park plant within tree protection zones. • General environmental management • Include environmental controls in pre-start talks and site inductions. • Complete EWMS / environmental checklists as per Tallan's HSEQ requirements in Loop.		
Cutting using Circular Saw, Nailing, De-nailing using chisels	Airborne dust (silica), debris pollution, waste generation	Moderate	Possible	M13	• Use water-suppressed saws or grinders where practicable to minimise respirable crystalline silica (RCS) and nuisance dust. • Fit saws, grinders, sanders and drills with H-class or M-class dust extraction units with HEPA filtration. • Enclose or partially enclose cutting areas where practicable to contain dust and debris. • Avoid cutting or grinding in open windy conditions near sensitive receptors (schools, hospitals, neighbouring residences). • Use local screening (shade cloth hoardings, solid barriers) to prevent debris leaving the site boundary.	Site Supervisor during regular site inspections	L6

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Collect slurry and cuttings; do not allow slurry to enter stormwater drains or soak directly into soil. • Segregate and dispose of dust-contaminated waste, broken tiles, masonry and concrete via licensed facilities. • Clean surfaces using H-class vacuum and damp wiping; avoid dry sweeping of fine dust.		
Use of grinders and wet saws	Airborne dust (silica), debris pollution, waste generation	Moderate	Possible	M13	• Use water-suppressed saws or grinders where practicable to minimise respirable crystalline silica (RCS) and nuisance dust. • Fit saws, grinders, sanders and drills with H-class or M-class dust extraction units with HEPA filtration. • Enclose or partially enclose cutting areas where practicable to contain dust and debris. • Avoid cutting or grinding in open windy conditions near sensitive receptors (schools, hospitals, neighbouring residences). • Use local screening (shade cloth hoardings, solid barriers) to prevent debris leaving the site boundary.	Site Supervisor during regular site inspections	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Collect slurry and cuttings; do not allow slurry to enter stormwater drains or soak directly into soil. • Segregate and dispose of dust-contaminated waste, broken tiles, masonry and concrete via licensed facilities. • Clean surfaces using H-class vacuum and damp wiping; avoid dry sweeping of fine dust.		

Sanding	General environmental risk including dust, waste, noise, soil disturbance	Moderate	Possible	M13	• Dust control
					  • Use water carts, misting or fine spray hoses for dust-generating activities (cutting, excavation, demolition, sweeping external areas).
					  • Use dust extraction or on-tool vacuum systems on saws, grinders, sanders and other high-dust tools.
					  • Avoid dry sweeping where possible; use H-class vacuum or damp sweeping methods.
					  • Cover or bind dusty stockpiles and cover truck loads leaving site.
					  • Schedule high-dust activities away from strong winds where practicable.
						Site Supervisor during regular site inspections	L6

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			

					• Noise control
					  • Maintain plant and equipment to minimise noisy operation (exhausts, guards, bearings).
					  • Position stationary plant (generators, compressors, pumps) as far as practicable from neighbouring sensitive receivers.
					  • Use local acoustic screens or barriers around very noisy stationary plant where needed.
					  • Comply with approved working hours and local noise conditions; avoid high-impact works early morning/late evening.
					• Waste management & housekeeping
					  • Provide clearly labelled waste streams (general waste, recyclables, scrap metal, timber, concrete, green waste, hazardous waste).
					  • Keep work areas tidy and clear of off-cuts and debris; remove waste at least daily.
					  • Prevent debris and off-cuts from entering stormwater drains, pits,		

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					waterways or neighbouring properties. • Use licensed waste contractors and keep records of waste removed (dockets, weighbridge tickets where available). • Soil & habitat protection • Confine works to designated areas to avoid unnecessary vegetation damage and soil compaction. • Protect tree trunks and root zones with fencing or bollards where trees are to be retained. • Do not store materials or park plant within tree protection zones. • General environmental management • Include environmental controls in pre-start talks and site inductions. • Complete EWMS / environmental checklists as per Tallan's HSEQ requirements in Loop.		
Using Fillers and Putties	General environmental risk including dust, waste, noise, soil disturbance	Moderate	Possible	13	• Dust control • Use water carts, misting or fine spray hoses for dust-generating activities (cutting, excavation,	Site Supervisor during regular site inspections	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					demolition, sweeping external areas). • Use dust extraction or on-tool vacuum systems on saws, grinders, sanders and other high-dust tools. • Avoid dry sweeping where possible; use H-class vacuum or damp sweeping methods. • Cover or bind dusty stockpiles and cover truck loads leaving site. • Schedule high-dust activities away from strong winds where practicable. • Noise control • Maintain plant and equipment to minimise noisy operation (exhausts, guards, bearings). • Position stationary plant (generators, compressors, pumps) as far as practicable from neighbouring sensitive receivers. • Use local acoustic screens or barriers around very noisy stationary plant where needed. • Comply with approved working hours and local noise conditions; avoid high-impact		

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					works early morning/late evening. • Waste management & housekeeping • Provide clearly labelled waste streams (general waste, recyclables, scrap metal, timber, concrete, green waste, hazardous waste). • Keep work areas tidy and clear of off-cuts and debris; remove waste at least daily. • Prevent debris and off-cuts from entering stormwater drains, pits, waterways or neighbouring properties. • Use licensed waste contractors and keep records of waste removed (dockets, weighbridge tickets where available). • Soil & habitat protection • Confine works to designated areas to avoid unnecessary vegetation damage and soil compaction. • Protect tree trunks and root zones with fencing or bollards where trees are to be retained.		

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Do not store materials or park plant within tree protection zones. • General environmental management • Include environmental controls in pre-start talks and site inductions. • Complete EWMS / environmental checklists as per Tallan's HSEQ requirements in Loop.		
Application of Liquid Nails	General environmental risk including dust, waste, noise, soil disturbance	Moderate	Possible	13	• Dust control • Use water carts, misting or fine spray hoses for dust-generating activities (cutting, excavation, demolition, sweeping external areas). • Use dust extraction or on-tool vacuum systems on saws, grinders, sanders and other high-dust tools. • Avoid dry sweeping where possible; use H-class vacuum or damp sweeping methods. • Cover or bind dusty stockpiles and cover truck loads leaving site. • Schedule high-dust activities away from strong winds where practicable.	Site Supervisor during regular site inspections	L6

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			

					• Noise control
					  • Maintain plant and equipment to minimise noisy operation (exhausts, guards, bearings).
					  • Position stationary plant (generators, compressors, pumps) as far as practicable from neighbouring sensitive receivers.
					  • Use local acoustic screens or barriers around very noisy stationary plant where needed.
					  • Comply with approved working hours and local noise conditions; avoid high-impact works early morning/late evening.
					• Waste management & housekeeping
					  • Provide clearly labelled waste streams (general waste, recyclables, scrap metal, timber, concrete, green waste, hazardous waste).
					  • Keep work areas tidy and clear of off-cuts and debris; remove waste at least daily.
					  • Prevent debris and off-cuts from entering stormwater drains, pits,		

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					waterways or neighbouring properties. • Use licensed waste contractors and keep records of waste removed (dockets, weighbridge tickets where available). • Soil & habitat protection • Confine works to designated areas to avoid unnecessary vegetation damage and soil compaction. • Protect tree trunks and root zones with fencing or bollards where trees are to be retained. • Do not store materials or park plant within tree protection zones. • General environmental management • Include environmental controls in pre-start talks and site inductions. • Complete EWMS / environmental checklists as per Tallan's HSEQ requirements in Loop.		
Mixing Sand and Cement	Concrete washout risks, alkaline runoff, dust emissions, sediment contamination	Moderate	Possible	M13	• Provide a designated lined concrete washout pit or container (e.g. geo-fabric-lined bund, skip bin with liner) for all concrete washout and equipment cleaning.	Site Supervisor during regular site inspections	L6

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Do not allow concrete slurry, washwater or residue to enter soil, stormwater drains, gullies or waterways. • Direct pump line and chute washout into the lined washout area. • Allow washwater to settle; once hardened, remove concrete waste and dispose of as solid construction waste via licensed facility. • Manage pH if required under project conditions before any controlled discharge. • Keep stockpiles of sand and aggregates away from drainage lines and protect them from runoff. • Minimise on-site mixing where possible by using pre-mixed products and batching off-site. • Use water suppression during cutting, grinding or chasing of concrete to reduce airborne dust; capture resulting slurry. • Inspect washout areas and surrounding ground after concreting activities; repair any breaches in linings or bunds immediately.		

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
Cutting of tiles with grinder or other power tile cutting saw.	Airborne dust (silica), debris pollution, waste generation	Moderate	Possible	M13	• Use water-suppressed saws or grinders where practicable to minimise respirable crystalline silica (RCS) and nuisance dust. • Fit saws, grinders, sanders and drills with H-class or M-class dust extraction units with HEPA filtration. • Enclose or partially enclose cutting areas where practicable to contain dust and debris. • Avoid cutting or grinding in open windy conditions near sensitive receptors (schools, hospitals, neighbouring residences). • Use local screening (shade cloth hoardings, solid barriers) to prevent debris leaving the site boundary. • Collect slurry and cuttings; do not allow slurry to enter stormwater drains or soak directly into soil. • Segregate and dispose of dust-contaminated waste, broken tiles, masonry and concrete via licensed facilities. • Clean surfaces using H-class vacuum and damp wiping; avoid dry sweeping of fine dust.	Site Supervisor during regular site inspections	L6

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
Use of Hazardous Substances and Chemicals	Chemical spill risk, hazardous runoff, groundwater contamination	Moderate	Possible	M13	• Maintain a chemical and fuel register and ensure current SDS are available on site. • Store all fuels, oils, paints, solvents and hazardous chemicals in bunded, weather-protected areas away from drains and waterways. • Use drip trays or portable bunds under generators, pumps and other stationary plant. • Provide spill kits (absorbent pads, booms, neutralising agents, disposal bags) at chemical storage areas, refuelling locations and near high-risk activities. • Train all relevant workers in spill prevention and spill response, including notification and clean-up procedures. • Refuel only in designated locations with appropriate containment; never refuel within 10 m of stormwater drains or waterways. • Immediately contain spills using absorbents and booms; recover contaminated material and dispose of as regulated waste in	Site Supervisor during regular site inspections	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					accordance with EPA / POEO requirements. • Prohibit hosing of spills into drains or onto soil; contaminated soil must be excavated and managed appropriately. • Check bund capacities and integrity regularly; repair cracks and remove accumulated rainwater in accordance with environmental requirements.		
Painting work	VOC emissions, chemical contamination of air/soil, improper disposal impacts	Moderate	Possible	M13	• Select low-VOC or water-based paints, sealants and adhesives where practicable. • Use drop sheets and trays to prevent paint, solvents and other liquids contacting soil or hardstand. • Prevent washing of brushes, rollers and paint equipment in areas that discharge directly to stormwater – use designated wash-up points connected to sewer or contained systems. • Collect solvent residues, waste paint, contaminated rags and empty containers and treat as hazardous/regulated waste, disposing of via licensed contractor.	Site Supervisor during regular site inspections	L6

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Keep lids on containers when not in use to minimise evaporation and VOC emissions. • Avoid spray painting in windy conditions or close to boundaries; use shields or curtains to contain overspray. • Do not discharge paint or solvent waste, even heavily diluted, into stormwater drains, gutters or onto bare soil. • Keep appropriate fire-safe bunded storage for flammable paints and solvents in accordance with AS 1940 / AS/NZS 3833 listing in your EWMS.		

General Lanscaping	General environmental risk including dust, waste, noise, soil disturbance	Moderate	Possible	M13	• Dust control
					  • Use water carts, misting or fine spray hoses for dust-generating activities (cutting, excavation, demolition, sweeping external areas).
					  • Use dust extraction or on-tool vacuum systems on saws, grinders, sanders and other high-dust tools.
					  • Avoid dry sweeping where possible; use H-class vacuum or damp sweeping methods.
						Supervisor in Monthly Site Inspection	L6

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Cover or bind dusty stockpiles and cover truck loads leaving site. • Schedule high-dust activities away from strong winds where practicable. • Noise control • Maintain plant and equipment to minimise noisy operation (exhausts, guards, bearings). • Position stationary plant (generators, compressors, pumps) as far as practicable from neighbouring sensitive receivers. • Use local acoustic screens or barriers around very noisy stationary plant where needed. • Comply with approved working hours and local noise conditions; avoid high-impact works early morning/late evening. • Waste management & housekeeping • Provide clearly labelled waste streams (general waste, recyclables, scrap metal, timber, concrete, green waste, hazardous waste).		

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Keep work areas tidy and clear of off-cuts and debris; remove waste at least daily. • Prevent debris and off-cuts from entering stormwater drains, pits, waterways or neighbouring properties. • Use licensed waste contractors and keep records of waste removed (dockets, weighbridge tickets where available). • Soil & habitat protection • Confine works to designated areas to avoid unnecessary vegetation damage and soil compaction. • Protect tree trunks and root zones with fencing or bollards where trees are to be retained. • Do not store materials or park plant within tree protection zones. • General environmental management • Include environmental controls in pre-start talks and site inductions. • Complete EWMS / environmental checklists as per Tallan's HSEQ requirements in Loop.		

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
Using Fuel Powered Equipment Operation (blowers, whipper snippers, hedgers etc.)	Chemical spill risk, hazardous runoff, groundwater contamination	Moderate	Possible	M13	• Maintain a chemical and fuel register and ensure current SDS are available on site. • Store all fuels, oils, paints, solvents and hazardous chemicals in bunded, weather-protected areas away from drains and waterways. • Use drip trays or portable bunds under generators, pumps and other stationary plant. • Provide spill kits (absorbent pads, booms, neutralising agents, disposal bags) at chemical storage areas, refuelling locations and near high-risk activities. • Train all relevant workers in spill prevention and spill response, including notification and clean-up procedures. • Refuel only in designated locations with appropriate containment; never refuel within 10 m of stormwater drains or waterways. • Immediately contain spills using absorbents and booms; recover contaminated material and dispose of as regulated waste in	Operator	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					accordance with EPA / POEO requirements. • Prohibit hosing of spills into drains or onto soil; contaminated soil must be excavated and managed appropriately. • Check bund capacities and integrity regularly; repair cracks and remove accumulated rainwater in accordance with environmental requirements.		
Plant Movement on Site	Soil disturbance, sediment runoff, stormwater pollution, vegetation disturbance	Moderate	Possible	M13	• Install and maintain erosion and sediment controls (e.g. silt fences, sediment socks, diversion drains, check dams) before starting earthworks. • Limit disturbance to clearly defined work zones; fence off or flag "no-go" areas, particularly around sensitive vegetation and waterways. • Stabilise exposed soil (e.g. mulch, temporary turf, geo-fabric) as soon as practicable. • Locate stockpiles away from drains, gullies and watercourses and protect them with sediment controls. • Protect all stormwater inlets with approved inlet filters or geotextile	Supervisor All Workers Daily	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					and inspect before and after rain events. • Sequence works to avoid large areas of bare ground being open at one time. • Avoid working during heavy rainfall where practicable and check controls after any rain event. • Do not discharge turbid water off site without treatment and approval (e.g. settlement, filtration, pH adjustment where required). • Record installation and inspection of erosion and sediment controls in site checklists / Loop EWMS inspections.		

Install Plasterboard	General environmental risk including dust, waste, noise, soil disturbance	Moderate	Possible	M13	• Dust control
					  • Use water carts, misting or fine spray hoses for dust-generating activities (cutting, excavation, demolition, sweeping external areas).
					  • Use dust extraction or on-tool vacuum systems on saws, grinders, sanders and other high-dust tools.
					  • Avoid dry sweeping where possible; use H-class vacuum or damp sweeping methods.
						Supervisor in Site Inspection	L6

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Cover or bind dusty stockpiles and cover truck loads leaving site. • Schedule high-dust activities away from strong winds where practicable. • Noise control • Maintain plant and equipment to minimise noisy operation (exhausts, guards, bearings). • Position stationary plant (generators, compressors, pumps) as far as practicable from neighbouring sensitive receivers. • Use local acoustic screens or barriers around very noisy stationary plant where needed. • Comply with approved working hours and local noise conditions; avoid high-impact works early morning/late evening. • Waste management & housekeeping • Provide clearly labelled waste streams (general waste, recyclables, scrap metal, timber, concrete, green waste, hazardous waste).		

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Keep work areas tidy and clear of off-cuts and debris; remove waste at least daily. • Prevent debris and off-cuts from entering stormwater drains, pits, waterways or neighbouring properties. • Use licensed waste contractors and keep records of waste removed (dockets, weighbridge tickets where available). • Soil & habitat protection • Confine works to designated areas to avoid unnecessary vegetation damage and soil compaction. • Protect tree trunks and root zones with fencing or bollards where trees are to be retained. • Do not store materials or park plant within tree protection zones. • General environmental management • Include environmental controls in pre-start talks and site inductions. • Complete EWMS / environmental checklists as per Tallan's HSEQ requirements in Loop.		

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			

Install insulation	General environmental risk including dust, waste, noise, soil disturbance	Moderate	Possible	M13	• Dust control
					  • Use water carts, misting or fine spray hoses for dust-generating activities (cutting, excavation, demolition, sweeping external areas).
					  • Use dust extraction or on-tool vacuum systems on saws, grinders, sanders and other high-dust tools.
					  • Avoid dry sweeping where possible; use H-class vacuum or damp sweeping methods.
					  • Cover or bind dusty stockpiles and cover truck loads leaving site.
					  • Schedule high-dust activities away from strong winds where practicable.
					• Noise control
					  • Maintain plant and equipment to minimise noisy operation (exhausts, guards, bearings).
					  • Position stationary plant (generators, compressors, pumps) as far as practicable from neighbouring sensitive receivers.
						Supervisor in Site Inspection	L6

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Use local acoustic screens or barriers around very noisy stationary plant where needed. • Comply with approved working hours and local noise conditions; avoid high-impact works early morning/late evening. • Waste management & housekeeping • Provide clearly labelled waste streams (general waste, recyclables, scrap metal, timber, concrete, green waste, hazardous waste). • Keep work areas tidy and clear of off-cuts and debris; remove waste at least daily. • Prevent debris and off-cuts from entering stormwater drains, pits, waterways or neighbouring properties. • Use licensed waste contractors and keep records of waste removed (dockets, weighbridge tickets where available). • Soil & habitat protection • Confine works to designated areas to avoid unnecessary		

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					vegetation damage and soil compaction. • Protect tree trunks and root zones with fencing or bollards where trees are to be retained. • Do not store materials or park plant within tree protection zones. • General environmental management • Include environmental controls in pre-start talks and site inductions. Complete EWMS / environmental checklists as per Tallan's HSEQ requirements in Loop.		
Installing Bricks and Blocks	General environmental risk including dust, waste, noise, soil disturbance	Moderate	Possible	M13	• Dust control • Use water carts, misting or fine spray hoses for dust-generating activities (cutting, excavation, demolition, sweeping external areas). • Use dust extraction or on-tool vacuum systems on saws, grinders, sanders and other high-dust tools. • Avoid dry sweeping where possible; use H-class vacuum or damp sweeping methods.	Supervisor in Site Inspection	L6

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Cover or bind dusty stockpiles and cover truck loads leaving site. • Schedule high-dust activities away from strong winds where practicable. • Noise control • Maintain plant and equipment to minimise noisy operation (exhausts, guards, bearings). • Position stationary plant (generators, compressors, pumps) as far as practicable from neighbouring sensitive receivers. • Use local acoustic screens or barriers around very noisy stationary plant where needed. • Comply with approved working hours and local noise conditions; avoid high-impact works early morning/late evening. • Waste management & housekeeping • Provide clearly labelled waste streams (general waste, recyclables, scrap metal, timber, concrete, green waste, hazardous waste).		

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Keep work areas tidy and clear of off-cuts and debris; remove waste at least daily. • Prevent debris and off-cuts from entering stormwater drains, pits, waterways or neighbouring properties. • Use licensed waste contractors and keep records of waste removed (dockets, weighbridge tickets where available). • Soil & habitat protection • Confine works to designated areas to avoid unnecessary vegetation damage and soil compaction. • Protect tree trunks and root zones with fencing or bollards where trees are to be retained. • Do not store materials or park plant within tree protection zones. • General environmental management • Include environmental controls in pre-start talks and site inductions. • Complete EWMS / environmental checklists as per Tallan's HSEQ requirements in Loop.		

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
Receiving concrete by mixer truck	Concrete washout risks, alkaline runoff, dust emissions, sediment contamination	Moderate	Possible	M13	• Provide a designated lined concrete washout pit or container (e.g. geo-fabric-lined bund, skip bin with liner) for all concrete washout and equipment cleaning. • Do not allow concrete slurry, washwater or residue to enter soil, stormwater drains, gullies or waterways. • Direct pump line and chute washout into the lined washout area. • Allow washwater to settle; once hardened, remove concrete waste and dispose of as solid construction waste via licensed facility. • Manage pH if required under project conditions before any controlled discharge. • Keep stockpiles of sand and aggregates away from drainage lines and protect them from runoff. • Minimise on-site mixing where possible by using pre-mixed products and batching off-site. • Use water suppression during cutting, grinding or chasing of concrete to reduce airborne dust; capture resulting slurry.	Supervisor in Site Inspection	L6

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Inspect washout areas and surrounding ground after concreting activities; repair any breaches in linings or bunds immediately.		
Pouring Concrete	Concrete washout risks, alkaline runoff, dust emissions, sediment contamination	Moderate	Possible	M13	• Provide a designated lined concrete washout pit or container (e.g. geo-fabric-lined bund, skip bin with liner) for all concrete washout and equipment cleaning. • Do not allow concrete slurry, washwater or residue to enter soil, stormwater drains, gullies or waterways. • Direct pump line and chute washout into the lined washout area. • Allow washwater to settle; once hardened, remove concrete waste and dispose of as solid construction waste via licensed facility. • Manage pH if required under project conditions before any controlled discharge. • Keep stockpiles of sand and aggregates away from drainage lines and protect them from runoff. • Minimise on-site mixing where possible by using pre-mixed products and batching off-site.	Supervisor in Site Inspection	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Use water suppression during cutting, grinding or chasing of concrete to reduce airborne dust; capture resulting slurry. • Inspect washout areas and surrounding ground after concreting activities; repair any breaches in linings or bunds immediately.		
Pumping concrete	Concrete washout risks, alkaline runoff, dust emissions, sediment contamination	Moderate	Possible	M13	• Provide a designated lined concrete washout pit or container (e.g. geo-fabric-lined bund, skip bin with liner) for all concrete washout and equipment cleaning. • Do not allow concrete slurry, washwater or residue to enter soil, stormwater drains, gullies or waterways. • Direct pump line and chute washout into the lined washout area. • Allow washwater to settle; once hardened, remove concrete waste and dispose of as solid construction waste via licensed facility. • Manage pH if required under project conditions before any controlled discharge.	Supervisor in Site Inspection	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Keep stockpiles of sand and aggregates away from drainage lines and protect them from runoff. • Minimise on-site mixing where possible by using pre-mixed products and batching off-site. • Use water suppression during cutting, grinding or chasing of concrete to reduce airborne dust; capture resulting slurry. • Inspect washout areas and surrounding ground after concreting activities; repair any breaches in linings or bunds immediately.		
Use of portable concrete mixer	Concrete washout risks, alkaline runoff, dust emissions, sediment contamination	Moderate	Possible	M13	• Provide a designated lined concrete washout pit or container (e.g. geo-fabric-lined bund, skip bin with liner) for all concrete washout and equipment cleaning. • Do not allow concrete slurry, washwater or residue to enter soil, stormwater drains, gullies or waterways. • Direct pump line and chute washout into the lined washout area. • Allow washwater to settle; once hardened, remove concrete waste	Supervisor in Site Inspection	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					and dispose of as solid construction waste via licensed facility. • Manage pH if required under project conditions before any controlled discharge. • Keep stockpiles of sand and aggregates away from drainage lines and protect them from runoff. • Minimise on-site mixing where possible by using pre-mixed products and batching off-site. • Use water suppression during cutting, grinding or chasing of concrete to reduce airborne dust; capture resulting slurry. • Inspect washout areas and surrounding ground after concreting activities; repair any breaches in linings or bunds immediately.		
Mixing cement render by hand	Concrete washout risks, alkaline runoff, dust emissions, sediment contamination	Moderate	Possible	M13	• Provide a designated lined concrete washout pit or container (e.g. geo-fabric-lined bund, skip bin with liner) for all concrete washout and equipment cleaning. • Do not allow concrete slurry, washwater or residue to enter soil, stormwater drains, gullies or waterways.	Supervisor in Site Inspection	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Direct pump line and chute washout into the lined washout area. • Allow washwater to settle; once hardened, remove concrete waste and dispose of as solid construction waste via licensed facility. • Manage pH if required under project conditions before any controlled discharge. • Keep stockpiles of sand and aggregates away from drainage lines and protect them from runoff. • Minimise on-site mixing where possible by using pre-mixed products and batching off-site. • Use water suppression during cutting, grinding or chasing of concrete to reduce airborne dust; capture resulting slurry. • Inspect washout areas and surrounding ground after concreting activities; repair any breaches in linings or bunds immediately.		
Concrete handling	Concrete washout risks, alkaline runoff, dust emissions, sediment contamination	Moderate	Possible	M13	• Provide a designated lined concrete washout pit or container (e.g. geo-fabric-lined bund, skip bin with liner) for all concrete washout and equipment cleaning.	Supervisor in Site Inspection	L6

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Do not allow concrete slurry, washwater or residue to enter soil, stormwater drains, gullies or waterways. • Direct pump line and chute washout into the lined washout area. • Allow washwater to settle; once hardened, remove concrete waste and dispose of as solid construction waste via licensed facility. • Manage pH if required under project conditions before any controlled discharge. • Keep stockpiles of sand and aggregates away from drainage lines and protect them from runoff. • Minimise on-site mixing where possible by using pre-mixed products and batching off-site. • Use water suppression during cutting, grinding or chasing of concrete to reduce airborne dust; capture resulting slurry. • Inspect washout areas and surrounding ground after concreting activities; repair any breaches in linings or bunds immediately.		

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
Sealing concrete/ curing	Concrete washout risks, alkaline runoff, dust emissions, sediment contamination	Moderate	Possible	M13	• Provide a designated lined concrete washout pit or container (e.g. geo-fabric-lined bund, skip bin with liner) for all concrete washout and equipment cleaning. • Do not allow concrete slurry, washwater or residue to enter soil, stormwater drains, gullies or waterways. • Direct pump line and chute washout into the lined washout area. • Allow washwater to settle; once hardened, remove concrete waste and dispose of as solid construction waste via licensed facility. • Manage pH if required under project conditions before any controlled discharge. • Keep stockpiles of sand and aggregates away from drainage lines and protect them from runoff. • Minimise on-site mixing where possible by using pre-mixed products and batching off-site. • Use water suppression during cutting, grinding or chasing of concrete to reduce airborne dust; capture resulting slurry.	Supervisor in Site Inspection	L6

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Inspect washout areas and surrounding ground after concreting activities; repair any breaches in linings or bunds immediately.		

Clean up after shift	General environmental risk including dust, waste, noise, soil disturbance	Moderate	Possible	M13	• Dust control
					  • Use water carts, misting or fine spray hoses for dust-generating activities (cutting, excavation, demolition, sweeping external areas).
					  • Use dust extraction or on-tool vacuum systems on saws, grinders, sanders and other high-dust tools.
					  • Avoid dry sweeping where possible; use H-class vacuum or damp sweeping methods.
					  • Cover or bind dusty stockpiles and cover truck loads leaving site.
					  • Schedule high-dust activities away from strong winds where practicable.
					• Noise control
					  • Maintain plant and equipment to minimise noisy operation (exhausts, guards, bearings).
					  • Position stationary plant (generators, compressors, pumps) as far as practicable
						Supervisor and WHSE Manager in regular site inspections	L6

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					from neighbouring sensitive receivers. • Use local acoustic screens or barriers around very noisy stationary plant where needed. • Comply with approved working hours and local noise conditions; avoid high-impact works early morning/late evening. • Waste management & housekeeping • Provide clearly labelled waste streams (general waste, recyclables, scrap metal, timber, concrete, green waste, hazardous waste). • Keep work areas tidy and clear of off-cuts and debris; remove waste at least daily. • Prevent debris and off-cuts from entering stormwater drains, pits, waterways or neighbouring properties. • Use licensed waste contractors and keep records of waste removed (dockets, weighbridge tickets where available). • Soil & habitat protection		

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

A	B	C			D	E	F
PROCEDURE / ACTIVITY (Break the job down into steps)	**POTENTIAL HAZARDS (What can go wrong)**	**RISK ASSESSMENT (Refer to risk matrix at end of document)**			**CONTROL MEASURE (Control Measure to be in place in order to manage potential hazards)**	**MONITOR & REVIEW (Who, how and when)**	**Residual Risk**
		Consequence	**Likelihood**	**Rating (1 – 25)**			
					• Confine works to designated areas to avoid unnecessary vegetation damage and soil compaction. • Protect tree trunks and root zones with fencing or bollards where trees are to be retained. • Do not store materials or park plant within tree protection zones. • General environmental management • Include environmental controls in pre-start talks and site inductions. • Complete EWMS / environmental checklists as per Tallan's HSEQ requirements in Loop.		

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

INSTRUCTIONS TO COMPLETE THE WORK METHOD STATEMENT

PREPARATION OF EWMS
Select the relevant persons to develop the EWMS
Ensure all sections are completed
Column A – Identify, in working sequence, each activity step. (In consultation with workers involved)
Column B – Identify the Hazards associated with each step.
Column C – Refer to Risk Assessment Tables to determine Likelihood, Consequences and Risk Rating
Column D – Determine appropriate Control Measures in accordance with the 'Hierarchy of Controls'.
Column E – Allocate the responsibility. (e.g. - By supervisor daily)
Submit the EWMS to the relevant person/s for approval.
Relevant person/s to evaluate the EWMS for approval. Any changes required must be made before approval. Any changes after approval will be indicated by a Revision Number and must be re-submitted for approval.
Conduct a specific training meeting or toolbox talk to train all persons involved in the EWMS activities and have them sign the Training/Toolbox Record. If the EWMS is revised (Rev. No.), then repeat this process.

RISK MATRIX

A hazard is anything that has the potential to cause harm or damage.

	CONSEQUENCE				
LIKELIHOOD	**Insignificant**	**Minor**	**Moderate**	**Major**	**Critical**
Almost Certain	M (11)	H (16)	H (20)	VH (23)	VH (25)
Likely	M (7)	M (12)	H (17)	H (21)	VH (24)
Possible	L (4)	M (8)	M (13)	H (18)	H (22)
Unlikely	L (2)	L (5)	M (9)	M (14)	H (19)
Rare	L (1)	L (3)	L (6)	M (10)	H (15)
H18 - VH25	Unacceptable: Immediate action required to manage the risk.				
M13 - H17	Issue: Action required to manage the risk.				

HIERARCHY OF CONTROL
Elimination
Substitution
Engineering
Administration
PPE

ENVIRONMENTAL WORK METHOD STATEMENT
GENERAL CONSTRUCTION

L5 - M12	Monitor:	Action advisable if cost beneficial.
L1 - L4	Tolerable:	Manage using routine procedures.

TOOLBOX / TRAINING RECORD – I have read and understood EWMS -				
Toolbox/Training Conducted by:	**Name:**		**Signature:**	

We, the undersigned, confirm that this Environmental Work Method Statement has been explained to us and that we understand its contents. We are able to comply with these requirements.

We also confirm that we understand its purpose of reducing, as far as possible, the chance of incidents occurring. We will report any non-compliance of this EWMS to a relevant person/supervisor.

ALL PERSONS INVOLVED IN THE WORKS MUST COMPLETE THE FOLLOWING, PRIOR TO START OF WORKS.

Name	Roles	Signature

Name	**Roles**	**Signature**

ENVIRONMENTAL WORK METHOD STATEMENT GENERAL CONSTRUCTION