
egoShield with 4 push-buttons and OLED display



The TimeLapse library has the following functionality:

• <u>Idle state</u>

- o Press **FWD** or **REV** to manually move 1mm in either direction
- o Press and hold **FWD** or **REV** to move continuous until releasing
- Press **RECORD** to enter <u>TimeLapse state</u>
- o Press and hold **STOP** to invert PID mode (either PID ON or PID OFF)

• <u>TimeLapse state</u>

- o Press **FWD** or **REV** to Change the value in the menu
- o Press **RECORD** to Move to the next menu item
- o After reaching the final item, press **PLAY** to start TimeLapse
- o Press **STOP** to exit *TimeLapse state*, and return to *Idle state*