AAE 538: Air-Breathing Propulsion

Lecture 28: Combustion in Supersonic Propulsion

Prof. Carson D. Slabaugh

Purdue University
School of Aeronautics and Astronautics
Maurice J. Zucrow Laboratories





PURDUE AERONAUTICS & ASTRONAUTICS

Basic Injector Design

- Consider the case of two uniform, parallel flows of air and gaseous fuel from splitter plate into a constant-area duct.
 - The initial velocities are u_1 and u_2 .

0

Assume:

- Pressure and density are equal and constant
- Boundary layers can be ignored.



- If the two velocities differ, a _____ is generated at the interface of the two streams
- Non-dimensional local velocities are typically normalized by an average reference velocity;
- Lateral transport is _____
 - Momentum
 - Thermal, and mechanical, energy
 - Mass (molecules); for example, air and fuel.

- If the two velocities are equal, no shear stress exists between the two streams and they simply co-flow downstream at the convective velocity.
 - Even though there is no lateral transport of momentum or vorticity, there is still at the interface due to molecular diffusion.



- The rate of molecular diffusion is given by Fick's Law:
 - The time rate of change of molecular transport is proportional to the product of the interfacial area and the local concentration gradient.

o Fick's law can be written for the diffusion of air into the fuel as:

$$j_A = -D_{FA} \frac{\partial C_A}{\partial y}$$

- where j_A is the new molar diffusive flux of air in the y direction.
- *C*_A is the concentration of air
- $\frac{\partial C_A}{\partial v}$ is the lateral concentration gradient



 We relate the air mole-fraction to the concentrations of fuel and air by some simple accounting:

• As a result, it can be seen that the mixing-layer thickness (δ_m) grows with the downstream distance (x) approximately as:

While the spatial profile of the air mole fraction varies in the x and y directions as approximately:



- The mole fraction profile for $Y_A(x, y)$ is shown.
- The greatest concentration gradient, and therefore, the greatest diffusive flux, occurs
- Once the mixing layer reaches the wall, there is no pure substance anymore,



• We can relate the total distance required for the mixing layer to reach the walls to the mixing layer thickness evolution by setting $\delta_m = 2b$.

• We need to minimize L_m . How?

 \circ





