```
function P = calcStaticPressure(M, gamma, P_0)
%
P = P_0 / ((1 + (((gamma - 1) / 2) * M^2))^(gamma / (gamma - 1)));
end
```

Published with MATLAB® R2015a