





























| Battery Connector | | |
|-------------------|-----|------|
| J6 | | |
| B2B-PH-SM4-TB | | |
| | 2 1 | VBAT |
| | | GND |

| Table 7-2. EN1/EN2 Settings | | | |
|-----------------------------|-----|--|--|
| EN2 | EN1 | MAXIMUM INPUT CURRENT INTO IN PIN | |
| 0 | 0 | 100 mA. USB100 mode | |
| 0 | 1 | 500 mA. USB500 mode | |
| 1 | 0 | Set by an external resistor from ILIM to VSS | |
| 1 | 1 | Standby (USB suspend mode) | |

Initial in USB100 (charging disabled) After Enumeration USB500 (charging enabled)

 $R_ISET = K_ISET/I_CHG$ 890/1A = 890 Ohm

Not CE — high (disable charging) — low (enable charging)