



## Sentry Floor Mount Computer Station - SFMCS **Assembly Instructions**



How can we improve our assembly instructions?  
Your comments and suggestions are important to us.  
Please e-mail us at: [support@versatables.com](mailto:support@versatables.com).



**VersaTables.com**  
14105 Avalon Blvd.  
Los Angeles, CA 90061



Lifetime Warranty



Quantity Discounts



Assembled in USA




Fast Shipping

### Support:

Local: 310-353-7100  
Toll Free: 888-929-0322  
Fax: 310-353-7109  
[Support@VersaTables.com](mailto:Support@VersaTables.com)

Main Pole  Qty:1	4mm & 8mm Allen Wrench  Qty:2	3" X 3/8 Concrete Anchor  Qty:4	3" X 3/8 Head Hex Lag  Qty:4	4" Plastic Insert  Qty:1
Base  Qty:1	Keyboard Bracket  Qty:1		Zip Tie & Curly Tie  Qty:5	
Keyboard Platform  Qty:1	LCD Holder  Qty:1	8mm Machine Screw  Qty:4		
1/4 - 20 Phillips Head Bolt  Qty:4	3/8 - 1/6 x 1" Socket Head Bolt  Qty:2	CPU holder  Qty:1		
Clamp Bushing  Qty:2	CPU Holder Mount Bracket  Qty:1	Clamp  Qty:1	1" 7/8 Velcro Pads 1 Velcro Loops 1 Velcro Hooks  Qty:2	
Additional Tools Required		Slotted Screw Driver (Optional)  Qty:1	3/4" Wrench  Qty:1	



Step

1

Attach Base to floor then slide Main Pole onto it and secure T-Knob.


**NOTE:** Use Base to mark hole pattern on floor first, then attach required hardware..

SFMCS

Attach Base to floor



## CPU holder Adjustability



VersaTables.com  
14105 Avalon Blvd.  
Los Angeles, CA 90061



Lifetime Warranty



Quantity Discounts



Assembled in USA



Fast Shipping

### Support:

Local: 310-353-7100

Toll Free: 888-929-0322

Fax: 310-353-7109

Support@VersaTables.com

## Step 2

Attach mount bracket to CPU holder

Use (2) 20mm Furniture Bolts.

20mm Furniture  
Bolt

**NOTE:** If necessary, loosen the two stoppers and lower bottom piece to expose the mounting holes



## Step 3

Attach CPU Holder At the desired Height.

Use (1) Clamps and (2) 3/8 1/6 x 1" Socket Head Bolts.

Clamp

3/8 1/6 x 1"  
Socket Head Bolt

Clamp Bushing



**VersaTables.com**  
14105 Avalon Blvd.  
Los Angeles, CA 90061

**Support:**

Local: 310-353-7100  
Toll Free: 888-929-0322  
Fax: 310-353-7109  
[Support@VersaTables.com](mailto:Support@VersaTables.com)

## Step 4

Attach Velcro Pads to both your CPU and CPU Holder.

Velcro Pads



Qty:2

Once in place, adjust Holder and tighten  
Thumb Nuts to keep CPU secure.



VersaTables.com  
14105 Avalon Blvd.  
Los Angeles, CA 90061



Lifetime Warranty



Quantity Discounts



Assembled in USA



Fast Shipping

**Support:**

Local: 310-353-7100  
Toll Free: 888-929-0322  
Fax: 310-353-7109  
[Support@VersaTables.com](mailto:Support@VersaTables.com)

## Step 6

Attach Keyboard Bracket using one Socket Head Bolt and one T-Knob.

3/8 - 16 x 1"  
Socket Head Bolt


Qty:1

T Knob



Qty:1

T knob

3/8 - 16 x 1"  
Socket Head Bolt

## Attach Keyboard Bracket




## Step 7

Attach Keyboard Platform to Keyboard Bracket using four 1/4-20 Phillips Head Bolts.

1/4-20 Phillips  
Head Bolt

Qty:4

1/4-20 Phillips  
Head Bolt

## Attach Keyboard Platform.



VersaTables.com  
14105 Avalon Blvd.  
Los Angeles, CA 90061



Lifetime Warranty



Quantity Discounts



Assembled in USA



Fast Shipping

## Support:

Local: 310-353-7100  
Toll Free: 888-929-0322  
Fax: 310-353-7109  
Support@VersaTables.com

## Step 8

- Slide Monitor Arm onto Upright Extension and tighten T-Knob.




Attach LCD Holder.



## Step 9

- Attach your monitor to the LCD holder using four 8mm Phillips Machine Screws.



Attach Monitor.



How can we improve our assembly instructions?  
Your comments and suggestions are important to us.  
Please e-mail us at: support@versatables.com.



VersaTables.com  
14105 Avalon Blvd.  
Los Angeles, CA 90061



Lifetime Warranty



Quantity Discounts



Assembled in USA



Fast Shipping

**Support:**

Local: 310-353-7100  
Toll Free: 888-929-0322  
Fax: 310-353-7109  
Support@VersaTables.com