
31	Battery -		
30	Battery +		
X1	Data link connector (DLC)		
EP3	Earth point 3		
EP4	Earth point 4		
EP5	Earth point 5		
EP6	Earth point 6		
F	Fuse		
X28-II	Fuse box/relay plate, engine bay 1		
X28-I	Fuse box/relay plate, fascia 1		
X28-III	Fuse box/relay plate, fascia 2		
15	Ignition switch - ignition ON		
A11	Multifunction control module		

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	


NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.




Manufacturer: Peugeot Engine code: XU10J4R (RFV) Tuned for: R-Cat

**Model:** 406 2,0 Output: 97 (132) 5500 **Year:** 1995-02

(c) Autodata Limited 2013 . 8/30/2020






Manufacturer: Peugeot Engine code: XU10J4R (RFV) Tuned for: R-Cat **Model:** 406 2,0 **Output:** 97 (132) 5500

Year: 1995-02

(c) Autodata Limited 2013 . 8/30/2020

V9.200- /Autodata



300184

Manufacturer: Peugeot Engine code: XU10J4R (RFV) Tuned for: R-Cat

**Model:** 406 2,0 Output: 97 (132) 5500

**Year:** 1995-02

(c) Autodata Limited 2013 . 8/30/2020

/Autodata