




## STM32 Nucleo-64 Board






### STM32 Nucleo-64 Board - Block Diagram & Top View




STM32 Nucleo-64 hardware block diagram







# STM32 Nucleo-64 Board - Pin Mapping



### Fitur STM32 Nucleo-64 Board

- STM32 microcontroller (STM32F401RET6) in LQFP64 package.
- Three LEDs: USB communication (LD1), user LED (LD2), power LED (LD3).
- Two push-buttons: USER and RESET.
- Two types of extension resources: Arduino™ Uno V3 connectivity and ST morpho extension pin headers for full access to all STM32 I/Os.
- Flexible board power supply: USB VBUS or external source (3.3V, 5V, 7 12V) and Power management access point.
- On-board ST-LINK/V2-1 debugger and programmer with SWD connector Selection-mode switch to use the kit as
  a standalone ST-LINK/V2-1
- USB re-enumeration capability. Three different interfaces supported on USB: Virtual COM port, Mass storage,
   Debug port.
- Comprehensive free software HAL (*Hardware Abstraction Layer*) library including a variety of software examples, as well as direct access to the Arm<sup>®</sup> Mbed<sup>™</sup> online resources at <a href="http://mbed.org/">http://mbed.org/</a>



### Kebutuhan Sistem - STM32 Nucleo-64 Board

- Komputer Windows® OS (XP, 7, 8 and 10)
- Kabel USB type A to Mini-B.



# **Software Development - STM32 Nucleo-64 Kit**

- ARM® mbed Enabled™ online
- STM32CubeIDE (Free)



# Support untuk STM32 Nucleo-64 Board

1. UM1724 - User manual - STM32 Nucleo-64 boards

https://www.st.com/resource/en/user\_manual/dm00105823-stm32-nucleo64-boards-mb1136-stmicroelectronics.pdf

2. STM32 Nucleo Board

https://www.st.com/en/evaluation-tools/stm32-nucleo-boards.html

3. NUCLEO-F401RE

https://os.mbed.com/platforms/ST-Nucleo-F401RE/



### Support untuk ST-Link/V2 di STM32 Nucleo-64 Board

1. STM32 ST-LINK utility (GUI for download program process)

https://www.st.com/content/st\_com/en/products/development-tools/software-development-tools/stm32-software-development-tools/stm32-programmers/stsw-link004.html

2. ST-Link/V2 Firmware

https://www.st.com/content/st\_com/en/products/development-tools/software-development-tools/stm32-software-development-tools/stm32-programmers/stsw-link007.html

3. ST-LINK/V2 USB driver (for Windows7/8/10)


https://www.st.com/content/st\_com/en/products/development-tools/software-development-tools/stm32-software-development-tools/stm32-utilities/stsw-link009.html



#### **Jenis STM32 Nucleo Board**

Untuk mengetahui STM32 Nucleo board jenis yang lain, silakan klik link di bawah ini!

https://www.st.com/en/evaluation-tools/stm32-nucleo-boards.html





# Terima kasih

