

How to set up a sevina machine

- Check the machine before starting. Are parts missing? Is the needle broken? Report to your teacher immediately
- The presser foot must always be RAISED when threading the machine
- To sew, the presser foot must always be LOWERED

- Guide the fabric through the machine from FRONT to BACK. Never pull at the fabric!
- Use the guide on the presser foot to help you line up your sewing to ensure straight and accurate stitching
- Always turn the hand wheel TOWARDS you, do not rock it backwards and forwards

Fill in the Blanks in Workbook

- Check that the needle is
- Check that the has been put in correctly.
- Check that the machine has been correctly.
- Check that the power and powerare in good working order.



