




- Frequency Selector Switch to eliminate the effect of harmonics.
- Three AC current ranges :20mA/200mA/200A.
- Data hold function.
- •Auto power-off function(automatically turns off in about 10 minutes).
- Rotary switch for easy one finger power-on and range selection.



KYORITSU ELECTRICAL INSTRUMENTS WORKS, LTD.

Compact, truly portable and high performance digital leakage current mini clamp meter.

LAYOUT DIAGRAM



FEATURES


- Frequency Selector Switch to eliminate the effect of harmonics.
- Measures from 0.01mA to 199.9A AC.
- Tear drop shaped jaws for easy use in tight places and crowded cable areas.
- Maximum conductor size is 24mm in diameter.
- Data hold function to allow for easy readings in dimly illuminated or hard-to-reach locations.
- Rotary switch for easy power-on and range selection.
- Auto power-off function to conserve battery power.

■ SPECIFICATIONS

© AC Current Ranges (at 23 ±5°C, RH75% or less)

| Range | Measuring Range | Accuracy Frequency Selector Switch | |
|-------|-----------------|------------------------------------|-----------------------------|
| | | | |
| | | 20mA | AC0~19.99mA |
| 200mA | AC0~199.9mA | ±5.0%rdg ±6dgt | (50/60Hz) |
| 200A | AC0~100.0A | (40~400Hz) | |
| | AC100.1~199.9A | ±5.0%rdg ±4dgt (50/60Hz) | ±5.0%rdg ±5dgt (50/60Hz) |

| Maximum Circuit Voltage | AC300V | |
|----------------------------|---|--|
| Withstand Voltage | AC1000V for 1 minute | |
| Response Time | Approx. 2 seconds | |
| Conductor Size | Approx. | |
| Dimensions | 149 (L) × 60 (W) × 26 (D)mm | |
| Weight | Approx. 120g (batteries included) | |
| Power Source | 1.5V button cell × 2 type LR-44 | |
| Accessories | Two LR-44 button cells Carring Case Model 9090 Instruction Manual | |
| Options | Model 8004. 8008 (Multi Trans) ★These Multi-Trans can not be used for leakage current measurement Model 8021 (Energizer) | |



Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely for correct use.

Failure to follow the safety rules can cause fire, trouble, electrical shock, etc. Therefore, make sure to operate the instrument on a correct power supply and voltage rating marked on each instrument.

*The contents of this catalogue may be subject to change without notice

DISTRIBUTOR



KYORITSU ELECTRICAL INSTRUMENTS WORKS. LTD.

No. 5-20 Nakane 2-chome, Meguro-ku, Tokyo, 152-0031 Japan Phone: (03) 3723-0131 Telex: 0246-6703 Fax: (03) 3723-0152 E-Mail:kew @ sh0. po. iijnet.or.jp

Cable Address: "KYORITSUKEIKI" TOKYO

Factories: Uwajima & Ehime