

POWER QUALITY ANALYZER KEW 6315



Simultaneous Power & Power quality measurements

Power/ Harmonics/ Waveform/ Power quality are recorded at all CHs. (Voltage: 3ch, Current 4ch)

- Helpful support functions
 Quick Start Guide, Wiring check and Sensor detection for easy and reliable measurement
- Measurement with high accuracy
 Guaranteed accuracy: ±0.3%rdg (energy),

±0.2%rdg (voltage/current)

Complies with the International Standard IEC 61000-4-30 Class S and the European Standard EN 50160

- Remote monitoring on PC and Android™ device Remote checking of measurement in real-time is possible via Bluetooth® communication. Recorded data can be saved in the supplied SD card. EN 50160 report can be generated after measurment by PC software.
- Various Clamp Current Sensors
 Various types of clamp and flexible sensors are available: from 1000mA range up to 3000A range and Earth leakage measurements
- Energy consumption check on site
 Trend and demand graphs for easy recognition.
- TFT color display with high resolution
- IEC 61010-1 CAT № 300V / CAT 🏻 600V / CAT 🗘 1000V

Simultaneous recording of all power and power quality with easy operation



Quick Start Guide

Easily and securely starts recording

One-Touch START/STOP Key for Quick Start Guide providing easy setup guides.







Guide start

①Select desirable recording item.
All (Power + Quality + Harmonics)

Power + Quality

Power + Harmonics

Connect to the circuit

Wring check

Select interval

Set recording time

Start recording

W/Wh

Power & Energy

Instantaneous value


		1ch	2ch	3ch		
٧	:	239.9	246.3	236.6	٧	
A	:	48.1	48.3	47.9	Α	
	:	11.5	11.9	11.5	kW	
Q	:	1.2	1.0		kvar	
S	:	11.6	11.8	11.4	kVA	
PF	:	0.812	0.809	0.792		Inst
	:	44.8	kw f:	60.01	Hz	Avg
Q	:	4.5				Max
S	:	44.8				
PF	:	0.788	An:	4974	mA	Min
DC1	:	0	m/ DC2:	0	mV	00:38 /1min

VI 1851 240.7 V 1851 243.3 V VS 1851 233.1 V 1851 59.99 Hz

List


Zoom(8-split)

Zoom(4-split)



- Measures instantaneous / average / min / max for voltage, current, active / reactive / apparent power, cos θ and line frequency all on one screen.
 The recording time for these parameters can be set from 1
- second up to 2 hours in several steps.
- Trend of all main parameters and customized Zoom functions.
- Function to define size of capacitor banks of PF correction unit.

Integration value




- The display will list the active / reactive / apparent energy in total and for each phase consumed (or generated in case of co-generation like solar panels, etc).
- The elapsed time is also shown on the same display screen.

Demand








Measurement


Change in specific period


Demand change

To support demand control, present energy usage and estimated value are displayed on a graph while recording max demand value and the occurred time.

Solution Vector and Wiring check







Vector

Wiring check

Ideal vector

- Can display voltage and current by vector per CH and also unbalance ratio.
- Wiring check function confirms connection and displays ideal vector (at the lower left corner) according to the selected wiring system, and shows connection errors.

PRINT Print Screen

This function takes a color photo of the display screen and saves it as BMP file. Useful for report creation.



QUALITY Power Quality

Event


A	ll even	ts	Occurrence			
	101.0	٧	2013/07/18	10:45:43.136		
5	50.4	٧	2013/07/18	10:45:43.136		
4	87.1	٧	2013/07/18	10:45:35.136		
	128.5			10:45:27.136		
	-217.1	V	2013/07/18	10:45:27.136		
4	50.4		2013/07/18	10:45:18.136		
1	87.1			10:45:10.136		
	128.5	٧	2013/07/18	10:45:02.136		

Measures voltage swells / dips / interruptions / transients and inrush currents that may indicate a weak power distribution system. Such phenomena may damage or reset devices. KEW 6315 can catch swells / dips / interruptions and inrush currents based on half cycle (10 ms @ 50Hz or 8.3ms @ 60Hz) True RMS. All necessary data is displayed by pressing one key.

Swell

Swell is an instantaneous voltage increase, most of the time

originated by upstream power line failure or switching OFF large load or switching ON large capacitor.



POWER QUALITY ANALYZER K

Windows software for data analysis and setting via USB port

- Automatic creation of graph and list from recorded data.
- Centralized management of setting and recorded data acquired from multiple devices.
- Data can be expressed in crude oil and CO2 equivalent values in the report.

- ⟨System requirements⟩
 OS: Windows® 11/10
 Display: XGA (Resolution 1024×768 dots) or more
 Required hard-disk space: 1Gbyte or more
- Other: With CD-ROM drive and USB port, .NET Framework (4.6.1 or later)

*Windows®is registered trademark of Microsoft in the United States.



CONTRACTOR OF THE PARTY OF	Marin- Hi	-		2009		_		-	-
	- 14-1 88 11								TATE:
		000							(0000)
THE RESIDENCE OF									-3
40.0	Policy Comments								- 1
201	440								- 4
THE RESIDENCE OF	Life I				_				
	may A								- 1
	-			-					- 1
1980 4						-			
A 100	1000								
Leve n	1000								- 1
	SHA MARKS								
Man World 14, 150									- 1
1000	E20								H
	100								
Market Land									100
	THE RESIDENCE			1 Ab	10 .14		440	150	1.55
	THE MESSAGE I								
	THE WORLD								
E133		ADD - ADD - 4.6	44	-			-		4.65
		MIN MIN 4.6		A434	- HE . I . IN		7.00	1.000	201

1970 1970 MEN'S MEN'S

Real-time and remote measurements.




Measurements can be graphically displayed on Android™ devices or PC in realtime via Bluetooth®







Waveform



- Displays voltage and current on each Ch by waveform.
- Scales of voltage/current axis and time axis are selectable, and also full-scale function for automatic scaling is available.

USB Terminal

Digital Output Terminal

Open Collector Output (1ch)


Analog Input Terminal

●2ch DC100mV / 1000mV, 10V, To record additional parameters (e.g. Lux, Temperature, Humidity, etc.)

Harmonics Analysis



List



- Graphic display of harmonic components up to 50th order for voltage, current and power in total and for
- List display of harmonic content, RMS value and phase angle of each order.
- Can analyze harmonic currents that may contribute to damage capacitor banks for PF correction, overheating transformers / neutral conductors / cables, unwanted tripping of breakers.

SD card Interface

SD cards up to 2GB can be used

Possible recording time When the 2GB of SD is used

Interval	REC item				
interval	Power	+Harmonics	7		
1sec.	13days	3days			
1min.	1year or more	3months			
30min.	10year or more	7year or more			

Data of power quality events are not considered to estimate the possible recording time. The max possible time will be shortened by recording such events.

Dip, as the opposite of a swell, is an instantaneous voltage decrease, most of the time caused by switching ON large load e.g. motors or by downstream power line failure.

Interruption


Interruption is a power line cut-off from any source of supply. It can be caused by a fault in a power line, which causes switch gear to open.

Transients/Over Voltage (Impulse)

Transient is a very fast and momentary voltage increase that can seriously damage devices connected to a power line. It may be caused by electrical switching events such as unstable contacts of relays, tripping of breakers but also by lightening. KEW 6315 can catch Transients from 24 us.


Inrush Current

Inrush current is a surge current that happens when motors, large or low impedance loads are switched ON. Then the current will stabilize as soon as the load has reached normal working conditions.











Flicker

Designed to meet IEC 61000-4-15

Flicker is a phenomenon giving an impression of unsteadiness of visual sensation induced by periodic voltage changes caused by fluctuating loads when using: arc furnace, spot welder, crane, excavator, etc.





Trend graph

Displays Pst (1min.) on a trend graph.

Optional Accessories

Load current clamp sensors

MODEL 8128 MODEL 8127 MODEL 8126 MODEL 8125 MODEL 8124



KEW 8146



KEW 8147



















Carrying case with magnet **Power supply** adapter **MODEL 8312 MODEL 9132**





Load current flexible clamp sensors



Before connecting with the sensors KEW 8133 or KEW 8135, confirm that the internal firmware version is later than the one listed in the table below.

MODEL	Firmware version		
KEW 8133	V1.50 or later		
KEW 8135	V3.00 or later		

The latest firmware is available on our website.

Distribution board door can be closed during measurement?

KEW 6315 facilitates safe testing thanks to its extreme compact design and with two attractive optional accessories: a carrying case with magnet (9132) for attaching it to the sides of metal enclosures and a power supply adapter (8312) which takes the power for the instrument from the supply being measured.

Kits



KEW 6315-01 KEW 6315 \times 1 MODEL 8125(500A) \times 3 Carrying case : MODEL 9125



KEW 6315-03

KEW 6315 × 1

KEW 6315-04 **KEW 6315-05**

KEW 6315 × 1 KEW 6315 × 1 KEW 8130(1000A) × 3 KEW 8130(1000A) × 4 KEW 8133(3000A) × 3 Carrying case : MODEL 9135 Carrying case : MODEL 9135 Carrying case : MODEL 9135

Specification

	_						
Wiring connections	1P2W, 1P3W, 3P3W, 3P4W						
Measurements and parameters	Apparent power, Ac Apparent energy, Po Demand, Harmonics Transients/Over volt	Voltage, Current, Frequency, Active power, Reactive power, Apparent power, Active energy, Reactive energy, Apparent energy, Power factor (cos#), Neutral current, Demand, Harmonics, Quality (Swell/Dip/Interruption, Transients/Over voltage, Inrush current, Unbalance rate), Capacitance calculation for PF correction unit, Flicker					
Voltage (RMS)							
Range	600.0/1000V						
Accuracy	10% to 150% agai Out of above range	600.0V Range: (sine wave 40 to 70Hz) 10% to 150% against 100V or more of nominal V: Nominal V±0.5% Out of above range: ±0.2%rdg±0.2%f.s. 1000V Range: ±0.2%rdg±0.2%f.s.(sine wave 40 to 70Hz)					
Allowable input	1 to 120% of each range (rms). 200% of each range (peak)						
Display range	0.15 to 130% of each range						
Crest factor	3 or less	3 or less					
Sampling speed of Voltage transient	24µs	24µs					
Current (RMS)							
Range	8128 8127 8126 8125 8124 8146/8147/8148 8130 8133 8135	(50A type) (100A type) (200A type) (500A type) (1000A type) (1000A type) (3000A type) (50A type)	300.0/3000A/AUTO 5000mA/50.00A/AUTO				
Accuracy	±0.2%rdg±0.2%f.s	±0.2%rdg±0.2%f.s.+accuracy of clamp sensor (sine wave, 40 to 70Hz)					
Allowable input	1 to 110% of each r	1 to 110% of each range (rms). 200% of each range (peak)					
Display range	0.15 to 130% of eac	ch range					
Crest factor	3 or less						

Active power					
Accuracy	±0.3%rdg±0.2%f.s. + accuracy of clamp sensor (power factor 1, sine wave, 40 to 70Hz)				
Influence of power factor	±1.0%rdg (reading at power factor 0.5 against power factor 1)				
Frequency meter range	40 to 70Hz				
Power source (AC Line)	AC100 to 240V / 50 to 60Hz / 7VA max				
Power source (DC battery)	Alkaline size AA battery LR6 or Ni-MH (HR15-51)×6 Battery life approx. 3 h (LR6, Backlight OFF)				
Internal memory	FLASH memory (4MB)				
PC card interface	SD card (2GB)				
Communication interface	USB, Bluetooth®				
Display	320×240(RGB)Pixel, 3.5inch color TFT display				
Display update period	1 sec.				
Temperature and humidity range	23±5℃, relative humidity 85% or less(no condensation)				
Operating temperature and humidity range	0 to 45°C. relative humidity 85% or less(no condensation)				
Storage temperature and humidity range	-20 to 60°C. relative humidity 85% or less(no condensation)				
Applicable standards	IEC 61010-1 CAT № 300V / CAT Ⅲ 600V / CAT Ⅲ 1000V Pollution degree 2 IEC 61010-2-030, IEC 61010-031, IEC 61326, EN 50160 IEC 61000-4-30 Class S, IEC 61000-4-15, IEC 61000-4-7				
Dimension / Weight	175 (L) × 120 (W) × 68 (D) mm / Approx. 900g				
Accessories	7141B (Voltage test lead set), 7170(Power cord[EU]) or 7240(Power cord[UK] 7219 (USB cable),8326-02(SD card [2GB]), 9125 (Carrying case for KEW 6315, KEW 6315-01) 9135 (Carrying case for KEW 6315-03, KEW 6315-04, KEW 6315-05), Input terminal platex6, KEW Windows for KEW6315 (software), Quick manual, Alkaline size AA battery (LR6)×6				
Optional accessories	8124, 8125, 8126, 8127, 8128 (Load current clamp sensor), 8130, 8133, 8135(Flexible clamp sensor), 8130, 8147, 8148(Leakage and Load current clamp sensor), 8312 (Power supply adapter), 9132 (Carrying case with magnet)				

Bluetooth[®] is a registered trademark of the Bluetooth SIG, Inc. Android™ is a registered trademark of the Google Inc.



Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely for correct use. Failure to follow the safety rules can cause fire, trouble, electrical shock, etc. Therefore, make sure to operate the instrument on a correct power supply and voltage rating marked on each instrument.

For inquiries or orders:



KYORITSU ELECTRICAL **INSTRUMENTS** WORKS, LTD.

2-5-20, Nakane, Meguro-ku, Tokyo, 152-0031 Japan Phone:+81-3-3723-0131 Fax:+81-3-3723-0152

www.kew-ltd.co.jp

