MECHATRONICS

TECHNOLOGIES, PRINCIPLES, DESIGN, AND ANALYSIS OF COMPLEX ELECTRO-MECHANICAL SYSTEMS

THADDEUS HUGHES

WITH CONTRIBUTIONS FROM CALEB HAGNER AND HOPEFULLY MORE TO COME

PUBLISHED IN THE WILD

APRIL 2020

Contents

1	\mathbf{Elec}	ctrical	
	1.1	Power	Electronics
		1.1.1	Batteries
		1.1.2	Regulators
		1.1.3	Breakers
		1.1.4	Wires
		1.1.5	Terminals and Connectors
	1.2	Sensor	S
		1.2.1	On/Off Position Sensors
		1.2.2	Variable Position Sensors
		1.2.3	Rangefinding
		1.2.4	IMUs
	1.3	Comm	nunication Protocols
		1.3.1	Dumb signals
		1.3.2	Serial links
		1.3.3	Bus/network signals
2	Goi	ng For	auth

Chapter 1


Electrical

1.1 Power Electronics

1.1.1 Batteries

Power sources are a critical component of electrical systems. For mobile ones, a battery is the obvious choice- the question is, what battery? Batteries may be rated by many parameters.

- 1. Chemistry refers to the type of chemicals and technologies being used in the battery. Spillable Lead-Acid, Sealed AGM, LiPo, NiCd are all different types of chemistries on the market each with their pros and cons. Some work better at cold temperatures, some cannot be used in extremely high temperatures, and some have much higher flammability hazards. Some require maintenance and watering, some do not.
- 2. Nominal voltage is the approximate voltage that a battery will sit at. This will fluctuate throughout operation both due to internal resistance and chemical changes- over time the battery will drain and the voltage may sink. A 12 volt nominal AGM battery may be fully charged at 13.5 volts, but be depleted at 11
- 3. Amp-hours is a measure of how much energy can be stored by the battery, specifically, how many hours it could run for if one amp was constantly being used.
- 4. Cold Cranking Amps (CCA) is a performance characteristic often found in car batteries, which must pull extremely high amounts of current in order to start an engine. As temperature negatively impacts the current-supplying ability of lead-acid batteries, the cranking capacity is usually measured at a representative worst-case temperature. The CCA rating is found by the number of amps a battery can support for 30 seconds at 0 Farenheit before the battery voltage drops to 1.2 volts per cell (7.2 volts for a 12V battery).
- 5. Other measures like Pulse Cranking Amps (PCA), Marine Cranking Amps (MCA), and Hot Cranking Amps (HCA) also exist.
- 6. *Internal resistance* is a key performance characteristic that is often not rated. This is a measurement that is found by realizing the battery is not an ideal voltage source, and instead modeling it as such:



$$V_{nom} - I_{load}R_{int} = V_{load} = V_{apparent}$$

$$\tag{1.1}$$

This behavior is fairly accurate: when more current is drawn, the apparent voltage of the battery will drop as well.

- Regulators 1.1.2
- 1.1.3 **Breakers**
- 1.1.4 Wires
- 1.1.5 Terminals and Connectors

1.2 Sensors

1.2.1 On/Off Position Sensors




- a) Limit switches are basic switches. They mechanically switch power between different positions- so do not require power to operate them (just signal).
- b) Inductive proximity switches send out a magnetic field and detect interference in this field caused by metallic objects (ferrous metals usually work best). This allows them to sense if an object is in position without risking dangerous mechanical contact. They require appropriate power to operate (refer to their datasheet for requirements). These sensors come in different packages, although the screw-body style shown is the most common. They are also rated by their minimum and maximum sensing distances.
- c) IR photoeyes emit infrared radiation and measure how much is reflected back. This allows any object to be detected if it is within the sensing range. They require power to operate (refer to their datasheet for requirements).
- d) Beam breaks emit infrared lasers and collect them on the opposite side. If an object blocks the path, the beam is broken, causing a change in signal.

Switches and sensors may be denoted as ¡x¿P¡y¿T to indicate how they may be wired. For example, a SPDT, or Single-Pole Double-Throw switch has a single contactor which can be switched between two positions. A DPST may only alternative the switch between a connected and unconnected state (single pole) but has a second electrically isolated version of the switch (double-throw).

Switches also may be momentary, reverting state as soon as they are unpressed, or toggle, staying put until actively switched back (like a lightswitch, or a pushbutton pen). If the switch is momentary, it may be either normally open (NO) or normally closed (NC), referring to if the switch is open or closed by default. If the switch has two poles, the poles may be referred to as NO and NC as one will be normally opened, and one normally closed.

Sensors can be wired in various ways.



- a) Pull down resistors make the inputs of a microprocessor rest naturally at ground level. When the connected switch is closed, the resistance of the switch is much much less than the pulldown resistor, so the voltage of the input will rise to the logic voltage. The resistor is sized so as not to consume too much current (usually R=5 to 20 k Ω). A microprocessor may have such a resistor built-in to the circuitry, although the resistor may need to be enabled.
- b) Pull up resistors work on the same principle as pull down resistors but with reversed voltages. On the RoboRIO, 2.2 k Ω pull-up resistors are on all DIO pins when in input mode.
- c) NPN and PNP sensors are to be wired as shown. You may note that the wiring looks the same as for a pull-up or pull-down; match the type of pulling resistor in your microprocessor to the type of sensor you intend to use, otherwise external pulling resistors may be necessary.

1.2.2 Variable Position Sensors

(a) Encoder

(b) Potentiometer

- (c) LVDT
- a) *Encoders* use rotating discs with multiple on/off positions in them to determine position. The on/off mechanism could be optical, magnetic, or something else entirely. A microprocessor running fast enough can watch the waveform produced by the encoder and determine how much the position has changed. Some encoders have builtin microprocessors, which can feed back more complex signals, while others may simply feed back *quadrature* data from the two channels that are monitored.
- b) Potentiometers have a resistive element, with the moving wiper making contact somewhere in the middle of it. When the wiper moves, the resistance between the wiper and the ends changes, which allows the voltage to be read. These are inherently absolute sensors- power cycling does not affect the resistance values. Multi-turn potentiometers allow the shaft to be rotated multiple times by running the wiper through a helical spiral. Linear potentiometers also exist- they often come in a piston-style package that can be mounted with rod ends.
- c) Linear Variable Differential Transformers (LVDTs) use multiple magnetic fields and measurements to determine position. They are quite expensive, but can be used in harsh environments with high accuracies. Rotational equivalents (RVDTs) also exist.

1.2.3 Rangefinding

- a) Ultrasonic sensors send out high-pitched sound waves and measure how long it takes for them to return. These can be finnicky, and do not work to detect objects that absorb, rather than reflect sound.
- b) Time of flight sensors work on the same principle as ultrasonic sensors, but with light. Light travels much, much faster- so these devices are more sophisticated and expensive.
- c) LIDAR systems employ a moving time of flight sensor to build a 3D map of the surroundings.
- d) Computer Vision (CV) can be used to pick up targets visually and determine their distance and relative position. It's particularly easy when the targets are a specialized color and shape that is distinct from everything else. CV systems can operate on even the simplest of hardware such as a smartphone, but the latency and image quality may suffer. Specialized sensors exist to improve the key performance parameters when using a camera in a real-time system.

1.2.4 IMUs

- a) Gyroscopes measure the rate of rotational acceleration. They can be used to find rotational velocity and position by performing numeric integration with a computer. As the rotational acceleration/velocity on a rigid body is constant, it does not matter where they are mounted so long as it is of sufficient rigidity and vibration isolation.
- b) Accelerometers measure linear acceleration. They can be used to find linear velocity and position by performing numeric integration with a computer.
- c) Magnetometers or digital compasses pick up magnetic fields (such as the earth's). This allows them to determine absolute orientation, although magnetic fields can be greatly disturbed by metallic structures and buildings.
- d) Integrated Motion Units combine several of these sensors into one system, complete with an onboard microprocessor to perform aforementioned numerical integration. This dedicated processing allows them to acheive high integration accuracy.

1.3 Communication Protocols

1.3.1 Dumb signals

- a) Simple high and low signals can convey whether something is active or inactive at a particular point in time.
- b) Analog signals can convey a particular variable value rather than a high or low. However, they require complex circuits to encode and decode from digital devices
- c) Pulse-width modulation (PWM) allows for the unidirectional trasmittal of variables over one signal wire without the need for analog circuitry. A square wave of fixed frequency is generated and the variable to be sent is encoded in the pulse width or duty cycle. Typical "servo style" PWM uses a frequency of 50 Hz (or a period of 20 ms), with a pulse width of 1 ms corresponding to the minimum value (full reverse, or 0 degrees), and 2 ms corresponding to the maximum value (full forwards, or 180 degrees). This is a reasonably safe signal to send safety critical functions on as any interruptions to the signal would result in clearly invalid data.

1.3.2 Serial links

Serial encoding of data takes a binary signal and serializes it. For example, the ASCII character 'A' is represented in binary as 01000001. So, one device would send a low signal, then a high signal, followed by five low signals, and a final high signal in order to transmit an 'A'. It isn't quite this simple, though.

To begin with, data is not always going to be transmitted over the line. The line will be a constant value before the data to be transmitted is sent. The sending device must first send a *start bit* to denote the beginning of a transmission. Additionally, a *stop bit* may be sent to denote the end of the transmission.

a) Serial

1.3.3 Bus/network signals

Chapter 2

Going Forth