# Bluetooth Low Energy Pairing

## Bluetooth Low Energy (BLE)


- 블루투스 저전력 프로토콜(Bluetooth Low Energy) 또는 줄여서 BLE은 블루투스 4.0스 펙이 2010년 채택된 이후로 배포되는 저전력 블루투스이다.
- 저전력을 사용하며, BT Classic(기존 블루투스)와는 장단점이 존재한다.
- 주로 피트니스, 스포츠, 헬스케어와 같은 분야에서 많이 사용된다.





#### Advertising


- 페어링을 진행할 수 있도록 주변의 모든 기기에게 신호를 보내 자신을 알리는 행위
- Advertising 진행하는 두 기기는 다음과 같은 역할을 맡는다.
  - Advertiser : Advertising Packet을 주기적으로 송신하는 역할
  - Observer : Advertiser가 보내는 패킷을 주기적으로 수신하는 역할






### Advertising

- Hopping 기법을 사용하여 다음 3개의 채널(2402MHz (Ch37), 2426MHz(Ch38), 2480MHz(Ch39))에서 Advertising을 진행한다.
- 각각 자신의 Time Interval을 가지고 Hopping을 진행한다.



#### **Pairing Security**

- Legacy Pairing과 SSP(Simple Secure Pairing)으로 나뉘던 BT Classic과 다르게 BLE는 Legacy Pairing과 Secure Connection 둘로 나뉜다.
- 페어링 진행 이전 서로의 정보를 교환한 후 다음 4가지 중 하나를 사용하여 진행한다.
  - Just Works Legacy or Secure
  - Passkey Entry Legacy or Secure
  - Out Of Band Legacy or Secure
  - Numeric Comparison Only Secure Connection



## Security Request (Optional)

- Slave가 Master에게 보내는 보안 요청으로 Master는 해당 요청을 통해 링크를 암호화하거나 페 어링을 시작하게 할 수 있다.
- 만약 Master가 Slave의 요청을 들어주지 못하는 환경일 때 Pairing Not Supported 명령을 보내는 것으로 연결을 해제한다.

Field			AuthReq (1 Byte)						
Sub- define	Opcode (1 Byte)	Bonding Flags	MITM	Secure Connection	Keypress Flag	Reserved			
Bits	8	2	1	1	1	3			

#### AuthReq

- Bonding Flags(BF) : 페어링 이후 장기귀(long-term)를 교환하여 저장할 것인지를 나타내는 값
- MITM: MITM 보호를 사용할 것인지를 나타내는 값
- Secure Connection(SC): LE Secure Connection을 사용할 것인지를 나타내는 값
  - 두 기기 모두가 1일때 Secure Connection을 진행한다.
- Keypress Flag(KF) : Passkey Entry Protocol에서 사용되는 특수 값
- Reserved : 의미 없으며 무시되는 값

Field		AuthReq (1 Byte)						
Sub- define	Opcode (1 Byte)	Bonding Flags (2 Bits)	MITM (1 Bi+)	Secure Connection (1 Bit)	Keypress Flag (1 Bit)	Reserved (3 Bits)		

Q & A

```
      Source
      Destination
      Protocol
      Length
      Info

      SamsungE_23:8f:b7 (Galaxy Fit2 (8FB7))
      1ocalhost (♦♦♦♦♦♦♦♦ A80)
      SMP
      11 Rcvd Security Request
```

```
V Bluetooth Security Manager Protocol
    Opcode: Security Request (0x0b)

V AuthReq: 0x0c, Secure Connection Flag, MITM Flag, Bonding Flags: No Bonding
    000. .... = Reserved: 0x0
    ...0 .... = Keypress Flag: False
    .... 1... = Secure Connection Flag: True
    .... .1.. = MITM Flag: True
    .... .00 = Bonding Flags: No Bonding (0x0)
```

## Pairing (Request & Response)

- 연결하려는 기기가 이후 서로의 IO(Input/Output), MITM, 보호 연결 요구와 같은 보안 기능을 교 환하는 명령
- 해당 값들을 서로 교환하는 것으로 이후 페어링을 어떠한 방법으로 진행할지 결정된다.
- Request(Master to Slave), Response(Slave to Master)

Field					Aut	hReq	(1 Byt	e)	Massims	luidi adam	Dagage Jan
Sub- define	Opcode (1 Byte)	IO Capa (1 Byte)	OOB DF (1 Byte)	BF	MITM	SC	KF	Reserved	Maximum Encryption Key Size (1 Byte)	Initiator Key Distribution (1 Byte)	Responder Key Distribution (1 Byte)
Bits	8	8	8	2	1	1	1	3	8	8	8

## Pairing (Request & Response)

- IO Capability : 현재 기기가 사용할 수 있는 IO(Input/Output)을 나타내는 값
- OOB Data Flags(OOB DF): OOB(Out-Of-Band) 즉, 블루투스가 아닌 다른 통신 수단(NFC, QR, ...)
   을 사용하여 페어링을 진행할 것인지를 나타내는 값
- AuthReq : 이전 장표와 동일
- Maximum Encryption Key Size : 암호화 키 크기를 나타내는 값 (7 ~ 16 octets 사이)
- (Initiator or Responder) Key Distribution : 배포/생성 또는 사용을 요청하는 귀를 나타내는 값.

				AuthReq (1 Byte)				M i	lu:4: .4	Daga an Jan
Pcode Byte)	IO Capa (1 Byte)	OOB DF (1 Byte)	BF	MITM	SC	KF	Reserved	Maximum Encryption Key Size (1 Byte)	Initiator Key Distribution (1 Byte)	Responder Key Distribution (1 Byte)

# **Pairing**

```
Destination
 Source
                                                                                          Protocol Length
                                                                                                             Info
                                                SamsungE_23:8f:b7 (Galaxy Fit2 (8FB... SMP
                                                                                                          16 Sent Pairing Request
localhost ( * * * * * * * * * * * * * A80)
                                                Destination
Source
                                                                                         Protocol Length
                                                                                                            Info
SamsungE_23:8f:b7 (Galaxy Fit2 (8FB7))
                                                                                         SMP
                                                                                                          16 Rcvd Pairing Response:
                                                localhost ( • • • • • • • • • A80)
```

```
Bluetooth Security Manager Protocol
   Opcode: Pairing Request (0x01)
    IO Capability: Keyboard, Display (0x04)
    OOB Data Flags: OOB Auth. Data Not Present (0x00)

    AuthReq: 0x2d, Secure Connection Flag, MITM Flag, Bonding Flags: Bonding

       001. .... = Reserved: 0x1
       ...0 .... = Keypress Flag: False
       .... 1... = Secure Connection Flag: True
       .... .1.. = MITM Flag: True
       .... ..01 = Bonding Flags: Bonding (0x1)
   Max Encryption Key Size: 16

▼ Initiator Key Distribution: 0x0f, Link Key, Signature Key (CSRK), Id Key (IRK), Encryption Key (LTK)

       0000 .... = Reserved: 0x0
       .... 1... = Link Key: True
       .... .1.. = Signature Key (CSRK): True
       .... ..1. = Id Key (IRK): True
       .... 1 = Encryption Key (LTK): True

▼ Responder Key Distribution: 0x0f, Link Key, Signature Key (CSRK), Id Key (IRK), Encryption Key (LTK)

       0000 .... = Reserved: 0x0
       .... 1... = Link Key: True
       .... .1.. = Signature Key (CSRK): True
       .... ..1. = Id Key (IRK): True
       .... 1 = Encryption Key (LTK): True
```

# Rules for using OOB and MITM flags

		Initiator							
		OOB Set	OOB Not Set	MITM Set	MITM Not Set				
	OOB Set	Use OOB	Check MITM						
Jer	OOB Not Set	Check MITM	Check MITM						
Responder	MITM Set			Use IO Capabilities	Use IO Capabilities				
~	MITM Not Set			Use IO Capabilities	Use Just Works				

		tiator			
		OOB Set	OOB Not Set	MITM Set	MITM Not Set
	OOB Set	Use OOB	Use OOB		
Responder	OOB Not Set	Use OOB	Check MITM		
	MITM Set			Use IO Capabilities	Use IO Capabilities
	MITM Not Set			Use IO Capabilities	Use Just Works

BLE

in Legacy Pairing

in Secure Connection

# Mapping of 10 Capabilities to Key Generation Method

		Initiator									
Responder	DisplayOnly	Display YesNo	Keyboard Only	NoInput NoOutput	Keyboard Display						
Display Only	Just Works Unauthenti- cated	Just Works Unauthenti- cated	Passkey Entry: responder displays, ini- tiator inputs Authenti- cated	Just Works Unauthenti- cated	Passkey Entry: responder displays, ini- tiator inputs Authenti- cated						
Display YesNo	Just Works Unauthenti-	Just Works (For LE Legacy Pairing) Unauthenti- cated	Passkey Entry: responder displays, ini-	Just Works Unauthenti- cated	Passkey Entry (For LE Legacy Pairing): responder displays, initiator inputs Authenticated						
	cated	Numeric Comparison (For LE Secure Connections) Authenticated	tiator inputs Authenti- cated		Numeric Comparison (For LE Secure Connections) Authenticated						

	Initiator								
Responder	DisplayOnly	Display YesNo	Keyboard Only	NoInput NoOutput	Keyboard Display				
Keyboard Only	Passkey Entry: initia- tor displays, responder inputs Authenti- cated	Passkey Entry: initia- tor displays, responder inputs Authenti- cated	Passkey Entry: initia- tor and responder inputs Authenti- cated	Just Works Unauthenti- cated	Passkey Entry: initia- tor displays, responder inputs Authenti- cated				
NoInput NoOutput	Just Works Unauthenti- cated	Just Works Unauthenti- cated	Just Works Unauthenti- cated	Just Works Unauthenti- cated	Just Works Unauthenti- cated				
Keyboard Display	Passkey Entry: initia- tor displays, responder inputs Authenti- cated	Passkey Entry (For LE Legacy Pairing): initiator dis- plays, responder inputs Authenti- cated  Numeric Comparison (For LE Secure Con- nections) Authenti- cated	Passkey Entry: responder displays, ini- tiator inputs Authenti- cated	Just Works Unauthenti- cated	Passkey Entry (For LE Legacy Pairing): initiator dis- plays, responder inputs Authenti- cated  Numeric Comparison (For LE Secure Con- nections) Authenti- cated				

Q & A

#### Public Key Exchange

- Legacy Pairing과 Secure Connecion의 가장 큰 차이점
- Pairing Request & Response의 Auth Req 필드의 Secure Connection값이 둘 다 1일 때 사용한다.
- Diffie-Hellman Key exchange를 사용한다.
- Just Works, Numeric Comparion을 진행하기 이전에 Pairing Public Key를 통해 서로 공개기를 교환하여 비밀기를 계산한 후 이후 과정에서 이를 사용한다.

# **Pairing**

- Bluetooth Security Manager Protocol
  - Opcode: Pairing Public Key (0x0c)
  - Public Key X: 0479c015303b047ccd82ac9a68b9c1ab1d1fa7664be26310a57b4ee2b8f53f78
  - Public Key Y: 62ce7146d60a0b23c27081421a9f93e52a1027dbec3958223b9d0001ab3cb5a8
- ▼ Bluetooth Security Manager Protocol
  - Opcode: Pairing Public Key (0x0c)
  - Public Key X: 3760bc694d8b087bc45b79bcb821f7d8f8bc3b97895d6b3d8621a1d9c5d365e4
  - Public Key Y: 74ffe85c0cd18ca0a0ad31fdd3bf37ee1bec39a531849677ba25edd5f9fe7eba

Q & A