

- 1) SEAL ALL DUPONT™ TYVEK® WEATHER BARRIER SEAMS AND REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE. 2) FASTEN DUPONT™ TYVEK® WEATHER BARRIER WITH RECOMMENDED FASTENERS AND SPACING.

3) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.

4) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES, REGULATIONS AND LAWS TO DETERMINE THE APPROPRIATE CONSTRUCTION METHONDS AND MATERIALS NEEDED.

SCALE: NOT TO SCALE

REVISION DATE: 11/17/10

DRAWING: CW-BXO-202

PENETRATION DETAIL - METHOD 1

BRICK VENEER / EXTERIOR INSULATION (WRAP OVER) / STEEL STUD WALL



DUPONT™ COMMERCIAL SEALANT

REINFORCE **DUPONT** ™ **TYVEK**® **COMMERCIALWRAP®** USING 3" DUPONT™ TYVEK® TAPE